

Inclusive Technology
www.inclusive.co.uk

Compatibility

The it-Send is compatible with any Simply Works receiver. These include:

- it-Receive - for connection to a computer.
- it-Control, it-Control Lite and it-Control Pro - for connection to battery toys or mains power adaptors.

It enables you to use any wired switch that has a standard 3.5mm jack with Simply Works.

Batteries

The it-Send requires 2 x AAA batteries. These are fitted by removing the battery cover on the underside of the device.

Ensure the batteries are inserted correctly - match the + and – symbols on the battery with those in the battery compartment. Replace the battery cover and screw. It is recommended that good quality batteries are used (such as Energiser or Duracell).

If you are not intending to use the it-Send for an extended period (e.g. a number of weeks) it is advisable to remove the batteries to prevent leakage, which may damage the device.

Pairing it-Send with it-Receive (for computer connection)

1. Ensure the it-Receive is connected to your computer.
2. Place the it-Send close to the it-Receive (within 1 metre).
3. Press and release the PAIR button on the front of the it-Receive. The red light next to it will begin flashing.
4. Within 10 seconds press and release the PAIR button on the it-Send.
5. The light on the it-Receive will continue to flash while the devices communicate with each other.
6. Once the pairing is successful the red light on the it-Receive will stay on for 5 seconds.
7. If the light continues to flash for 30 seconds and then stops, repeat the process above. If it still does not pair successfully, refer to the Troubleshooting section.
8. If pairing two it-Sends, repeat the process above for the second switch.

Pairing information is retained in the it-Send's memory even after changing the batteries.

Operation with it-Receive

Plug your choice of switch into the socket marked INPUT on the it-Send.

To enable the switch to interact with software on the computer, the correct mode will need to be selected on the it-Send. The mode is selected by pressing the MODE button on the front of the it-Send. The mode is shown on the display as a number (0-9) or letter (A-H). The table overleaf shows the function for each mode. Repeated pressing of the MODE button will cycle through 0-9 then A-H, then back to 0.

A single press of the MODE button will display the current mode.

To find the mode you require, refer to the manual for the software you are using. For example the function needed for using one switch with Inclusive Technology software is Space (Mode 7). If you were using two switches with Inclusive Technology software you would set one to Space (Mode 7) and one to Enter (Mode 8).

Mode setting	Class	Function	Explanation
0	Switch	Switch 1	Gamepad functions - used with various software including Inclusive Technology and Crick.*
1	Switch	Switch 2	
2	Switch	Switch 3	
3	Switch	Switch 4	
4	Mouse	Left Click	Mouse functions.
5	Mouse	Right Click	
6	Mouse	Drag Lock	
7	Keyboard	Space	General purpose keyboard functions used widely for computer access.
8	Keyboard	Enter	
9	Keyboard	Tab	

A	Keyboard	~1	Tilda** functions used on new tablet computer Apps.
B	Keyboard	~3	
C	Keyboard	F7	Functions 7 and 8 - used with Clicker*, for example.
D	Keyboard	F8	
E	Keyboard	Numeral 2	Used with IntelliTools* and other US software.
F	Keyboard	Numeral 3	
G	Keyboard	Up Arrow	General purpose keyboard functions used mainly for navigation.
H	Keyboard	Down Arrow	
I	Keyboard	Left Arrow	
J	Keyboard	Right Arrow	

* All Trademarks are property of their respected owners and are acknowledged.

** Do NOT use Tilda functions when controlling toys or mains appliances (e.g. with the it-Control, it-Control Pro or the it-Click-On Plus.)

Pairing it-Send with it-Control devices (for toy connection)

1. Place the it-Send close to the it-Control device.
2. Press and release the PAIR button on the front of the it-Control device. The red light next to it will begin flashing.
3. Within 10 seconds press and release the PAIR button on the it-Send.
4. The light on the it-Control will continue to flash while the devices communicate with each other.
5. Once the pairing is successful the red light on the it-Control will stay on for 5 seconds.
6. If the light continues to flash for 30 seconds and then stops, repeat the process above. If it still does not pair successfully, refer to the Troubleshooting section.

Operation with it-Control devices

You must set the mode on the it-Send to 0. To do this press the MODE button on the front of the it-Send until the display shows 0.

The operation of the it-Send is determined by the settings on the it-Control.

it-Send troubleshooting

Problem	Possible cause
it-Send not functioning when used with it-Receive.	<ul style="list-style-type: none">• Devices are not paired - see pairing instructions.• No batteries in it-Send, or batteries are flat - insert or replace batteries.
it-Send not functioning when used with it-Control devices.	<ul style="list-style-type: none">• Mode not set to 0 - press MODE button to set mode to 0.• Devices are not paired - see pairing instructions.• No batteries in it-Send, or batteries are flat - insert or replace batteries.
it-Send works erratically or intermittently.	<ul style="list-style-type: none">• Batteries in it-Send flat - replace batteries.• Out of range - move it-Send closer to receiver.• Interference - move it-Send and receiver away from sources of interference (e.g. mobile phone).
Devices will not pair.	<ul style="list-style-type: none">• No batteries in it-Send, or batteries are flat - insert or replace batteries.• Ensure it-Send is close to receiver while pairing (within 1 metre).

Maintenance

Your Simply Works device contains no user serviceable parts. If it does not work as expected consult the troubleshooting guide. If there are still problems with the device please contact your supplier.


Warranty

Your Simply Works device is warranted against defects in manufacture or component failure. The unit is designed for domestic and educational applications. Use outside these areas will invalidate the warranty. Unauthorised repair or modification, mechanical abuse, immersion in any liquid or connection to incompatible equipment will also invalidate the warranty.

Technical support

If you need further support with any of the Simply Works range, please contact us:

Inclusive Technology Ltd
Riverside Court, Huddersfield Road
Delph
Oldham OL3 5FZ
United Kingdom
Tel: +44 (0)1457 819790
Fax: +44 (0)1457 819799
email: inclusive@inclusive.co.uk
www.inclusive.co.uk



Inclusive Technology Ltd

Riverside Court, Huddersfield Road
Delph, Oldham OL3 5FZ
United Kingdom

Tel: +44 (0)1457 819790

Fax: +44 (0)1457 819799

email: inclusive@inclusive.co.uk

www.inclusive.co.uk