



IntelliMix Room

Audio Processing Software

User guide for Shure IntelliMix Room DSP software. Learn how to install, activate, and manage IntelliMix Room to bring crystal-clear audio to all of your rooms.

Version: 9.4 (2021-E)

Table of Contents

IntelliMix Room Audio Processing Software	4	Use Cases	16
What is IntelliMix® Room?	4	Overview of Shure Conferencing Devices	16
What Do I Need to Use IntelliMix Room?	4	Use Case: IntelliMix Room, 2 MXA310s, and Display with Built-In Speakers	18
Choosing a Channel Count	4	Use Case: IntelliMix Room, 2 MXA910s, and Loudspeakers	19
How to Purchase IntelliMix Room	5	Applying DSP Blocks	20
IntelliMix Room Free Trial	5	Using Designer's Optimize Workflow	20
System Requirements	5	Schematic View	21
Optimizing Windows for Conference Room Audio Processing	6	Parametric Equalizer	22
Installation Guide	7	EQ Contours for IntelliMix Room	24
Installing IntelliMix Room	7	Acoustic Echo Cancellation	24
Installing with Mass Deployment Tools	7	Noise Reduction	25
IntelliMix Room Firewall Changes	8	Compressor	25
Basics of Shure Designer Software	8	Delay	26
Discovering IntelliMix Room in Designer	9	Automatic Gain Control (AGC)	26
Uninstalling IntelliMix Room	10	Using Call Status	26
Updating IntelliMix Room	10	Mute Synchronization	27
Activating IntelliMix Room	10	Mute and Fader Groups	27
How IntelliMix Room Licenses Work	11	Adjusting Input levels	28
Renewing a License	12	Pre- and Post-Gain Metering	28
Moving or Reassigning Licenses	12	When to Use the Input and Automixer Gain Faders	28
Deactivating Licenses	13	Matrix Mixer	28
License Server Details	13	Crosspoint Gain	29
Using Videoconferencing Software with IntelliMix Room	13	Routing Channels	29
Routing Microphone Signals to the DSP	14	Automix Modes	29
Routing Far-End Audio to IntelliMix Room	15	Gating	29
Sending Far-End Audio to Loudspeakers and Other Sources	16	Gain Sharing	29
		Manual	29
		Automix Settings	29

Automixer Direct Out Tap Points	30	Dante Flows for Shure Devices	35
Network Setup Examples	31	Using Command Strings with IntelliMix Room	36
Choosing Networks for Shure Control and Dante Audio	32	Troubleshooting	36
Choosing a Licensing NIC	33	Event Logs	38
Security Testing	33	Reset	39
IntelliMix Room IP Ports and Protocols	33	Specifications	39
Compatibility with Dante Domain Manager	34	Contact Customer Support	40
How to Recover IntelliMix Room from Inaccessible Dante Domains	35		

IntelliMix Room Audio Processing Software

What is IntelliMix[®] Room?


IntelliMix Room is digital signal processing (DSP) software designed to optimize the performance of Shure networked microphones with videoconferencing software, resulting in better conference room audio all around. It's designed to run on the same computer as any videoconferencing software, which reduces the amount of equipment in the room.





What Do I Need to Use IntelliMix Room?

IntelliMix Room requires other software and hardware to work in your room. You'll need the following:

Software:

-  **Shure Designer** software installed on a separate computer and connected to the same network as IntelliMix Room.
 - Designer lets you control all installations of IntelliMix Room in one place.
 - For best results, do not run IntelliMix Room and Designer on the same computer.
- **Videoconferencing software** (such as Zoom, Microsoft Teams, or BlueJeans) installed on the same computer/device as IntelliMix Room

Hardware:

-  **Dante-enabled microphone**, such as a Shure MXA910 or MXA310
-  **PC** or other physical device optimized for running IntelliMix Room (no virtual machines)
 - See the [System Requirements](#) for recommended specifications.
- **Other room components**, such as displays, cameras, loudspeakers, switches, Cat5e cables, and meeting control interfaces

Choosing a Channel Count

IntelliMix Room software is sold based on the number of IntelliMix DSP channels you need. For example, an 8-channel license has 8 channels with all of the IntelliMix DSP blocks (AEC, NR, and AGC).

The software always includes 8 auxiliary Dante input channels **without** IntelliMix processing. You shouldn't count these when deciding on your channel needs.

To choose a channel count:

- **Check your Dante-enabled microphone's channel count**
 - Plan the microphone's coverage for the room, and see how many channels you will need. For example, if you use 2 MXA910s, a 16-channel license is the best option. For 2 MXA310s, an 8-channel license covers your needs.
 - For best results, each microphone channel should have an IntelliMix DSP input channel.
 - Larger rooms may require multiple microphones.
 - Don't count the microphone's automix out channel when calculating channel needs.
- **Plan for future device needs**
 - If you plan to add more microphone channels with processing in future, include them in your channel count.

Room Size	Small/Medium	Large
Possible equipment combinations	MXA910 or 2 MXA310s	2 MXA910s or 3-4 MXA310s
Channel count	8 channels	16 channels

How to Purchase IntelliMix Room

To purchase, contact your local Shure sales representative (find yours at [shure.com](https://www.shure.com)). For each installation, you can choose from 8 or 16 channels of IntelliMix DSP. Licenses are available for 3- and 5-year durations.

After purchasing, you'll receive an email with instructions for creating a software.shure.com account, where you can find your license ID. The license ID activates all purchased installations.

Next steps:

- Install IntelliMix Room on all devices.
- Discover and activate all IntelliMix Room installations using Shure Designer software.
- Apply DSP and route audio for each installation using Designer.

IntelliMix Room Free Trial

Before purchasing, you can try out a 16-channel version of IntelliMix Room. The software runs exactly like a purchased version during the trial.

To download a trial version, contact your local Shure sales representative (find yours at [shure.com](https://www.shure.com)).

Once you set up a trial license, you'll get a license ID for the software. Enter that ID in Designer to activate the trial.

System Requirements

IntelliMix Room runs on devices that meet both the minimum specifications and the recommended specifications.

For best results:

- Install on devices that meet the recommended specifications.
- Do not run IntelliMix Room and Designer on the same PC.

Devices that don't meet the minimum specifications are not supported. Virtual machines are not supported.

Recommended Specifications

- **Processor:**
 - Intel (64 bit)
 - 8th generation Core i5 or better
 - 2.2 GHz or better
 - 4 physical cores or better
 - 6 threads (logical processors) or better
- **Memory:**
 - 8 GB RAM
- **Storage:**
 - Solid State Drive (SSD) required
- **Operating System (64 bit):**
 - Windows 10 Pro
 - Windows 10 Pro Education
 - Windows 10 Education
 - Windows 10 IoT
 - Windows 10 Enterprise IoT
- **Internet Connection:**
 - Required for initial license activation

Minimum Specifications and Use Case Limitations

If your device meets the minimum specifications but not the recommended specifications, see the Use Case Limitations.

- **Processor:**
 - Intel (64 bit)
 - 7th generation Core i5
 - 2.2 GHz
 - 4 physical cores
 - 4 threads (logical processors)
- **Memory:**
 - 8 GB RAM
- **Storage:**
 - Solid State Drive (SSD) required
- **Operating System (64 bit):**
 - Windows 10 Pro
 - Windows 10 Pro Education
 - Windows 10 Education
 - Windows 10 IoT
 - Windows 10 Enterprise IoT
- **Internet Connection:**
 - Required for initial license activation
- **Use Case Limitations:**
 - Avoid using displays with resolutions above 1080p.
 - Avoid screen sharing displays with resolutions above 1080p.
 - Avoid using large-format, interactive touch screen displays. Touch panel controllers work.

Optimizing Windows for Conference Room Audio Processing

These are the recommended Windows settings for conference room audio processing:

- Disable Cortana.
- Disable notifications from Windows and installed programs.

- Use the high performance power plan in Power Options.
 - Make sure this plan uses active cooling in the advanced power options.
- Disable all Sleep and Hibernate settings.
- Disable network throttling.

Additionally, follow these system best practices:

- Reboot the computer regularly.
- Disconnect unused USB devices.
- Remove software with high CPU loads, such as games or streaming apps.
- Make sure the computer's BIOS is updated.
- Check that Ethernet, Wi-Fi, and display drivers are updated.

Installation Guide

Installing IntelliMix Room

Before installing, make sure you have admin rights for all devices.

1. Purchase IntelliMix Room from your Shure sales representative (find yours at shure.com).
2. Download the .exe from shure.com.
3. Launch the installation file and follow the steps.
4. Choose network interface cards (NICs) to use for Shure control, Dante audio, and licensing.
 - The Shure control NIC must match the one used by Designer software.
 - **Important:** For licensing, only use a permanent NIC on the computer. This setting can't be changed after installation.
5. Choose which PC optimizations to make. For the best audio performance, choose all options.
6. Click the IntelliMix Room icon in the system tray to access basic settings and a troubleshooting event log.

Next steps:

- Activate IntelliMix Room installations using Designer software (free at shure.com). IntelliMix Room installations will not pass audio until you activate your license.
- Control DSP, routing, and all other settings with Designer.

Installing with Mass Deployment Tools

You can deploy IntelliMix Room using standard software deployment tools. See below for available command line and silent install arguments.

Optional CLI Arguments

- **/S** : Silent mode. Installer runs without GUI and implements default options. If there is an existing version installed, the installer uses the existing settings unless parameters listed below are provided.
 - **/S /express**: Installer runs with only a progress bar UI and keeps all previous settings.
- **/nicindex=[integer]**: NIC index to use for both Shure control and Dante audio network capabilities.
 - **/nicindex_control=[integer]**: NIC index to use for Shure control network capabilities.
 - **/nicindex_audio=[integer]**: NIC index to use for Dante audio network capabilities.
- **/nicipaddress=[integer]**: NIC IP address to use for all IntelliMix Room network capabilities.
 - **/nicipaddress_control=[integer]**: NIC IP address to use for Shure control network capabilities.
 - **/nicipaddress_audio=[integer]**: NIC IP address to use for Dante audio network capabilities.
- **/nicid=[UUID]**: NIC UUID to use for all IntelliMix Room network capabilities.
 - **/nicid_control=[integer]**: NIC UUID to use for Shure control network capabilities.

- `/nicid_audio=[integer]`: NIC UUID to use for Dante audio network capabilities.
- `/licindex=[integer]`: NIC index to use for licensing identification. Also used to get MAC address.
- `/licipaddress=[IP ADDRESS]`: NIC IP address to use for licensing identification. Also used to get MAC address.
- `/licid=[UUID]`: NIC UUID to use for licensing identification. Also used to get MAC address.
- `/licmac=[mac address]`: NIC MAC address (without -) to use for licensing identification.

Installation and IntelliMix Room Settings

- `/norestart`: Do not reboot the system after installation. Default behavior of the software is to reboot, and rebooting is required to implement certain Windows optimizations.
- `/analyticsoptout=[true|false]`: Opt out of analytics data collection.

Windows Optimizations

- `/skipoptimizations`: Skip all optimizations.
- `/disablecortana=[true|false]`
- `/disablepushnotifications=[true|false]`
- `/optimizepowerplan=[true|false]`
- `/neversleep=[true|false]`
- `/disablenetworkthrottling=[true|false]`

Installer Default Settings

Option	Default Value	Notes
NIC index	0	The 0th found NIC using the lookup <code>GetEnabledNetworkAdaptersIds</code>
Analytics opt out	False	Users have data collection enabled by default.
Disable Cortana	True	
Disable push notifications	True	
Optimize power plan	True	
Never sleep	True	
Disable network throttling	True	

IntelliMix Room Firewall Changes

During installation, the software modifies your firewall to allow access for all Shure .exes. These changes are required to run the software.

- Shure_IntelliMix_Room.exe
- Shure PTP.exe
- Shure mDNSResponder.exe
- common_server.exe
- apec3.exe

Basics of Shure Designer Software

To use IntelliMix Room, you need Shure Designer software installed on a computer with a network connection to all IntelliMix Room installations.

Designer has some basic concepts that are important to understand as you start using IntelliMix Room:

Projects

- Use to manage groups of locations.
- Each project uses 1 license ID. All IntelliMix Room installations in a project use the same license ID.
If you're managing multiple customers with multiple license IDs, create separate projects to manage them.

Locations

- Use to organize groups of devices installed in the same physical location, such as a room, an area, or a building floor.
- If devices are in the same Designer location, you can route audio between them using the Routing tab.

Optimize

- After placing your devices in the same location, select Optimize to have Designer automatically adjust device settings and create audio routes for you.
- You can customize settings further, but the Optimize workflow gives you a good starting point.

Virtual Devices

- Use to design coverage without being on the same network as the physical devices.
- Push settings from virtual devices to physical devices once connected at the job site.

Online Devices

- Shows every available device on your network.

Live Mode

- Location-level setting that lets you control devices in real time.
- Use to push settings to online devices or pull settings from online devices.

Sync

- Use in Live mode to match the settings between virtual devices and online devices.
Push settings from virtual devices to online devices.
Pull settings from online devices to virtual devices.

Discovering IntelliMix Room in Designer

Each installation of IntelliMix Room appears as a separate device in Designer. Each installation's name matches the computer's network name.

To find any online installations:

- Go to Online devices.
- Use the checkboxes to select IntelliMix Room installations and add them to locations.

If you can't find some installations:

1. Go to the computer that won't appear in Designer.
2. Click the IntelliMix Room icon in the system tray.
3. Make sure IntelliMix Room is using the same Shure control NIC (network interface card) as Designer.

Note: IntelliMix Room doesn't show up in Shure Update Utility or Shure Web Device Discovery.

Uninstalling IntelliMix Room

Before uninstalling, make sure you have admin rights and an internet connection for all devices.

1. In Designer, find the devices that you plan to uninstall IntelliMix Room software from.
2. Select the devices, and choose Deactivate. After deactivation, the licenses are available to be used again.

Devices must have an internet connection to release their licenses.

3. On each device, uninstall IntelliMix Room like any other software.

Updating IntelliMix Room

Version 2.x and newer: When a new version of IntelliMix Room is available, you'll receive an email about the release. To update, open the IntelliMix Room installation that is being updated from the Windows system tray and go to **Version > Check for updates**.

Updating from Version 1.x to 2.x: Download the 2.x version from shure.com and run the installer over the 1.x version. The 2.x version replaces the 1.x version.

Note: Updating from version 1.x to version 3.x and above does not work. Update sequentially from 1.x to 2.x, and then use the 2.x and newer update process.


Activating IntelliMix Room

To activate the software, you need:


- A license for each installation
 - Licenses are based on the channel count (8 or 16 channels) for each installation of the software.
- Your license ID
 - A license ID activates all licenses in your account.
 - Find in your purchase confirmation email, or in your account at software.shure.com.
- Internet connection for all devices running IntelliMix Room

IntelliMix Room must be installed on a device before you can activate that license.

1. In Designer, go to Online devices. Check that you can discover all installations.
 - Each installation appears as a separate device. The device name matches the PC's name.
 - If you don't see all installations, check the Shure control NIC settings on the computer running IntelliMix Room. Use the same network as Designer.
2. Create a new project in Designer.
 - If you have many license IDs to manage, create a separate project for each license ID.
3. Go to the project's Licenses page. From the list of available installations, select one to move into the project. Click **Move into project**.
 - If you add multiple installations to a project at the same time, choose installations that all use the same license type. For example, move all 8-channel licenses into the project first, and then repeat the process for your 16-channel licenses.



4. Click Activate. Choose the license type for the installation and click Next.
5. Add your license ID and click Activate. This license ID is used for all installations in the project. If the device running IntelliMix Room has an internet connection, the installation activates and is ready to use.



Next steps:

- Create locations and add IntelliMix Room installations to them.
- Route audio to IntelliMix Room to apply DSP.

How IntelliMix Room Licenses Work

After installing IntelliMix Room on all devices, use Shure Designer software to activate your licenses. Designer is usually installed on a separate computer since it manages all installations of IntelliMix Room.

There are a couple terms to know as you manage licenses for IntelliMix Room:

- **Installation:** A single instance of IntelliMix Room software installed on a device.
- **License:** Each installation of v needs one to run. Choose between an 8- or a 16-channel license.
- **Project:** A grouping in Designer that has a collection of locations with devices. Each project uses 1 license ID. If you have multiple license IDs to manage, create separate projects for each one.
- **License ID:** A 12-digit code used to activate all of your purchased installations in Designer. When you purchase a group of licenses from Shure, you'll receive this code in the purchase email (it's also available in your account at software.shure.com). Each customer has 1 license ID.


Project: Main Hall Building

License ID: 1JK9374HYT7U

Licenses:

- Six 16-channel
- Two 8-channel

Locations:



Here's an example workflow for the whole process:

1. Decide how many 8-channel and how many 16-channel licenses you need. Purchase them from Shure.
2. Install IntelliMix Room on all devices.
3. Install Designer on a computer connected to the same network and discover all of your installations.
4. Create a project in Designer. Move all 8-channel installations into that project at the same time, and then repeat for 16-channel installations. You choose which type of license to use for the installations during this step.
5. Click Activate and add your license ID. All installations with an internet connection should activate quickly.

Renewing a License

To renew your IntelliMix Room licenses, [contact your Shure sales representative](#).

After you renew your licenses, your license ID stays the same. You won't need to make any changes to any existing room setups. All installations will continue running normally.

What Happens When My License Expires?

IntelliMix Room stops passing audio when your license expires.

You will receive email reminders to renew your license 90 days before it expires.

Moving or Reassigning Licenses

After purchasing, you might need to install IntelliMix Room on a different device than it was originally installed on. Make sure all devices have an internet connection before attempting to reassign a license.

To reassign a license to a new device:

1. In your project, go to Licenses. This page shows all IntelliMix Room installations in the project.
2. Select the license that you want to move to a different device.
3. Click Deactivate. Devices must have an internet connection to release their licenses.
4. Install IntelliMix Room on the new device.
5. In Designer, find the new installation of IntelliMix Room. Add it to the same project as the old installation.

- When prompted, choose the channel count that matches the old installation. Your license is now reassigned to the new device.

Deactivating Licenses

Deactivating the license for an IntelliMix Room installation causes that installation to stop passing audio. Make sure the device has an internet connection before deactivating.

After deactivation, the license is available to be used again on another installation of IntelliMix Room.

To deactivate licenses:

- In your project, go to Licenses. This page shows all IntelliMix Room installations in the project.
- Select the installations you want to deactivate.
- Click Deactivate. Devices must have an internet connection to release their licenses.
- Deactivated licenses are now available to be assigned to other installations.

License Server Details

To see information about available licenses and your account, sign in at software.shure.com. Use the username and password you set up during purchase.

IntelliMix Room initially requires an internet connection to activate your license, but it doesn't require one after activation.

When you receive an IntelliMix Room license from Shure, some of your information is collected and stored.


The information stored includes the following:

- User ID
- First name
- Last name
- Email address
- Contact information (phone number, fax number)

This information is stored in data centers that are in Santa Clara, CA and Elk Grove Village, IL.

Using Videoconferencing Software with IntelliMix Room

To connect IntelliMix Room to videoconferencing software, select **IntelliMix Room Echo Cancelling Speakerphone** as the speaker and the microphone in your videoconferencing software. Do the same thing in the computer's sound settings.



The microphone setting sends signals to the videoconferencing software from any microphone connected to IntelliMix Room.

The speaker setting sends a far-end signal from the videoconferencing software to IntelliMix Room. This is how IntelliMix Room gets an AEC reference and a signal for local sound reinforcement.


If you choose a different source as the speaker, you won't be able to get far-end audio from the videoconferencing software into IntelliMix Room to use as an AEC reference.

Routing Microphone Signals to the DSP

To route your microphone's signal to IntelliMix Room for processing, use Designer.

This example reflects a small conference room with:


1. MXA310 using 4 channels
2. Computer with 8-channel IntelliMix Room and videoconferencing software installed
3. Display and camera



To route signals to the DSP:

1. Create a location in Designer. Add the MXA310 and IntelliMix Room installation to the location from the Online devices list.
 - Both devices must be in the same location to route audio between them.
2. Open the location and go to Routing. This page lets you create Dante audio routes and link Shure networked mute buttons to devices.
3. Click Optimize. The Optimize workflow automatically routes audio signals, applies DSP settings, turns on mute synchronization, and enables LED logic control for connected devices.

You can also manually route audio and apply DSP settings outside of the Optimize workflow if you prefer.



4. Check the audio routes and settings to make sure they fit your needs. You might need to:
 - Delete unnecessary routes.
 - Check levels and adjust gain.
 - Verify that AEC reference signals are correctly routed.
 - Fine-tune DSP blocks as needed.
5. Open IntelliMix Room's device configuration window. From here, you can adjust DSP settings and route the signal to other sources. Check that your mic inputs are using the AEC reference you want to use.
6. To send your signal to other sources, go to Matrix mixer.
 - To send the automix signal to videoconferencing software, route to the virtual audio output.
 - To send the automix signal to other Dante sources, route to the appropriate Dante output. Use Dante Controller to route IntelliMix Room Dante outputs to non-Shure devices.


Note: If you're using a non-Shure Dante microphone, use Dante Controller to route the near-end signal to IntelliMix Room.

Routing Far-End Audio to IntelliMix Room


To use acoustic echo cancellation (AEC), you need to route a far-end signal to the software. The AEC uses that far-end signal as a reference and blocks it from being sent back to the far end as echo.

Each input channel can use a different AEC reference source. If all channels use the same source, select the AEC reference source on each input channel.

1. In your conferencing software's settings, select **IntelliMix Room Echo Cancelling Speakerphone** as the playback device. This sends the far-end signal to IntelliMix Room's virtual audio input.



2. Open IntelliMix Room's configuration window in Designer.
3. On each microphone input channel, select AEC. Choose the far-end reference source from the menu.
 - For best results, use the signal that feeds your local reinforcement system as the reference source.



Sending Far-End Audio to Loudspeakers and Other Sources

1. Go to Matrix mixer.
2. Find the far-end signal, which comes to the software through the Virtual Audio Input.
3. Check the box where the Virtual Audio Input and the destination intersect. You can also adjust crosspoint gain here.



Common destinations include:

- **PC audio output (3.5 mm or HDMI connector):** Go to Schematic view and click PC Output. Choose an output from the menu. Display speakers connected by HDMI cable or the 3.5 mm connector are common options.
- **Dante output destinations (loudspeakers or Shure ANI, for example)**



Use Cases

Overview of Shure Conferencing Devices


Shure offers a range of connectivity options for conferencing. MXA microphones, audio processors, and network interfaces all use Dante to send audio over standard IT networks. You can use Shure's free [Designer software](#) to control most Shure devices and route audio between them.

Device	Purpose	Physical Connections	Dante I/Os
 MXA910	Ceiling array microphone with IntelliMix DSP	1 PoE port	8 individual channel outputs or 1 automix channel output with IntelliMix DSP 1 AEC reference input
 MXA710	Linear array microphone with IntelliMix DSP	1 PoE port	2 Foot: 4 individual channel outputs or 1 automix channel output with IntelliMix DSP 1 AEC reference input

Device	Purpose	Physical Connections	Dante I/Os
			4 Foot: 8 individual channel outputs or 1 automix channel output with IntelliMix DSP 1 AEC reference input
 MXA310	Table array microphone	1 PoE port	4 individual channel outputs or 1 automix channel output
 P300	Audio processor with IntelliMix DSP and matrix mixer	1 USB in/out 2 analog block in 2 analog block out 1 mobile TRRS port (3.5 mm) 1 PoE+ port	8 Dante inputs with IntelliMix DSP 2 auxiliary Dante inputs 8 Dante outputs
 IntelliMix Room	Audio processing software with IntelliMix DSP and matrix mixer	Varies depending on device	8 or 16 Dante inputs with IntelliMix DSP 8 auxiliary Dante inputs 8 Dante outputs 1 virtual audio input and output 1 PC input and output
 ANIUSB-MATRIX	Matrix mixer with USB and analog input/output	1 USB in/out 1 analog block in 1 analog block out 1 PoE port	4 Dante inputs 2 Dante outputs
 ANI4IN (block or XLR connectors)	Converts analog signals to Dante signals	4 analog in 1 PoE port	4 Dante inputs
 ANI4OUT (block or XLR connectors)	Converts Dante signals to analog signals	4 analog out 1 PoE port	4 Dante outputs
 ANI22 (block or XLR connectors)	Converts 2 analog signals to Dante signals Converts 2 Dante signals to analog signals	2 analog in 2 analog out 1 PoE port	2 Dante inputs 2 Dante outputs

Device	Purpose	Physical Connections	Dante I/Os
 MXN5-C	Networked ceiling loud-speaker powered by PoE	1 PoE port	2 Dante inputs 1 Dante output
 MXA Network Mute Button	PoE-powered network mute button for Shure devices	1 PoE port 1 power cable connector for base	n/a

Use Case: IntelliMix Room, 2 MXA310s, and Display with Built-In Speakers



- IntelliMix Room provides DSP and sends signals from the MXA310s to the videoconferencing software.
- Far-end signal comes in to IntelliMix Room's Virtual Audio Input.
- Connect the computer to the display to use the display's built-in speakers for sound reinforcement.

Setup Process


1. Connect all devices, discover them in Designer, and place them in the same Designer location.
2. In Designer, go to [Your location] > Routing.
3. Click Optimize. This button automatically routes audio signals, applies DSP settings, turns on mute synchronization, and enables LED logic control for connected devices. You can customize the settings later if necessary, but Optimize gives you a good starting point.
4. Check that the Virtual Audio Input is set as the AEC reference signal. Delete any unnecessary audio routes.
5. Using the matrix mixer, route the far-end signal (the Virtual Audio Input) to the PC output. Click PC Output in the Schematic tab to choose the connected display.

If far-end participants hear echo artifacts, the display may be introducing latency. See Troubleshooting for help.

Equipment List:

- 2 MXA310s
- Computer in room with videoconferencing software and IntelliMix Room
- Display with built-in speakers
- Network switch supplying Power over Ethernet (PoE)
- Computer on network with Shure Designer software
- Cat5e (or better) Ethernet cables
- HDMI cable to connect computer to display
- Any other cameras or cables

Use Case: IntelliMix Room, 2 MXA910s, and Loudspeakers



- IntelliMix Room provides DSP and sends signals from the MXA910s to the videoconferencing software.
- Far-end signal comes in to IntelliMix Room's Virtual Audio Input
- Use Dante or analog loudspeakers for sound reinforcement. If you're using analog speakers, use an ANI22 or ANI4OUT to bring the far-end signal off the network to the loudspeakers.

Setup Process

1. Connect all devices, discover them in Designer, and place them in the same Designer location.
2. In Designer, go to [Your location] > Routing.
3. Click Optimize. This button automatically routes audio signals, applies DSP settings, turns on mute synchronization, and enables LED logic control for connected devices. You can customize the settings later if necessary, but Optimize gives you a good starting point.
4. Check that the Virtual Audio Input is set as the AEC reference signal. Delete any unnecessary audio routes.
5. Using the matrix mixer, route the far-end signal (the Virtual Audio Input) to a Dante output.
6. Open Dante Controller software to route the signal from IntelliMix Room's Dante output to the loudspeaker.

Dante Loudspeakers: Route the signal to the loudspeaker(s) in Dante Controller.

Analog Loudspeakers: Connect the loudspeakers to an ANI22 or ANI4OUT, and route the signal to the ANI in Dante Controller.

Equipment List:

- 2 MXA910s
- Computer in room with IntelliMix Room and videoconferencing software
- Dante or analog loudspeakers
- ANI22 or ANI4OUT for analog loudspeaker systems
- Network switch supplying Power over Ethernet (PoE)

- Computer on network with Shure Designer software
- Cat5e (or better) Ethernet cables
- Any other cameras, cables, or displays

Applying DSP Blocks

To apply DSP blocks:

1. Open a location that contains an IntelliMix Room installation.
2. Select the installation and click Configure.
3. In Schematic view, click a DSP block to open the settings window. You can also access DSP blocks from the Inputs and Outputs tabs.

DSP blocks also get applied during Designer's Optimize workflow.

Using Designer's Optimize Workflow

Designer's Optimize workflow speeds up the process of connecting systems with at least 1 microphone and 1 audio processor. Optimize also creates mute control routes in locations with MXA network mute buttons. When you select Optimize in a location, Designer does the following:

- Creates audio routes and mute control routes
- Adjusts audio settings
- Turns on mute synchronization
- Enables LED logic control for applicable devices

The settings are optimized for your particular combination of devices. You can customize settings further, but the Optimize workflow gives you a good starting point.

After optimizing a location, you should check and adjust settings to fit your needs. These steps may include:

- Deleting unnecessary routes.
- Checking levels and adjusting gain.
- Verifying that AEC reference signals are correctly routed.
- Fine-tuning DSP blocks as needed.

Compatible devices:

- MXA910
- MXA710
- MXA310
- P300
- IntelliMix Room
- ANIUSB-MATRIX
- MXN5-C
- MXA Network Mute Button

To use the Optimize workflow:

1. Place all relevant devices in a location.
2. Select Optimize. Designer optimizes microphone and DSP settings for your equipment combination.

If you remove or add devices, select Optimize again.

Schematic View

The schematic view in Designer provides an overview of the entire audio signal chain, with the ability to adjust settings and monitor signals.

Adjusting Settings

Right-click an input, output, or processing block to access the following options:

Per Channel

Copy / paste

Copy and paste settings between items. For example, set the equalizer curve on the USB output, and then use the same setting for the analog output. Or, copy the gain and mute status from one input channel to several others.

Mute / unmute

Mutes or activates the channel

Enable / disable

Turns processing on or off (does not apply to matrix mixer or automixer)

Edit

Opens the dialog to adjust parameters

Global (right-click in blank area)

Mute all inputs

Mutes all input channels

Mute all outputs

Mutes all output channels

Unmute all inputs

Unmutes all input channels

Unmute all outputs

Unmutes all output channels

Close all dialogs

Clears all open dialogs from the workspace

Customizing the Workspace

Create a custom environment to monitor and control a set of inputs, outputs, and processing blocks from a single screen. There are two ways to break out dialogs:

- Right click > edit
- Double-click the input, output, or processing block.

Open as many dialogs as you need to keep important controls available.

Metering and Audio Routing

A meter appears underneath each input and output to indicate signal levels (dBFS).

The lines connecting inputs and outputs to the matrix mixer appear colored when connections are established. When a signal is not routed, the line appears gray. Use these tools to troubleshoot audio signals and verify connections and levels.

Parametric Equalizer

Maximize audio quality by adjusting the frequency response with the parametric equalizer.


Common equalizer applications:

- Improve speech intelligibility
- Reduce noise from HVAC systems or video projectors
- Reduce room irregularities
- Adjust frequency response for reinforcement systems

Setting Filter Parameters

Adjust filter settings by manipulating the icons in the frequency response graph, or by entering numeric values. Disable a filter using the check-box next to the filter.

Filter Type	Only the first and last band have selectable filter types. Parametric: Attenuates or boosts the signal within a customizable frequency range Low Cut: Rolls off the audio signal below the selected frequency Low Shelf: Attenuates or boosts the audio signal below the selected frequency High Cut: Rolls off the audio signal above the selected frequency High Shelf: Attenuates or boosts the audio signal above the selected frequency
Frequency	Select the center frequency of the filter to cut/boost
Gain	Adjusts the level for a specific filter (+/- 30 dB)
Q	Adjusts the range of frequencies affected by the filter. As this value increases, the bandwidth becomes thinner.
Width	Adjusts the range of frequencies affected by the filter. The value is represented in octaves. Note: the Q and width parameters affect the equalization curve in the same way. The only difference is the way the values are represented.



Copy, Paste, Import, and Export Equalizer Channel Settings

These features make it simple to use effective equalizer settings from a previous installation, or simply accelerate configuration time.

Copy and Paste

Use to quickly apply the same PEQ setting across multiple channels.

1. Select the channel from the pull-down menu in the PEQ screen.
2. Select Copy
3. In the pull-down menu, select the channel to apply the PEQ setting and select Paste.

Import and Export

Use to save and load PEQ settings from a file on a computer. This is useful for creating a library of reusable configuration files on computers used for system installation.

Export	Choose a channel to save the PEQ setting, and select Export to file.
Import	Choose a channel to load the PEQ setting, and select Import from file.

Equalizer Applications

Conferencing room acoustics vary based on room size, shape, and construction materials. Use the guidelines in following table.

EQ Application	Suggested Settings
Treble boost for improved speech intelligibility	Add a high shelf filter to boost frequencies greater than 1 kHz by 3-6 dB
HVAC noise reduction	Add a low cut filter to attenuate frequencies below 200 Hz
Reduce flutter echoes and sibilance	<p>Identify the specific frequency range that "excites" the room:</p> <ol style="list-style-type: none"> 1. Set a narrow Q value 2. Increase the gain to between +10 and +15 dB, and then experiment with frequencies between 1 kHz and 6 kHz to pinpoint the range of flutter echoes or sibilance 3. Reduce the gain at the identified frequency (start between -3 and -6 dB) to minimize the unwanted room sound
Reduce hollow, resonant room sound	<p>Identify the specific frequency range that "excites" the room:</p> <ol style="list-style-type: none"> 1. Set a narrow Q value 2. Increase the gain to between +10 and +15 dB, and then experiment with frequencies between 300 Hz and 900 Hz to pinpoint the resonant frequency 3. Reduce the gain at the identified frequency (start between -3 and -6 dB) to minimize the unwanted room sound

EQ Contours for IntelliMix Room

Use the built-in equalizer contours to quickly apply EQ changes to any of the Dante input channels. Applying both EQ contours and other channel EQ filters has a cumulative effect, meaning that the EQ changes stack on top of each other.

Listen to and test your system as you make EQ changes.

Off: Turns off any active EQ contours

MXA910 High Pass: 300 Hz low-cut filter

MXA910 Low Shelf: 960 Hz, -10 dB low-shelf filter

MXA910 Multi-Band: 200 Hz low-cut filter, parametric 450 Hz, -10 dB, 2.87 Q, ½ octave parametric, 900 Hz, -10 dB, 2.87 Q, ½ octave parametric

MXA310 Low Cut: 180 Hz low-cut filter

MXA710 Low Shelf: 300 Hz, -6 dB low-shelf filter

Acoustic Echo Cancellation

In audio conferencing, a far-end talker may hear their voice echo as a result of a near-end microphone capturing audio from loudspeakers. Acoustic echo cancellation (AEC) is a DSP algorithm which identifies the far-end signal and stops it from being captured by the microphone to deliver clear, uninterrupted speech. During a conference call, the AEC works constantly to optimize processing as long as far-end audio is present.

When possible, optimize the acoustic environment using the following tips:

- Reduce speaker volume
- Position speakers farther from microphones
- Avoid pointing speakers directly at microphone coverage areas

Selecting a Reference Signal for AEC

To apply AEC, provide a far end reference signal. For best results, use the signal that also feeds your local reinforcement system.

P300: Go to Schematic and click any AEC block. Choose the reference source, and the reference source changes for all AEC blocks.

MXA910: Route a far-end signal to the AEC Reference In channel.

IntelliMix Room: Go to Schematic and click an AEC block. Choose the reference source. Each block can use a different reference source, so set the reference for each AEC block.

Designer's Optimize workflow automatically routes an AEC reference source, but it's a good idea to check that Designer chooses the reference source you want to use.

AEC Settings

Reference Meter

Use the reference meter to visually verify the reference signal is present. The reference signal should not be clipping.

ERLE

Echo return loss enhancement (ERLE) displays the dB level of signal reduction (the amount of echo being removed). If the reference source is connected properly, the ERLE meter activity generally corresponds to the reference meter.

Reference

Indicates which channel is serving as the far end reference signal.

Non-Linear Processing

The primary component of the acoustic echo canceller is an adaptive filter. Non-linear processing supplements the adaptive filter to remove any residual echo caused by acoustic irregularities or changes in the environment. Use the lowest possible setting that is effective in your room.

Low: Use in rooms with controlled acoustics and minimal echoes. This setting provides the most natural sound for full duplex.

Medium: Use in typical rooms as a starting point. If you hear echo artifacts, try using the high setting.

High: Use to provide the strongest echo reduction in rooms with bad acoustics, or in situations where the echo path frequently changes.

Noise Reduction

Noise reduction significantly reduces the amount of noise in the signal caused by projectors, HVAC systems, or other environmental noise. It is a dynamic processor, which calculates the noise floor in the room and removes noise throughout the entire spectrum with maximum transparency.

Settings

The noise reduction setting (low, medium, or high) represents the amount of reduction in dB. Use the lowest possible setting that effectively lowers noise in the room.

Compressor

Use the compressor to control the dynamic range of the selected signal.

Threshold

When the audio signal exceeds the threshold value, the level is attenuated to prevent unwanted spikes in the output signal. The amount of attenuation is determined by the ratio value. Perform a soundcheck and set the threshold 3-6 dB above average talker levels, so the compressor only attenuates unexpected loud sounds.

Ratio

The ratio controls how much the signal is attenuated when it exceeds the threshold value. Higher ratios provide stronger attenuation. A lower ratio of 2:1 means that for every 2 dB the signal exceeds the threshold, the output signal will only exceed the threshold by 1 dB. A higher ratio of 10:1 means a loud sound that exceeds the threshold by 10 dB will only exceed the threshold by 1 dB, effectively reducing the signal by 9 dB.

Delay

Use delay to synchronize audio and video. When a video system introduces latency (where you hear someone speak, and their mouth moves later), add delay to align audio and video.

Delay is measured in milliseconds. If there is a significant difference between audio and video, start by using larger intervals of delay time (500-1000 ms). When the audio and video are slightly out of sync, use smaller intervals to fine-tune.

Automatic Gain Control (AGC)

Automatic gain control adjusts channel levels to ensure consistent volume for all talkers, in all scenarios. For quieter voices, it increases gain; for louder voices, it attenuates the signal.

Automatic gain control is post-fader, and adjusts the channel level after the input level has been adjusted. Enable it on channels where the distance between the talker and the microphone may vary, or in rooms where many different people will use the conferencing system.

Target Level (dBFS)

Represents the level that you want the gain to reach. This level is different from adjusting the input fader according to peak levels to avoid clipping. Suggested starting points:

- P300: -32 dBFS
- MXA910: -37 dBFS
- IntelliMix Room: -32 dBFS

Maximum Boost (dB)

Sets the maximum amount of gain that can be applied

Maximum Cut (dB)

Sets the maximum attenuation that can be applied

Tip: Use the boost/cut meter to monitor the amount of gain added or subtracted from the signal. If this meter is always reaching the maximum boost or cut level, adjust the input fader so the signal is closer to the target level.

Using Call Status

Designer's Call status feature uses microphone LEDs to show if you're in a videoconferencing call or not. This is a location-level feature, so it applies to all microphones in a Designer location.

To use:

1. Put all microphones and processors (ANIUSB-MATRIX, IntelliMix Room, or P300) in the same Designer location.
2. Route microphone signals to the processor manually or with Designer's Optimize workflow.
3. Go to [Your location] > Settings > Call status to enable or disable Call status.

When Call status is enabled:

- Microphone LEDs off = Not in a call
- Microphone LEDs on = In a call

Call status is compatible with the following codecs:

- Microsoft Teams
- Microsoft Teams Rooms
- Zoom Client for Meetings
- Zoom Rooms

Note: If your codec is running on a computer with a Chrome operating system, call status will not work.

Mute Synchronization

Mute synchronization ensures that all connected devices in a conferencing system mute or unmute at the same time and at the correct point in the signal path. Mute status is synchronized in the devices using logic signals or USB connections.


To use mute synchronization, enable logic on connected devices using the web application or Shure Designer software. Many Shure devices have logic enabled automatically.

If you use Designer's Optimize workflow, Designer configures all of the necessary mute synchronization settings for you.

Shure logic devices:

- P300 (Also mutes [supported soft codecs](#) connected by USB)
- ANIUSB-MATRIX (Also mutes [supported soft codecs](#) connected by USB)
- IntelliMix Room software
- MXA910
- MXA710
- MXA310
- Network Mute Button
- ANI22-BLOCK
- ANI4IN-BLOCK
- Logic-enabled MX microphones connected to ANI22-BLOCK or ANI4IN-BLOCK
 - MX392
 - MX395-LED
 - MX396
 - MX405/410/415

Mute and Fader Groups

You can link channels to each other to create groups for muting and fader controls. You link channels by clicking  for the channels and the controls that you want linked. For example, if channels 1, 2, and 3 are linked for Mute, muting any of those individual channels mutes all of the linked channels.

Adjusting Input levels

The Inputs tab controls a channel's gain before it reaches the matrix mixer. However, you should also adjust the source's gain before it reaches IntelliMix Room.

To monitor a source's input level before IntelliMix Room processing: Set metering to **Pre-gain** in the Settings menu.

1. Check the source level before it reaches IntelliMix Room. Verify that the networked microphones or other Dante sources are operating at nominal output levels.
2. Adjust gain in the Inputs tab.
 - This gain stage adjusts the signal level before it reaches the matrix mixer.
 - Mix the levels as high as possible so that the loudest channel does not reach the peak level (0 dB) on the meter.

Pre- and Post-Gain Metering

The 2 metering modes allow you to monitor signal levels before and after the gain stages.

Input Metering

- **Pre-gain:** Displays the pre-fader signal level. If signals are too low or clipping, adjust them at the source.
- **Post-gain:** Displays the post-fader signal level, so the meters reflect gain adjustments on input faders. This meter does not include automatic gain control or any other processing.

Output Metering

- **Pre-gain:** Displays signal levels after input gain has been applied, but before the output faders. This meter includes input faders, digital signal processing blocks, automixing, and crosspoint gain.
- **Post-gain:** Displays the post-fader signal level sent to each output. This meter includes gain adjustments made on the output faders.

When to Use the Input and Automixer Gain Faders

There are 2 different gain faders that serve different purposes:

Input Gain (Pre-Gate)

To adjust, go to Inputs. These faders affect a channel's gain before it reaches the automixer and therefore affect the automixer's gating decision. Boosting the gain here will make the channel more sensitive to sound sources and more likely to gate on. Lowering gain here makes the channel less sensitive and less likely to gate on.

Automixer Gain (Post-Gate)

To adjust, go to Automixer. These faders adjust a channel's gain after automixer's gating decision. Adjusting the gain here will not affect the automixer's gating decision. Only use these faders to adjust the gain of a channel after you are satisfied with the automixer's gating behavior.

Matrix Mixer

The matrix mixer routes audio signals between inputs and outputs for simple and flexible routing:

- Send a single input channel to multiple outputs
- Send multiple input channels to a single output

Crosspoint Gain

Crosspoint gain adjusts the gain between a specific input and output, to create separate submixes without changing input or output fader settings. Select the dB value at any crosspoint to open the gain adjustment panel.

Gain staging: Input fader > crosspoint gain > output fader

Routing Channels

Connect inputs and outputs by selecting the box where they intersect.

Automix Modes

Gating

Gating mode delivers fast-acting, seamless channel gating and consistent perceived ambient sound levels. Off-attenuation in this mode is fixed at -20 dB per channel, regardless of the number of open channels.

Gain Sharing

Gain sharing mode dynamically balances system gain between open and closed channels. The system gain remains consistent by distributing gain across channels to equal one open channel. The scaled gain structure helps to reduce noise when there is a high channel count. When fewer channels are used, the lower off-attenuation provides transparent gating.

Manual

Manual mode sums all active tracks and sends the summed signal over a single Dante output. This provides the option to route an individual signal for reinforcement or recording, without enabling automixing. The settings from the faders in the standard monitoring view apply to the summed output.

Automix Settings

Note: Not all settings are available on all automixers.

Leave Last Mic On

Keeps the most recently used microphone channel active. The purpose of this feature is to keep natural room sound in the signal so that meeting participants on the far end know the audio signal has not been interrupted.

Gating Sensitivity

Changes the threshold of the level at which the gate is opened

Off Attenuation

Sets the level of signal reduction when a channel is not active

Hold Time

Sets the duration for which the channel remains open after the level drops below the gate threshold

Maximum Open Channels

Sets the maximum number of simultaneously active channels

Priority

When selected, this channel gate activates regardless of the number of maximum open channels.

Always On

When selected, this channel will always be active.

Send to Mix

When selected, sends the channel to the automix channel.

Solo

Mutes all of the other channels

Automix Gain Meter

When enabled, changes gain meters to display automix gating in real time. Channels that gate open will display more gain than channels that are closed (attenuated) in the mix.

Mic Optimization Mode (P300 only)

Select the microphone that is used with the automixer for best performance. For best results, use Designer's Optimize workflow (this automatically selects the correct mic optimization mode).

Use the Off setting when using a Shure Microflex[®] Wireless system, or traditional wired microphones.

Gate Inhibit (P300 only)

Enable gate inhibit to prevent far-end audio from gating on near-end microphone channels.

1. Make sure all input gain levels are properly adjusted and all other automixer settings are configured.
2. Disable Leave last mic on.
3. Perform a test call with the far end to adjust the gate inhibit fader. Increase the fader level so that the far end indicator turns on, and far-end audio does not gate on the near-end automixer channels.
4. Verify that near-end talkers still activate the automixer channels. If the channels do not turn on, lower the gate inhibit fader.
5. Re-enable Leave last mic on if necessary.

Automixer Direct Out Tap Points

In the Automixer tab, use the menus below each channel to choose where the signal to the matrix mixer should come from.

All options include input channel gain, mute, solo, and PEQ.

Pre-Processing/Pre-Gate

Sends a signal without AEC, noise reduction, or AGC to the matrix mixer.

Post-Processing/Pre-Gate

Sends a signal with AEC and noise reduction but without automixer gating or AGC to the matrix mixer.

Post-Processing/Post-Gate

Sends a signal with automixer gating, AEC, and noise reduction but without AGC to the matrix mixer.

Pre-Processing/Post-Gate

Sends a signal with automixer gating but without AEC, noise reduction, or AGC to the matrix mixer.


Note: Direct out tap points are not available on all Shure automixers.

Network Setup Examples

IntelliMix Room works with many different types of networks. Here are some of the most common network setups:


- **Flat Network**

- All A/V and corporate devices are on the same network.
- Use one network for Shure control and Dante audio data.




- **Corporate and AV Network**

- All A/V devices are on a separate network from the corporate network.
- The computer running IntelliMix Room uses the A/V network for Dante audio and Shure control data.
- The computer uses a wired connection to the corporate network for internet. USB 3.0 to gigabit Ethernet adapters are a common way to connect to 2 NICs.



- **Corporate and AV Network with Separate Internet Connections**

- IntelliMix Room and all other A/V devices are on a separate network that has its own internet connection, which is completely separate from the corporate network.
- Use the A/V network for both Dante audio and Shure control data.



Choosing Networks for Shure Control and Dante Audio

This software sends 2 types of data over the network: Shure control data and Dante audio data. You can use the same NIC (network interface card) for both, or use 2 different NICs to separate the traffic.

During installation, you will be asked to choose a network for each one.

Shure control NIC:

- Choose the network that Designer uses.
- Used for device discovery and control

Dante audio NIC:

- Choose the same network as other Dante devices to send audio between devices.
- Cannot use Wi-Fi
- Used to carry Dante digital audio

To change the NICs after installation, click the IntelliMix Room icon in the system tray of the computer running IntelliMix Room.

To change Designer's NIC, go to Settings.

Choosing a Licensing NIC

During installation, the software prompts you to choose a NIC (network interface card) to use for licensing identification. The NIC must be permanent and not removable. Do not use NICs that could be removed, such as a USB-to-Ethernet adapter or a docking station.

This setting cannot be changed after installation.

Security Testing

Shure IntelliMix Room underwent penetration testing by a reputable third-party security assessment company. The test results placed IntelliMix Room above the average of all applications tested. Going forward, Shure will continue to internally and externally test the security of IntelliMix Room. For more information on the test results, please contact productsecurity@shure.com.

IntelliMix Room IP Ports and Protocols

If there's a conflict with the default port, IntelliMix Room automatically selects a port from the specified range.

IntelliMix Room Version 3.0.4 and Newer

Pro- to- col	Port	Range	In- bound or out- bound?	Descrip- tion	Applicable .exe
UDP	n/a	319-320	Both	PTP clocking	C:\Program Files\Shure\IntelliMixRoom\da\exe\ptp.exe
UDP	n/a	34440 - 38000	Both	Audio routing	C:\Program Files\Shure\IntelliMixRoom\da\exe\ape3.exe
UDP	5353	n/a	Both	mDNS	C:\Program Files (x86)\Audinate\Shared Files\mDNSResponder.exe
UDP	n/a	38801 - 45000	Both	ConMon channels (unicast)	C:\Program Files\Shure\IntelliMixRoom\da\exe\common_server.exe

Pro- tocol	Port	Range	In- bound or out- bound?	Descrip- tion	Applicable .exe
UDP	n/a	8700 - 8708	Both	ConMon channels (multi-cast)	C:\Program Files\Shure\IntelliMixRoom\dal\exe\common_server.exe
UDP	n/a	34336 - 34439, 38001 - 38800	Both	Audio channels	C:\Program Files\Shure\IntelliMixRoom\Shure_IntelliMix_Room.exe
UDP	4321	n/a	Both	Audio (multi-cast)	C:\Program Files\Shure\IntelliMixRoom\Shure_IntelliMix_Room.exe
UDP	5568	n/a	Both	Session Data Transport (SDT), part of ACN	C:\Program Files\Shure\IntelliMixRoom\Shure_IntelliMix_Room.exe
UDP	n/a	49152-65535	Both	ACN dynamic ports	C:\Program Files\Shure\IntelliMixRoom\Shure_IntelliMix_Room.exe
UDP	8427	n/a	Both	Shure SLP (multi-cast)	C:\Program Files\Shure\IntelliMixRoom\Shure_IntelliMix_Room.exe
TCP	n/a	1025-65535	Inbound	Shure Command Strings	C:\Program Files\Shure\IntelliMixRoom\Shure_IntelliMix_Room.exe
TCP	443	n/a	Out-bound	HTTPS	C:\Program Files\Shure\IntelliMixRoom\SWUpdate\Shure.SoftwareUpdate.exe C:\Program Files\Shure\IntelliMixRoom\Shure_IntelliMix_Room.exe

Compatibility with Dante Domain Manager

This device is compatible with Dante Domain Manager software (DDM). DDM is network management software with user authentication, role-based security, and auditing features for Dante networks and Dante-enabled products.

Considerations for Shure devices controlled by DDM:

- When you add Shure devices to a Dante domain, set the local controller access to Read Write. Otherwise, you won't be able to access to Dante settings, perform a factory reset, or update device firmware.
- If the device and DDM can't communicate over the network for any reason, you won't be able to control Dante settings, perform a factory reset, or update device firmware. When the connection is reestablished, the device follows the policy set for it in the Dante domain.
- If Dante device lock is on, DDM is offline, or the configuration of the device is set to Prevent, some device settings are disabled. These include: Dante encryption, MXW association, AD4 Dante browse and Dante cue, and SCM820 linking.

See [Dante Domain Manager's documentation](#) for more information.

Note: IntelliMix Room is not compatible with Dante's device lock feature.

How to Recover IntelliMix Room from Inaccessible Dante Domains

If Dante Domain Manager isn't accessible, you can manually remove the IntelliMix Room installation from the domain. DDM can become inaccessible if an installation of IntelliMix Room gets moved from one network to another and it doesn't get removed from the Dante domain first.

To remove the installation from the domain:

1. Stop the IntelliMix Room service (Task manager > Services > Right-click IntelliMix Room > Stop).
2. Clear the contents in

C:\ProgramData\Shure\IntelliMixRoom\dalconfig

3. Restart the IntelliMix Room service. This clears the domain credentials and also resets other Dante settings.

Dante Flows for Shure Devices

Dante flows get created any time you route audio from one Dante device to another. One Dante flow can contain up to 4 audio channels. For example: sending all 5 available channels from an MXA310 to another device uses 2 Dante flows, because 1 flow can contain up to 4 channels.

Every Dante device has a specific number of transmit flows and receive flows. The number of flows is determined by Dante platform capabilities.

Unicast and multicast transmission settings also affect the number of Dante flows a device can send or receive. Using multicast transmission can help overcome unicast flow limitations.

Shure devices use different Dante platforms:

Dante Platform	Shure Devices Using Platform	Unicast Transmit Flow Limit	Unicast Receive Flow Limit
Brooklyn II	ULX-D, SCM820, MXWAPT, MXWANI, P300, MXCWAPT	32	32
Brooklyn II (without SRAM)	MXA910, MXA710, AD4	16	16
Ultimo/UltimoX	MXA310, ANI4IN, ANI4OUT, ANIUSB-MATRIX, ANI22, MXN5-C	2	2
DAL	IntelliMix Room	16	16

[Learn more about Dante flows in our FAQs](#) or from [Audinate](#).

Using Command Strings with IntelliMix Room

To control IntelliMix Room with third-party control systems, turn on command strings in Designer. You must choose an open port on the computer running IntelliMix Room to send and receive command strings.

Default port: 2202

Port range: 1025-65534

1. In Designer, open the installation of IntelliMix Room you want to control and go to **Settings > Command strings**.
2. Turn on command strings.
3. Enter an available port to send and receive the command strings. Make sure that the port isn't being used by any other programs installed on the computer.

To test if the port is available:

- Send a command to IntelliMix Room. Make sure you are targeting IntelliMix Room's control IP address.
- If you don't receive a response, the port is being used by another program.
- Try a different port number and send the command until you receive a response.
- For best results, install all software on the computer before choosing a port for command strings. Adding new software after setting up command strings can change how the computer's ports are used, which can affect command strings.

A complete list of command strings is available at pubs.shure.com/command-strings/IntelliMixRoom.

Troubleshooting

Problem	Solution
IntelliMix Room installations won't show up in Designer	<ol style="list-style-type: none"> 1. On the device running IntelliMix Room, click the system tray icon. Check that the installation is using the same Shure control network as Designer. 2. Check if other Shure devices appear in Designer. If they do, open the Windows Task Manager and go to Services. Restart IntelliMix Room. 3. Open Dante Controller. Check if the installation appears in Dante Controller. 4. If the installation appears in Dante Controller, check firewall settings. Make sure it's not blocking any Shure traffic. 5. Contact Shure support if it still doesn't appear in Designer.
Licenses won't activate in Designer	<ol style="list-style-type: none"> 1. Check that the device running IntelliMix Room has an internet connection. This is required for license activation.

Problem	Solution
	<ol style="list-style-type: none"> Go to your account at software.shure.com and check that you have enough licenses. If you don't have enough licenses or need a different channel count, purchase more from your Shure sales representative. Contact Shure support.
<p>Clicked IntelliMix Room icon in system tray, and the screen loads continuously</p>	<p>This means IntelliMix Room isn't running properly. Try the following solutions:</p> <ol style="list-style-type: none"> Open the Windows Task Manager and go to Services. Check if IntelliMix Room is running. If it's stopped, right-click to start the service. If it's running, right-click to stop the service and then restart it. Restart the computer and reopen from the system tray. Check if you can discover this IntelliMix Room installation in Designer or Dante Controller. If you can't discover the installation, uninstall it and then reinstall. Contact Shure support if it still doesn't run correctly.
<p>IntelliMix Room won't pass audio</p>	<ol style="list-style-type: none"> Open the installation in Designer and check that it's unmuted. Check if the installation has a license that isn't expired. If it has a valid license, check the audio signal chain for inputs that are muted or routed incorrectly. If it doesn't have a license, find your license ID and add it to the project. Make sure the device with IntelliMix Room has a working internet connection to activate the license. Find the license ID in your purchase email or in your account at software.shure.com. If you don't have enough licenses or need a different channel count, purchase more from your Shure sales representative. Check that the installation has the same channel count as what is available in your account for that license ID. For example, if your installation has 8 channels, but your license ID only has one 16-channel license available, you need to purchase an 8-channel license. On the device running IntelliMix Room, try to access software.shure.com. If you can't access it, try visiting another website. If you can, your firewall could be blocking traffic from

Problem	Solution
	<p>the cloud license server. Adjust settings to allow traffic from Shure.</p> <p>If you can access it, contact Shure support. The firewall is not interfering with the cloud license server.</p>
<p>Far end hears whispy echo sounds coming from room using IntelliMix Room</p>	<p>This is likely caused by latency introduced to the signal chain after the AEC reference signal. We have observed devices like soundbars or displays adding extra latency to the signal after it leaves IntelliMix Room. This difference between the AEC reference signal and what comes through the speakers causes problems for the echo canceler's training, and results in a whispy sound.</p> <p>To fix this problem, delay your AEC reference signal so that it's closer to the signal coming out of the speakers.</p> <ol style="list-style-type: none"> 1. Using the matrix mixer, route the far-end signal (virtual audio input) to an unused Dante output. 2. Set this Dante output as the AEC reference signal. 3. Add delay to the Dante output. Start with 50-100 ms, and listen for echo artifacts on the far end. To provoke the artifacts, a single talker on the far end should make sibilant sounds ("Psst" or "Shhh") and observe the echo coming back. 4. Continue to increase or decrease the delay until the echo artifacts disappear from the perspective of the far-end participant.

Event Logs

There are 2 different event logs to help with troubleshooting: the IntelliMix Room-level event log, and the Designer-level event log. Each one logs different types of events.

IntelliMix Room Event Log

To access, open IntelliMix Room from the system tray and select Event log.

IntelliMix Room's event log collects detailed information about the license status, CPU performance, audio performance, and other possible issues. If you need to contact Shure's support team, this event log provides the most detail about each installation.

Designer Event Log

To access, open Designer and select Event log.

Designer's event log collects high-level information about all devices and software controlled by Designer. This event log isn't as detailed as the device-specific event logs.

Event logs collect up to 1,000 entries. Select Export log to create a CSV (comma separated values) document to save and sort the log data.

Severity Level

Information

An action or event has been successfully completed.

Warning

An action cannot be completed, but overall functionality is stable.

Error

A problem has occurred that could inhibit functionality.

Log Details

Description

Provides details on events and errors, including IP address and subnet mask

Time Stamp

Time since most recent boot-up

Event ID

Indicates event type for internal reference

Reset

Restore factory defaults: Resets all application and license settings to the factory defaults. Network settings remain the same.

Specifications

Control Software

Shure Designer

Digital Signal Processing

Automatic

mixing, Matrix mixer, Acoustic Echo Cancellation (AEC), Noise Reduction, Automatic Gain Control, Compressor, Delay, Equalizer (4-band Parametric) , Mute, Gain (140 dB

range)

Frequency Response

Dante Digital Audio or Virtual Audio Device	20 to 20,000 Hz
---	-----------------

Sampling Rate

Dante Digital Audio or Virtual Audio Device	48 kHz
---	--------

Bit Depth

Dante Digital Audio	24 bit
---------------------	--------

Virtual Audio Device	24 bit
----------------------	--------

Latency

Not including Dante latency

Auxiliary Dante Inputs to Dante out	28 ms
Dante Mic Inputs to Dante out (AEC enabled)	34.7 ms
Dante Mic Inputs to Dante out (AEC and NR disabled)	28 ms

Acoustic Echo Cancellation Tail Length
Up to 300 ms

Contact Customer Support

Didn't find what you need? [Contact our customer support](#) to get help.