


**SPLIT-TYPE ROOM AIR CONDITIONER**

# Owner's Manual & Installation Manual

**OS-C\_SENIH09E**  
**OS-C\_SENIH12E**  
**OS-C\_SENIH18E**  
**OS-C\_SENIH24E**  
**OS-C\_SENIH30E**  
**OS-C\_SENIH36E**



**IMPORTANT NOTE:**

Read this manual carefully before installing or operating your new air conditioning unit. Make sure to save this manual for future reference.

Please check the applicable models, technical data, F-GAS(if any) and manufacturer information from the "Owner's Manual - Product Fiche " in the packaging of the outdoor unit.  
(European Union products only)

# Table of Contents

Safety Precautions .....03

## Owner’s Manual

Unit Features.....07

1. Indoor unit display.....07  
2. Operating temperature.....09  
3. Other features .....10  
4. Setting angle of airflow.....11  
5. Manual operation (without Remote).....11

Care and Maintenance.....12

Troubleshooting.....14

# Installation Manual

<b>Accessories.....</b>	<b>17</b>
<b>Installation Summary - Indoor Unit .....</b>	<b>18</b>
<b>Unit Parts.....</b>	<b>19</b>
<b>Indoor Unit Installation.....</b>	<b>20</b>
1. Select installation location.....	20
2. Attach mounting plate to wall.....	20
3. Drill wall hole for connective piping.....	21
4. Prepare refrigerant piping.....	22
5. Connect drain hose.....	22
6. Connect signal and power cables.....	23
7. Wrap piping and cables.....	24
8. Mount indoor unit .....	25
<b>Outdoor Unit Installation.....</b>	<b>26</b>
1. Select installation location.....	26
2. Install drain joint.....	27
3. Anchor outdoor unit.....	27
4. Connect signal and power cables.....	29
<b>Refrigerant Piping Connection.....</b>	<b>30</b>
A. Note on Pipe Length.....	30
B. Connection Instructions –Refrigerant Piping.....	30
1. Cut pipe.....	30
2. Remove burrs.....	31
3. Flare pipe ends.....	31
4. Connect pipes.....	31
<b>Air Evacuation.....</b>	<b>33</b>
1. Evacuation Instructions.....	33
2. Note on Adding Refrigerant.....	34
<b>Electrical and Gas Leak Checks.....</b>	<b>35</b>
<b>Test Run.....</b>	<b>36</b>
<b>Model Specifications.....</b>	<b>37- 42</b>
<b>Startup and Troubleshooting Data Sheet.....</b>	<b>43</b>

# Safety Precautions

## Read Safety Precautions Before Operation and Installation

**Incorrect installation due to ignoring instructions can cause serious damage or injury.** The seriousness of potential damage or injuries is classified as either a **WARNING** or **CAUTION**.



### WARNING

This symbol indicates the possibility of personnel injury or loss of life.



### CAUTION

This symbol indicates the possibility of property damage or serious consequences.



### WARNING

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision (European Union countries).

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.



### WARNINGS FOR PRODUCT USE

- If an abnormal situation arises (like a burning smell), immediately turn off the unit and disconnect the power. Call your dealer for instructions to avoid electric shock, fire or injury.
- **Do not** insert fingers, rods or other objects into the air inlet or outlet. This may cause injury, since the fan may be rotating at high speeds.
- **Do not** use flammable sprays such as hair spray, lacquer or paint near the unit. This may cause fire or combustion.
- **Do not** operate the air conditioner in places near or around combustible gases. Emitted gas may collect around the unit and cause explosion.
- **Do not** operate your air conditioner in a wet room such as a bathroom or laundry room. Too much exposure to water can cause electrical components to short circuit.
- **Do not** expose your body directly to cool air for a prolonged period of time.
- **Do not** allow children to play with the air conditioner. Children must be supervised around the unit at all times.
- If the air conditioner is used together with burners or other heating devices, thoroughly ventilate the room to avoid oxygen deficiency.
- In certain functional environments, such as kitchens, server rooms, etc., the use of specially designed air-conditioning units is highly recommended.



## CLEANING AND MAINTENANCE WARNINGS

- Turn off the device and disconnect the power before cleaning. Failure to do so can cause electrical shock.
- **Do not** clean the air conditioner with excessive amounts of water.
- **Do not** clean the air conditioner with combustible cleaning agents. Combustible cleaning agents can cause fire or deformation.



### CAUTION

- Turn off the air conditioner and disconnect the power if you are not going to use it for a long time.
- Turn off and unplug the unit during storms.
- Make sure that water condensation can drain unhindered from the unit.
- **Do not** operate the air conditioner with wet hands. This may cause electric shock.
- **Do not** use device for any other purpose than its intended use.
- **Do not** climb onto or place objects on top of the outdoor unit.
- **Do not** allow the air conditioner to operate for long periods of time with doors or windows open, or if the humidity is very high.



### ELECTRICAL WARNINGS

- Only use the specified power cord. If the power cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Keep power plug clean. Remove any dust or grime that accumulates on or around the plug. Dirty plugs can cause fire or electric shock.
- **Do not** pull power cord to unplug unit. Hold the plug firmly and pull it from the outlet. Pulling directly on the cord can damage it, which can lead to fire or electric shock.
- **Do not** modify the length of the power supply cord or use an extension cord to power the unit.
- **Do not** share the electrical outlet with other appliances. Improper or insufficient power supply can cause fire or electrical shock.
- The product must be properly grounded at the time of installation, or electrical shock may occur.
- For all electrical work, follow all local and national wiring standards, regulations, and the Installation Manual. Connect cables tightly, and clamp them securely to prevent external forces from damaging the terminal. Improper electrical connections can overheat and cause fire, and may also cause shock. All electrical connections must be made according to the Electrical Connection Diagram located on the panels of the indoor and outdoor units.
- All wiring must be properly arranged to ensure that the control board cover can close properly. If the control board cover is not closed properly, it can lead to corrosion and cause the connection points on the terminal to heat up, catch fire, or cause electrical shock.
- If connecting power to fixed wiring, an all-pole disconnection device which has at least 3mm clearances in all poles, and have a leakage current that may exceed 10mA, the residual current device(RCD) having a rated residual operating current not exceeding 30mA, and disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.

## TAKE NOTE OF FUSE SPECIFICATIONS

The air conditioner's circuit board (PCB) is designed with a fuse to provide overcurrent protection. The specifications of the fuse are printed on the circuit board ,such as :  
T3.15A/250VAC, T5A/250VAC, T3.15A/250VAC, T5A/250VAC, T20A/250VAC, T30A/250VAC,etc.



## WARNINGS FOR PRODUCT INSTALLATION

1. Installation must be performed by an authorized dealer or specialist. Defective installation can cause water leakage, electrical shock, or fire.
2. Installation must be performed according to the installation instructions. Improper installation can cause water leakage, electrical shock, or fire.  
(In North America, installation must be performed in accordance with the requirement of NEC and CEC by authorized personnel only.)
3. Contact an authorized service technician for repair or maintenance of this unit. This appliance shall be installed in accordance with national wiring regulations.
4. Only use the included accessories, parts, and specified parts for installation. Using non-standard parts can cause water leakage, electrical shock, fire, and can cause the unit to fail.
5. Install the unit in a firm location that can support the unit's weight. If the chosen location cannot support the unit's weight, or the installation is not done properly, the unit may drop and cause serious injury and damage.
6. Install drainage piping according to the instructions in this manual. Improper drainage may cause water damage to your home and property.
7. For units that have an auxiliary electric heater, **do not** install the unit within 1 meter (3 feet) of any combustible materials.
8. **Do not** install the unit in a location that may be exposed to combustible gas leaks. If combustible gas accumulates around the unit, it may cause fire.
9. Do not turn on the power until all work has been completed.
10. When moving or relocating the air conditioner, consult experienced service technicians for disconnection and reinstallation of the unit.
11. How to install the appliance to its support, please read the information for details in "indoor unit installation" and "outdoor unit installation" sections.

### Note about Fluorinated Gasses

1. This air-conditioning unit contains fluorinated greenhouse gases. For specific information on the type of gas and the amount, please refer to the relevant label on the unit itself
2. Installation, service, maintenance and repair of this unit must be performed by a certified technician.
3. Product un-installation and recycling must be performed by a certified technician.
4. For equipment that contains fluorinated greenhouse gases you must follow all local, state, province and national codes as regards system inspections relevant to the specific refrigerant.
5. When the unit is checked for leaks, proper record-keeping of all checks is strongly recommended.




# Unit Features

## Indoor unit display

**NOTE:** Different models have different front panel and display window. Not all the indicators describing below are available for the air conditioner you purchased. Please check the indoor display window of the unit you purchased.

Illustrations in this manual are for explanatory purposes. The actual shape of your indoor unit may be slightly different. The actual shape shall prevail.



" **ECO** " when ECO function is activated(some units)

" **°C** " Lights up in different colour according to the operation mode(some units):  
Under COOL and DRY mode, it displays as cool colour.  
Under HEAT mode, it displays as warm colour.

" **⊞** " when Wireless Control feature is activated(some units)

" **88** " Displays temperature, operation feature and Error codes:

" **00** " for 3 seconds when:

- TIMER ON is set (if the unit is OFF, " **00** " remains on when TIMER ON is set )
- FRESH , SWING, TURBO , SILENCE or SOLAR PV ECO feature is turned on

" **0F** " for 3 seconds when:

- TIMER OFF is set
- FRESH , SWING, TURBO , SILENCE or SOLAR PV ECO feature is turned off


" **cF** " when anti-cold air feature is turned on

" **dF** " when defrosting(cooling & heating units)

" **SC** " when unit is self-cleaning

" **FP** " when 8°C heating feature is turned on

### Display Code Meanings



" 88.8 " Displays temperature, operation feature and Error codes:

" 01 " for 3 seconds when:

- TIMER ON is set(if the unit is OFF, " 01 " remains on when TIMER ON is set )
- FRESH, SWING, TURBO, or SILENCE features is turned on

" 0F " for 3 seconds when:

- TIMER OFF is set
- FRESH, SWING, TURBO, or SILENCE features is turned off

" dF " when defrosting(for cooling & heating units)

" SC " when unit is self-cleaning(some units)

" FP " when 8°C(46°F) or 12°C(54°F) heating mode is turned on(some units)

" ∅ " when fresh feature is turned on(some units)

" ECO " when ECO feature is activated(some units)

" ∞ " when wireless control feature is activated(some units)

### Display Code Meanings

In Fan mode, the unit will display the room temperature.

In other modes, the unit will display your temperature setting.

Press the LED button on the remote control will turn off the display screen, press the LED button again during 15 seconds will display the room temperature, if press it again after 15 seconds, it will turn on the display screen.

## Operating temperature

When your air conditioner is used outside of the following temperature ranges, certain safety protection features may activate and cause the unit to disable.

### Inverter Split Type

	COOL mode	HEAT mode	DRY mode
Room Temperature	17°C - 32°C (62°F - 90°F)	0°C - 30°C (32°F - 86°F)	10°C - 32°C (50°F - 90°F)
Outdoor Temperature	0°C - 50°C (32°F - 122°F)	-15°C - 30°C (5°F - 86°F)	0°C - 50°C (32°F - 122°F)
	-15°C - 50°C (5°F - 122°F) (For models with low temp. cooling systems.)		
	0°C - 52°C (32°F - 126°F) (For special tropical models)		0°C - 52°C (32°F - 126°F) (For special tropical models)

#### FOR OUTDOOR UNITS WITH AUXILIARY ELECTRIC HEATER

When outside temperature is below 0°C (32°F), we strongly recommend keeping the unit plugged in at all time to ensure smooth ongoing performance.

### Fixed-speed Type

	COOL mode	HEAT mode	DRY mode
Room Temperature	17°C-32°C (62°F-90°F)	0°C-30°C (32°F-86°F)	10°C-32°C (50°F-90°F)
Outdoor Temperature	18°C-43°C (64°F-109°F)	-7°C-24°C (19°F-75°F)	11°C-43°C (52°F-109°F)
	-7°C-43°C (19°F-109°F) (For models with low-temp cooling systems)		18°C-43°C (64°F-109°F)
	18°C-52°C (64°F-126°F) (For special tropical models)		18°C-52°C (64°F-126°F) (For special tropical models)

**NOTE:** Room relative humidity less than 80%. If the air conditioner operates in excess of this figure, the surface of the air conditioner may attract condensation. Please sets the vertical air flow louver to its maximum angle (vertically to the floor), and set HIGH fan mode.

#### To further optimize the performance of your unit, do the following:

- Keep doors and windows closed.
- Limit energy usage by using TIMER ON and TIMER OFF functions.
- Do not block air inlets or outlets.
- Regularly inspect and clean air filters.

A guide on using the infrared remote is not included in this literature package. Not all the functions are available for the air conditioner, please check the indoor display and remote control of the unit you purchased.

## Other Features

- **Auto-Restart(some units)**

If the unit loses power, it will automatically restart with the prior settings once power has been restored.

- **Anti-mildew (some units)**

When turning off the unit from COOL, AUTO (COOL), or DRY modes, the air conditioner will continue operate at very low power to dry up condensed water and prevent mildew growth.

- **Wireless Control (some units)**

Wireless control allows you to control your air conditioner using your mobile phone and a wireless connection.

For the USB device access, replacement, maintenance operations must be carried out by professional staff.

- **Louver Angle Memory(some units)**

When turning on your unit, the louver will automatically resume its former angle.

- **Refrigerant Leakage Detection (some units)**


The indoor unit will automatically display "EC" or "ELOC" or flash LEDS (model dependent ) when it detects refrigerant leakage.

- **Sleep Operation**

The SLEEP function is used to decrease energy use while you sleep (and don't need the same temperature settings to stay comfortable). This function can only be activated via remote control. And the Sleep function is not available in FAN or DRY mode.

Press the **SLEEP** button when you are ready to go to sleep. When in COOL mode, the unit will increase the temperature by 1°C (2°F) after 1 hour, and will increase an additional 1°C (2°F) after another hour. When in HEAT mode, the unit will decrease the temperature by 1°C (2°F) after 1 hour, and will decrease an additional 1°C (2°F) after another hour.

The sleep feature will stop after 8 hours and the system will keep running with final situation.



## • Setting Angle of Air Flow

### Setting vertical angle of air flow

While the unit is on, use the **SWING/DIRECT** button on remote control to set the direction (vertical angle) of airflow. Please refer to the Remote Control Manual for details.

#### NOTE ON LOUVER ANGLES

When using COOL or DRY mode, do not set louver at too vertical an angle for long periods of time. This can cause water to condense on the louver blade, which will drop on your floor or furnishings.

When using COOL or HEAT mode, setting the louver at too vertical an angle can reduce the performance of the unit due to restricted air flow.

### Setting horizontal angle of air flow

The horizontal angle of the airflow must be set manually. Grip the deflector rod (See **Fig.B**) and manually adjust it to your preferred direction.

**For some units**, the horizontal angle of the airflow can be set by remote control. please refer to the Remote Control Manual.


### Manual Operation(without remote)

#### ! CAUTION

The manual button is intended for testing purposes and emergency operation only. Please do not use this function unless the remote control is lost and it is absolutely necessary. To restore regular operation, use the remote control to activate the unit. Unit must be turned off before manual operation.

To operate your unit manually:

1. Open the front panel of the indoor unit.
2. Locate the **MANUAL CONTROL button** on the right-hand side of the unit.
3. Press the **MANUAL CONTROL button** one time to activate FORCED AUTO mode.
4. Press the **MANUAL CONTROL button** again to activate FORCED COOLING mode.
5. Press the **MANUAL CONTROL button** a third time to turn the unit off.
6. Close the front panel.



**NOTE:** Do not move louver by hand. This will cause the louver to become out of sync. If this occurs, turn off the unit and unplug it for a few seconds, then restart the unit. This will reset the louver.

Fig. A



#### CAUTION

Do not put your fingers in or near the blower and suction side of the unit. The high-speed fan inside the unit may cause injury.





Fig. B





# Care and Maintenance

## Cleaning Your Indoor Unit

### BEFORE CLEANING OR MAINTENANCE

**ALWAYS TURN OFF YOUR AIR CONDITIONER SYSTEM AND DISCONNECT ITS POWER SUPPLY BEFORE CLEANING OR MAINTENANCE.**

### CAUTION

Only use a soft, dry cloth to wipe the unit clean. If the unit is especially dirty, you can use a cloth soaked in warm water to wipe it clean.





- **Do not** use chemicals or chemically treated cloths to clean the unit
- **Do not** use benzene, paint thinner, polishing powder or other solvents to clean the unit. They can cause the plastic surface to crack or deform.
- **Do not** use water hotter than 40°C (104°F) to clean the front panel. This can cause the panel to deform or become discolored.

## Cleaning Your Air Filter

A clogged air conditioner can reduce the cooling efficiency of your unit, and can also be bad for your health. Make sure to clean the filter once every two weeks.

1. Lift the front panel of the indoor unit.
2. Grip the tab on the end of the filter, lift it up, then pull it towards yourself.
3. Now pull the filter out.
4. If your filter has a small air freshening filter, unclip it from the larger filter. Clean this air freshening filter with a hand-held vacuum.
5. Clean the large air filter with warm, soapy water. Be sure to use a mild detergent.

6. Rinse the filter with fresh water, then shake off excess water.
7. Dry it in a cool, dry place, and refrain from exposing it to direct sunlight.
8. When dry, re-clip the air freshening filter to the larger filter, then slide it back into the indoor unit.
9. Close the front panel of the indoor unit.



### CAUTION

Do not touch air freshening (Plasma) filter for at least 10 minutes after turning off the unit.



## CAUTION

- Before changing the filter or cleaning, turn off the unit and disconnect its power supply.
- When removing filter, do not touch metal parts in the unit. The sharp metal edges can cut you.
- Do not use water to clean the inside of the indoor unit. This can destroy insulation and cause electrical shock.
- Do not expose filter to direct sunlight when drying. This can shrink the filter.

## Air Filter Reminders (Optional)

### Air Filter Cleaning Reminder

After 240 hours of use, the display window on the indoor unit will flash "CL." This is a reminder to clean your filter. After 15 seconds, the unit will revert to its previous display.

To reset the reminder, press the **LED** button on your remote control 4 times, or press the **MANUAL CONTROL** button 3 times. If you don't reset the reminder, the "CL" indicator will flash again when you restart the unit.

### Air Filter Replacement Reminder

After 2,880 hours of use, the display window on the indoor unit will flash "nF." This is a reminder to replace your filter. After 15 seconds, the unit will revert to its previous display.

To reset the reminder, press the **LED** button on your remote control 4 times, or press the **MANUAL CONTROL** button 3 times. If you don't reset the reminder, the "nF" indicator will flash again when you restart the unit.




## CAUTION


- Any maintenance and cleaning of outdoor unit should be performed by an authorized dealer or a licensed service provider.
- Any unit repairs should be performed by an authorized dealer or a licensed service provider.

## Maintenance – Long Periods of Non-Use

If you plan not to use your air conditioner for an extended period of time, do the following:




Clean all filters



Turn on FAN function until unit dries out completely




Turn off the unit and disconnect the power




Remove batteries from remote control

## Maintenance – Pre-Season Inspection

After long periods of non-use, or before periods of frequent use, do the following:




Check for damaged wires





Clean all filters



Check for leaks



Replace batteries



Make sure nothing is blocking all air inlets and outlets

# Troubleshooting



## SAFETY PRECAUTIONS

If ANY of the following conditions occurs, turn off your unit immediately!

- The power cord is damaged or abnormally warm
- You smell a burning odor
- The unit emits loud or abnormal sounds
- A power fuse blows or the circuit breaker frequently trips
- Water or other objects fall into or out of the unit

**DO NOT ATTEMPT TO FIX THESE YOURSELF! CONTACT AN AUTHORIZED SERVICE PROVIDER IMMEDIATELY!**

## Common Issues

The following problems are not a malfunction and in most situations will not require repairs.

Issue	Possible Causes
<b>Unit does not turn on when pressing ON/OFF button</b>	The Unit has a 3-minute protection feature that prevents the unit from overloading. The unit cannot be restarted within three minutes of being turned off.
<b>The unit changes from COOL/HEAT mode to FAN mode</b>	The unit may change its setting to prevent frost from forming on the unit. Once the temperature increases, the unit will start operating in the previously selected mode again.
	The set temperature has been reached, at which point the unit turns off the compressor. The unit will continue operating when the temperature fluctuates again.
<b>The indoor unit emits white mist</b>	In humid regions, a large temperature difference between the room's air and the conditioned air can cause white mist.
<b>Both the indoor and outdoor units emit white mist</b>	When the unit restarts in HEAT mode after defrosting, white mist may be emitted due to moisture generated from the defrosting process.
<b>The indoor unit makes noises</b>	A rushing air sound may occur when the louver resets its position.
	A squeaking sound may occur after running the unit in HEAT mode due to expansion and contraction of the unit's plastic parts.
<b>Both the indoor unit and outdoor unit make noises</b>	Low hissing sound during operation: This is normal and is caused by refrigerant gas flowing through both indoor and outdoor units.
	Low hissing sound when the system starts, has just stopped running, or is defrosting: This noise is normal and is caused by the refrigerant gas stopping or changing direction.
	Squeaking sound: Normal expansion and contraction of plastic and metal parts caused by temperature changes during operation can cause squeaking noises.

Issue	Possible Causes
<b>The outdoor unit makes noises</b>	The unit will make different sounds based on its current operating mode.
<b>Dust is emitted from either the indoor or outdoor unit</b>	The unit may accumulate dust during extended periods of non-use, which will be emitted when the unit is turned on. This can be mitigated by covering the unit during long periods of inactivity.
<b>The unit emits a bad odor</b>	The unit may absorb odors from the environment (such as furniture, cooking, cigarettes, etc.) which will be emitted during operations.
	The unit's filters have become moldy and should be cleaned.
<b>The fan of the outdoor unit does not operate</b>	During operation, the fan speed is controlled to optimize product operation.
<b>Operation is erratic, unpredictable, or unit is unresponsive</b>	Interference from cell phone towers and remote boosters may cause the unit to malfunction. In this case, try the following:
	<ul style="list-style-type: none"> <li>• Disconnect the power, then reconnect.</li> <li>• Press ON/OFF button on remote control to restart operation.</li> </ul>

**NOTE:** If problem persists, contact a local dealer or your nearest customer service center. Provide them with a detailed description of the unit malfunction as well as your model number.

## Troubleshooting

When troubles occur, please check the following points before contacting a repair company.












Problem	Possible Causes	Solution
<b>Poor Cooling Performance</b>	Temperature setting may be higher than ambient room temperature	Lower the temperature setting
	The heat exchanger on the indoor or outdoor unit is dirty	Clean the affected heat exchanger
	The air filter is dirty	Remove the filter and clean it according to instructions
	The air inlet or outlet of either unit is blocked	Turn the unit off, remove the obstruction and turn it back on
	Doors and windows are open	Make sure that all doors and windows are closed while operating the unit
	Excessive heat is generated by sunlight	Close windows and curtains during periods of high heat or bright sunshine
	Too many sources of heat in the room (people, computers, electronics, etc.)	Reduce amount of heat sources
	Low refrigerant due to leak or long-term use	Check for leaks, re-seal if necessary and top off refrigerant
	SILENCE function is activated (optional function)	SILENCE function can lower product performance by reducing operating frequency. Turn off SILENCE function.



Problem	Possible Causes	Solution
<b>The unit is not working</b>	Power failure	Wait for the power to be restored
	The power is turned off	Turn on the power
	The fuse is burned out	Replace the fuse
	Remote control batteries are dead	Replace batteries
	The Unit's 3-minute protection has been activated	Wait three minutes after restarting the unit
	Timer is activated	Turn timer off
<b>The unit starts and stops frequently</b>	There's too much or too little refrigerant in the system	Check for leaks and recharge the system with refrigerant.
	Incompressible gas or moisture has entered the system.	Evacuate and recharge the system with refrigerant
	The compressor is broken	Replace the compressor
	The voltage is too high or too low	Install a manostat to regulate the voltage
<b>Poor heating performance</b>	The outdoor temperature is extremely low	Use auxiliary heating device
	Cold air is entering through doors and windows	Make sure that all doors and windows are closed during use
	Low refrigerant due to leak or long-term use	Check for leaks, re-seal if necessary and top off refrigerant
<b>Indicator lamps continue flashing</b>	<p>The unit may stop operation or continue to run safely. If the indicator lamps continue to flash or error codes appear, wait for about 10 minutes. The problem may resolve itself.</p> <p>If not, disconnect the power, then connect it again. Turn the unit on. If the problem persists, disconnect the power and contact your nearest customer service center.</p>	
<b>Error code appears and begins with the letters as the following in the window display of indoor unit:</b> <ul style="list-style-type: none"> <li>• E(x), P(x), F(x)</li> <li>• EH(xx), EL(xx), EC(xx)</li> <li>• PH(xx), PL(xx), PC(xx)</li> </ul>		

**NOTE:** If your problem persists after performing the checks and diagnostics above, turn off your unit immediately and contact an authorized service center.


# Accessories

The air conditioning system comes with the following accessories. Use all of the installation parts and accessories to install the air conditioner. Improper installation may result in water leakage, electrical shock and fire, or cause the equipment to fail. The items are not included with the air conditioner must be purchased separately.

Name of Accessories	Q'ty(pc)	Shape	Name of Accessories	Q'ty(pc)	Shape
Manual	2-3		Remote controller	1	
Drain joint (for cooling & heating models)	1		Battery	2	
Seal (for cooling & heating models)	1		Remote controller holder(optional)	1	
Mounting plate	1		Fixing screw for remote controller holder(optional)	2	
Anchor	5~8 (depending on models)		Small Filter (Need to be installed on the back of main air filter by the authorized technician while installing the machine)	1~2 (depending on models)	
Mounting plate fixing screw	5~8 (depending on models)				


Name	Shape	Quantity(PC)
Connecting pipe assembly	Liquid side	Φ 6.35(1/4in)
		Φ 9.52(3/8in)
	Gas side	Φ 9.52(3/8in)
		Φ 12.7(1/2in)
		Φ 16(5/8in)
		Φ 19(3/4in)
Magnetic ring and belt (if supplied ,please refer to the wiring diagram to install it on the connective cable. )	  <p>Pass the belt through the hole of the Magnetic ring to fix it on the cable</p>	Varies by model

# Installation Summary - Indoor Unit



# Unit Parts

**NOTE:** The installation must be performed in accordance with the requirement of local and national standards. The installation may be slightly different in different areas.



- |                            |   |   |
|----------------------------|---|---|
| ① Wall Mounting Plate      | ⑤ Functional Filter (On Back of Main Filter - Some Units) | ⑨ Remote Controller                     |
| ② Front Panel              | ⑥ Drainage Pipe   | ⑩ Remote controller Holder (Some Units) |
| ③ Power Cable (Some Units) | ⑦ Signal Cable  | ⑪ Outdoor Unit Power Cable (Some Units) |
| ④ Louver                   | ⑧ Refrigerant Piping                                      |   |

## NOTE ON ILLUSTRATIONS

Illustrations in this manual are for explanatory purposes. The actual shape of your indoor unit may be slightly different. The actual shape shall prevail.



# Indoor Unit Installation

## Installation Instructions – Indoor unit

### PRIOR TO INSTALLATION

Before installing the indoor unit, refer to the label on the product box to make sure that the model number of the indoor unit matches the model number of the outdoor unit.

#### Step 1: Select installation location

Before installing the indoor unit, you must choose an appropriate location. The following are standards that will help you choose an appropriate location for the unit.

#### Proper installation locations meet the following standards:

- ☑ Good air circulation
- ☑ Convenient drainage
- ☑ Noise from the unit will not disturb other people
- ☑ Firm and solid—the location will not vibrate
- ☑ Strong enough to support the weight of the unit
- ☑ A location at least one meter from all other electrical devices (e.g., TV, radio, computer)

#### **DO NOT** install unit in the following locations:

- ⊘ Near any source of heat, steam, or combustible gas
- ⊘ Near flammable items such as curtains or clothing
- ⊘ Near any obstacle that might block air circulation
- ⊘ Near the doorway
- ⊘ In a location subject to direct sunlight


### NOTE ABOUT WALL HOLE:

If there is no fixed refrigerant piping:

While choosing a location, be aware that you should leave ample room for a wall hole (see **Drill wall hole for connective piping** step) for the signal cable and refrigerant piping that connect the indoor and outdoor units.

The default position for all piping is the right side of the indoor unit (while facing the unit). However, the unit can accommodate piping to both the left and right.


#### Refer to the following diagram to ensure proper distance from walls and ceiling:



#### Step 2: Attach mounting plate to wall

The mounting plate is the device on which you will mount the indoor unit.

- Remove the screw that attaches the mounting plate to the back of the indoor unit.



- Secure the mounting plate to the wall with the screws provided. Make sure that mounting plate is flat against the wall.

### NOTE FOR CONCRETE OR BRICK WALLS:

If the wall is made of brick, concrete, or similar material, drill 5mm-diameter (0.2in-diameter) holes in the wall and insert the sleeve anchors provided. Then secure the mounting plate to the wall by tightening the screws directly into the clip anchors.


### Step 3: Drill wall hole for connective piping

1. Determine the location of the wall hole based on the position of the mounting plate. Refer to **Mounting Plate Dimensions**.
2. Using a 65mm (2.5in) or 90mm(3.54in) (depending on models )core drill, drill a hole in the wall. Make sure that the hole is drilled at a slight downward angle, so that the outdoor end of the hole is lower than the indoor end by about 5mm to 7mm (0.2-0.275in). This will ensure proper water drainage.
3. Place the protective wall cuff in the hole. This protects the edges of the hole and will help seal it when you finish the installation process.



### CAUTION



When drilling the wall hole, make sure to avoid wires, plumbing, and other sensitive components.




### MOUNTING PLATE DIMENSIONS

Different models have different mounting plates. For the different customization requirements, the shape of the mounting plate may be slightly different. But the installation dimensions are the same for the same size of indoor unit. See Type A and Type B for example:


#### Correct orientation of Mounting Plate




Type A




Type B




Model A




Model B



Model C



Model D




Model E

**NOTE:** When the gas side connective pipe is  $\Phi$  16mm(5/8in) or more, the wall hole should be 90mm(3.54in).

#### Step 4: Prepare refrigerant piping

The refrigerant piping is inside an insulating sleeve attached to the back of the unit. You must prepare the piping before passing it through the hole in the wall.

1. Based on the position of the wall hole relative to the mounting plate, choose the side from which the piping will exit the unit.
2. If the wall hole is behind the unit, keep the knock-out panel in place. If the wall hole is to the side of the indoor unit, remove the plastic knock-out panel from that side of the unit. This will create a slot through which your piping can exit the unit. Use needle nose pliers if the plastic panel is too difficult to remove by hand.
3. Groove has been made in the knock-out panel in order to cut it conveniently. The size of the slot is determined by the diameter of piping.




Knock-out Panel

4. If existing connective piping is already embedded in the wall, proceed directly to the **Connect Drain Hose** step. If there is no embedded piping, connect the indoor unit's refrigerant piping to the connective piping that will join the indoor and outdoor units. Refer to the **Refrigerant Piping Connection** section of this manual for detailed instructions.

#### NOTE ON PIPING ANGLE

Refrigerant piping can exit the indoor unit from four different angles: Left-hand side, Right-hand side, Left rear, Right rear.



#### CAUTION

Be extremely careful not to dent or damage the piping while bending them away from the unit. Any dents in the piping will affect the unit's performance.

#### Step 5: Connect drain hose


By default, the drain hose is attached to the left-hand side of unit (when you're facing the back of the unit). However, it can also be attached to the right-hand side. To ensure proper drainage, attach the drain hose on the same side that your refrigerant piping exits the unit. Attach drain hose extension (purchased separately) to the end of drain hose.

- Wrap the connection point firmly with Teflon tape to ensure a good seal and to prevent leaks.
- For the portion of the drain hose that will remain indoors, wrap it with foam pipe insulation to prevent condensation.
- Remove the air filter and pour a small amount of water into the drain pan to make sure that water flows from the unit smoothly.




#### NOTE ON DRAIN HOSE PLACEMENT

Make sure to arrange the drain hose according to the following figures.




#### CORRECT

Make sure there are no kinks or dent in drain hose to ensure proper drainage.




#### NOT CORRECT

Kinks in the drain hose will create water traps.



#### NOT CORRECT


Kinks in the drain hose will create water traps.



#### NOT CORRECT

Do not place the end of the drain hose in water or in containers that collect water. This will prevent proper drainage.

#### PLUG THE UNUSED DRAIN HOLE



To prevent unwanted leaks you must plug the unused drain hole with the rubber plug provided.



## BEFORE PERFORMING ANY ELECTRICAL WORK, READ THESE REGULATIONS

1. All wiring must comply with local and national electrical codes, regulations and must be installed by a licensed electrician.
2. All electrical connections must be made according to the Electrical Connection Diagram located on the panels of the indoor and outdoor units.
3. If there is a serious safety issue with the power supply, stop work immediately. Explain your reasoning to the client, and refuse to install the unit until the safety issue is properly resolved.
4. Power voltage should be within 90-110% of rated voltage. Insufficient power supply can cause malfunction, electrical shock, or fire.
5. If connecting power to fixed wiring, a surge protector and main power switch should be installed.
6. If connecting power to fixed wiring, a switch or circuit breaker that disconnects all poles and has a contact separation of at least 1/8in (3mm) must be incorporated in the fixed wiring. The qualified technician must use an approved circuit breaker or switch.
7. Only connect the unit to an individual branch circuit outlet. Do not connect another appliance to that outlet.
8. Make sure to properly ground the air conditioner.
9. Every wire must be firmly connected. Loose wiring can cause the terminal to overheat, resulting in product malfunction and possible fire.
10. Do not let wires touch or rest against refrigerant tubing, the compressor, or any moving parts within the unit.
11. If the unit has an auxiliary electric heater, it must be installed at least 1 meter (40in) away from any combustible materials.
12. To avoid getting an electric shock, never touch the electrical components soon after the power supply has been turned off. After turning off the power, always wait 10 minutes or more before you touch the electrical components.



## WARNING

**BEFORE PERFORMING ANY ELECTRICAL OR WIRING WORK, TURN OFF THE MAIN POWER TO THE SYSTEM.**

### Step 6: Connect signal and power cables

The signal cable enables communication between the indoor and outdoor units. You must first choose the right cable size before preparing it for connection.

#### Cable Types

- **Indoor Power Cable** (if applicable): H05VV-F or H05V2V2-F
- **Outdoor Power Cable:** H07RN-F or H05RN-F
- **Signal Cable:** H07RN-F

**NOTE:** In North America, choose the cable type according to the local electrical codes and regulations.

### Minimum Cross-Sectional Area of Power and Signal Cables (For reference) (Not applicable for North America)


Rated Current of Appliance (A)	Nominal Cross-Sectional Area (mm <sup>2</sup> )
> 3 and ≤ 6	0.75
> 6 and ≤ 10	1
> 10 and ≤ 16	1.5
> 16 and ≤ 25	2.5
> 25 and ≤ 32	4
> 32 and ≤ 40	6

### CHOOSE THE RIGHT CABLE SIZE

The size of the power supply cable, signal cable, fuse, and switch needed is determined by the maximum current of the unit. The maximum current is indicated on the nameplate located on the side panel of the unit. Refer to this nameplate to choose the right cable, fuse, or switch.

**NOTE:** In North America, please choose the right cable size according to the Minimum Circuit Ampacity indicated on the nameplate of the unit.

1. Open front panel of the indoor unit.
2. Using a screwdriver, open the wire box cover on the right side of the unit. This will reveal the terminal block.



## WARNING

**ALL WIRING MUST BE PERFORMED STRICTLY IN ACCORDANCE WITH THE WIRING DIAGRAM LOCATED ON THE BACK OF THE INDOOR UNIT'S FRONT PANEL .**

3. Unscrew the cable clamp below the terminal block and place it to the side.
4. Facing the back of the unit, remove the plastic panel on the bottom left-hand side.
5. Feed the signal wire through this slot, from the back of the unit to the front.
6. Facing the front of the unit, connect the wire according to the indoor unit's wiring diagram, connect the u-lug and firmly screw each wire to its corresponding terminal.



## CAUTION

### DO NOT MIX UP LIVE AND NULL WIRES

This is dangerous, and can cause the air conditioning unit to malfunction.

7. After checking to make sure every connection is secure, use the cable clamp to fasten the signal cable to the unit. Screw the cable clamp down tightly.
8. Replace the wire cover on the front of the unit, and the plastic panel on the back.


## NOTE ABOUT WIRING

**THE WIRING CONNECTION PROCESS MAY DIFFER SLIGHTLY BETWEEN UNITS AND REGIONS.**

### Step 7: Wrapping and cables

Before passing the piping, drain hose, and the signal cable through the wall hole, you must bundle them together to save space, protect them, and insulate them (Not applicable in North America).

1. Bundle the drain hose, refrigerant pipes, and signal cable as shown below:



### DRAIN HOSE MUST BE ON BOTTOM

Make sure that the drain hose is at the bottom of the bundle. Putting the drain hose at the top of the bundle can cause the drain pan to overflow, which can lead to fire or water damage.

### DO NOT INTERTWINE SIGNAL CABLE WITH OTHER WIRES

While bundling these items together, do not intertwine or cross the signal cable with any other wiring.

2. Using adhesive vinyl tape, attach the drain hose to the underside of the refrigerant pipes.
3. Using insulation tape, wrap the signal wire, refrigerant pipes, and drain hose tightly together. Double-check that all items are bundled.

### DO NOT WRAP ENDS OF PIPING

When wrapping the bundle, keep the ends of the piping unwrapped. You need to access them to test for leaks at the end of the installation process (refer to **Electrical Checks and Leak Checks** section of this manual).




## Step 8: Mount indoor unit

**If you installed new connective piping to the outdoor unit,** do the following:

1. If you have already passed the refrigerant piping through the hole in the wall, proceed to Step 4.
2. Otherwise, double-check that the ends of the refrigerant pipes are sealed to prevent dirt or foreign materials from entering the pipes.
3. Slowly pass the wrapped bundle of refrigerant pipes, drain hose, and signal wire through the hole in the wall.
4. Hook the top of the indoor unit on the upper hook of the mounting plate.
5. Check that unit is hooked firmly on mounting by applying slight pressure to the left and right-hand sides of the unit. The unit should not jiggle or shift.
6. Using even pressure, push down on the bottom half of the unit. Keep pushing down until the unit snaps onto the hooks along the bottom of the mounting plate.
7. Again, check that the unit is firmly mounted by applying slight pressure to the left and the right-hand sides of the unit.

**If refrigerant piping is already embedded in the wall,** do the following:


1. Hook the top of the indoor unit on the upper hook of the mounting plate.
2. Use a bracket or wedge to prop up the unit, giving you enough room to connect the refrigerant piping, signal cable, and drain hose.



3. Connect drain hose and refrigerant piping (refer to **Refrigerant Piping Connection** section of this manual for instructions).
4. Keep pipe connection point exposed to perform the leak test (refer to **Electrical Checks and Leak Checks** section of this manual).
5. After the leak test, wrap the connection point with insulation tape.
6. Remove the bracket or wedge that is propping up the unit.
7. Using even pressure, push down on the bottom half of the unit. Keep pushing down until the unit snaps onto the hooks along the bottom of the mounting plate.


### UNIT IS ADJUSTABLE

Keep in mind that the hooks on the mounting plate are smaller than the holes on the back of the unit. If you find that you don't have ample room to connect embedded pipes to the indoor unit, the unit can be adjusted left or right by about 30-50mm (1.18-1.96in), depending on the model.



# Outdoor Unit Installation

Install the unit by following local codes and regulations, there may be differ slightly between different regions.



## Installation Instructions – Outdoor unit

### Step 1: Select installation location

Before installing the outdoor unit, you must choose an appropriate location. The following are standards that will help you choose an appropriate location for the unit.

#### Proper installation locations meet the following standards:

- ☑ Meets all spatial requirements shown in Installation Space Requirements above.
- ☑ Good air circulation and ventilation
- ☑ Firm and solid—the location can support the unit and will not vibrate
- ☑ Noise from the unit will not disturb others
- ☑ Protected from prolonged periods of direct sunlight or rain
- ☑ Where snowfall is anticipated, raise the unit above the base pad to prevent ice buildup and coil damage. Mount the unit high enough to be above the average accumulated area snowfall. The minimum height must be 18 inches


### **DO NOT** install unit in the following locations:

- ⊘ Near an obstacle that will block air inlets and outlets
- ⊘ Near a public street, crowded areas, or where noise from the unit will disturb others
- ⊘ Near animals or plants that will be harmed by hot air discharge
- ⊘ Near any source of combustible gas
- ⊘ In a location that is exposed to large amounts of dust
- ⊘ In a location exposed to a excessive amounts of salty air

### SPECIAL CONSIDERATIONS FOR EXTREME WEATHER

#### If the unit is exposed to heavy wind:

Install unit so that air outlet fan is at a 90° angle to the direction of the wind. If needed, build a barrier in front of the unit to protect it from extremely heavy winds. See Figures below.



#### If the unit is frequently exposed to heavy rain or snow:

Build a shelter above the unit to protect it from the rain or snow. Be careful not to obstruct air flow around the unit.

#### If the unit is frequently exposed to salty air (seaside):

Use outdoor unit that is specially designed to resist corrosion.

## Step 2: Install drain joint(Heat pump unit only)


Before bolting the outdoor unit in place, you must install the drain joint at the bottom of the unit. Note that there are two different types of drain joints depending on the type of outdoor unit.

**If the drain joint comes with a rubber seal** (see **Fig. A**), do the following:

1. Fit the rubber seal on the end of the drain joint that will connect to the outdoor unit.
2. Insert the drain joint into the hole in the base pan of the unit.
3. Rotate the drain joint 90° until it clicks in place facing the front of the unit.
4. Connect a drain hose extension (not included) to the drain joint to redirect water from the unit during heating mode.

**If the drain joint doesn't come with a rubber seal** (see **Fig. B**), do the following:

1. Insert the drain joint into the hole in the base pan of the unit. The drain joint will click in place.
2. Connect a drain hose extension (not included) to the drain joint to redirect water from the unit during heating mode.



## ! IN COLD CLIMATES



In cold climates, make sure that the drain hose is as vertical as possible to ensure swift water drainage. If water drains too slowly, it can freeze in the hose and flood the unit.

## Step 3: Anchor outdoor unit

The outdoor unit can be anchored to the ground or to a wall-mounted bracket with bolt(M10). Prepare the installation base of the unit according to the dimensions below.

### UNIT MOUNTING DIMENSIONS

The following is a list of different outdoor unit sizes and the distance between their mounting feet. Prepare the installation base of the unit according to the dimensions below.





Outdoor Unit Dimensions (mm)	Mounting Dimensions	
	Distance A (mm)	Distance B (mm)
W x H x D		
681x434x285 (26.8" x 17.1" x 11.2")	460 (18.1")	292 (11.5")
700x550x270 (27.5" x 21.6" x 10.6")	450 (17.7")	260 (10.2")
700x550x275 (27.5" x 21.6" x 10.8")	450 (17.7")	260 (10.2")
720x495x270 (28.3" x 19.5" x 10.6")	452 (17.8")	255 (10.0")
728x555x300 (28.7" x 21.8" x 11.8")	452 (17.8")	302 (11.9")
765x555x303 (30.1" x 21.8" x 11.9")	452 (17.8")	286 (11.3")
770x555x300 (30.3" x 21.8" x 11.8")	487 (19.2")	298 (11.7")
805x554x330 (31.7" x 21.8" x 12.9")	511 (20.1")	317 (12.5")
800x554x333 (31.5" x 21.8" x 13.1")	514 (20.2")	340 (13.4")
845x702x363 (33.3" x 27.6" x 14.3")	540 (21.3")	350 (13.8")
890x673x342 (35.0" x 26.5" x 13.5")	663 (26.1")	354 (13.9")
946x810x420 (37.2" x 31.9" x 16.5")	673 (26.5")	403 (15.9")
946x810x410 (37.2" x 31.9" x 16.1")	673 (26.5")	403 (15.9")

**If you will install the unit on the ground or on a concrete mounting platform, do the following:**

1. Mark the positions for four expansion bolts based on dimensions chart.
2. Pre-drill holes for expansion bolts.
3. Place a nut on the end of each expansion bolt.
4. Hammer expansion bolts into the pre-drilled holes.
5. Remove the nuts from expansion bolts, and place outdoor unit on bolts.
6. Put washer on each expansion bolt, then replace the nuts.
7. Using a wrench, tighten each nut until snug.



### WARNING

**WHEN DRILLING INTO CONCRETE, EYE PROTECTION IS RECOMMENDED AT ALL TIMES.**

**If you will install the unit on a wall-mounted bracket, do the following:**



### CAUTION

Make sure that the wall is made of solid brick, concrete, or of similarly strong material. **The wall must be able to support at least four times the weight of the unit.**

1. Mark the position of bracket holes based on dimensions chart.
2. Pre-drill the holes for the expansion bolts.
3. Place a washer and nut on the end of each expansion bolt.
4. Thread expansion bolts through holes in mounting brackets, put mounting brackets in position, and hammer expansion bolts into the wall.
5. Check that the mounting brackets are level.
6. Carefully lift unit and place its mounting feet on brackets.
7. Bolt the unit firmly to the brackets.
8. If allowed, install the unit with rubber gaskets to reduce vibrations and noise.

#### Step 4: Connect signal and power cables

The outside unit's terminal block is protected by an electrical wiring cover on the side of the unit. A comprehensive wiring diagram is printed on the inside of the wiring cover.



#### WARNING

**BEFORE PERFORMING ANY ELECTRICAL OR WIRING WORK, TURN OFF THE MAIN POWER TO THE SYSTEM.**

1. Prepare the cable for connection:

#### USE THE RIGHT CABLE

Please choose the right cable refer to "Cable types" in page 23.

#### CHOOSE THE RIGHT CABLE SIZE

The size of the power supply cable, signal cable, fuse, and switch needed is determined by the maximum current of the unit. The maximum current is indicated on the nameplate located on the side panel of the unit.

**NOTE:** In North America, please choose the right cable size according to the Minimum Circuit Ampacity indicated on the nameplate of the unit.

- Using wire strippers, strip the rubber jacket from both ends of cable to reveal about 40mm (1.57in) of the wires inside.
- Strip the insulation from the ends of the wires.
- Using a wire crimper, crimp u-lugs on the ends of the wires.

#### PAY ATTENTION TO LIVE WIRE

While crimping wires, make sure you clearly distinguish the Live ("L") Wire from other wires.




#### WARNING


**ALL WIRING WORK MUST BE PERFORMED STRICTLY IN ACCORDANCE WITH THE WIRING DIAGRAM LOCATED INSIDE OF WIRE COVER OF THE OUTDOOR UNIT .**

- Unscrew the electrical wiring cover and remove it.
- Unscrew the cable clamp below the terminal block and place it to the side.
- Connect the wire according to the wiring diagram, and firmly screw the u-lug of each wire to its corresponding terminal.
- After checking to make sure every connection is secure, loop the wires around to prevent rain water from flowing into the terminal.
- Using the cable clamp, fasten the cable to the unit. Screw the cable clamp down tightly.


- Insulate unused wires with PVC electrical tape. Arrange them so that they do not touch any electrical or metal parts.
- Replace the wire cover on the side of the unit, and screw it in place.



**NOTE:** If the cable clamp looks like the following, please select the appropriate through-hole according to the diameter of the wire.




Three size hole: Small, Large, Medium



When the cable is not fasten enough, use the buckle to prop it up, so it can be clamped tightly.

#### In North America

- Remove the wire cover from the unit by loosening the 3 screws.
- Dismount caps on the conduit panel.
- Temporarily mount the conduit tubes(not included) on the conduit panel.
- Properly connect both the power supply and low voltage lines to the corresponding terminals on the terminal block.
- Ground the unit in accordance with local codes.
- Be sure to size each wire allowing several inches longer than the required length for wiring.
- Use lock nuts to secure the conduit tubes.



# Refrigerant Piping Connection

When connecting refrigerant piping, **do not** let substances or gases other than the specified refrigerant enter the unit. The presence of other gases or substances will lower the unit's capacity, and can cause abnormally high pressure in the refrigeration cycle. This can cause explosion and injury.

## Note on Pipe Length

The length of refrigerant piping will affect the performance and energy efficiency of the unit. Nominal efficiency is tested on units with a pipe length of 5 meters (16.5ft)( In North America, the standard pipe length is 7.5m (25'). A minimum pipe run of 3 metres is required to minimise vibration & excessive noise. In special tropical area, for the R290 refrigerant models, no refrigerant can be added and the maximum length of refrigerant pipe should not exceed 10 meters(32.8ft).

Refer to the table below for specifications on the maximum length and drop height of piping.

**Maximum Length and Drop Height of Refrigerant Piping per Unit Model**


Model	Capacity (BTU/h)	Max. Length (m)	Max. Drop Height (m)
R410A,R32 Inverter Split Air Conditioner	< 15,000	25 (82ft)	10 (33ft)
	≥ 15,000 and < 24,000	30 (98.5ft)	20 (66ft)
	≥ 24,000 and < 36,000	50 (164ft)	25 (82ft)
R22 Fixed-speed Split Air Conditioner	< 18,000	10 (33ft)	5 (16ft)
	≥ 18,000 and < 21,000	15 (49ft)	8(26ft)
	≥ 21,000 and < 35,000	20 (66ft)	10(33ft)
R410A, R32 Fixed-speed Split Air Conditioner	< 18,000	20 (66ft)	8(26ft)
	≥ 18,000 and < 36,000	25 (82ft)	10(33ft)

## Connection Instructions – Refrigerant Piping

### Step 1: Cut pipes

When preparing refrigerant pipes, take extra care to cut and flare them properly. This will ensure efficient operation and minimize the need for future maintenance.

1. Measure the distance between the indoor and outdoor units.
2. Using a pipe cutter, cut the pipe a little longer than the measured distance.
3. Make sure that the pipe is cut at a perfect 90° angle.




### **DO NOT DEFORM PIPE WHILE CUTTING**

Be extra careful not to damage, dent, or deform the pipe while cutting. This will drastically reduce the heating efficiency of the unit.

## Step 2: Remove burrs

Burrs can affect the air-tight seal of refrigerant piping connection. They must be completely removed.


1. Hold the pipe at a downward angle to prevent burrs from falling into the pipe.
2. Using a reamer or deburring tool, remove all burrs from the cut section of the pipe.




## Step 3: Flare pipe ends

Proper flaring is essential to achieve an airtight seal.

1. After removing burrs from cut pipe, seal the ends with PVC tape to prevent foreign materials from entering the pipe.
2. Sheath the pipe with insulating material.
3. Place flare nuts on both ends of pipe. Make sure they are facing in the right direction, because you can't put them on or change their direction after flaring.




4. Remove PVC tape from ends of pipe when ready to perform flaring work.
5. Clamp flare form on the end of the pipe. The end of the pipe must extend beyond the edge of the flare form in accordance with the dimensions shown in the table below.



## PIPING EXTENSION BEYOND FLARE FORM

Outer Diameter of Pipe (mm)	A (mm)	
	Min.	Max.
Ø 6.35 (Ø 0.25")	0.7 (0.0275")	1.3 (0.05")
Ø 9.52 (Ø 0.375")	1.0 (0.04")	1.6 (0.063")
Ø 12.7 (Ø 0.5")	1.0 (0.04")	1.8 (0.07")
Ø 16 (Ø 0.63")	2.0 (0.078")	2.2 (0.086")
Ø 19 (Ø 0.75")	2.0 (0.078")	2.4 (0.094")




6. Place flaring tool onto the form.
7. Turn the handle of the flaring tool clockwise until the pipe is fully flared.
8. Remove the flaring tool and flare form, then inspect the end of the pipe for cracks and even flaring.

## Step 4: Connect pipes

When connecting refrigerant pipes, be careful not to use excessive torque or to deform the piping in any way. You should first connect the low-pressure pipe, then the high-pressure pipe.


### MINIMUM BEND RADIUS

When bending connective refrigerant piping, the minimum bending radius is 10cm.




## Instructions for Connecting Piping to Indoor Unit

1. Align the center of the two pipes that you will connect.



2. Tighten the flare nut as tightly as possible by hand.
3. Using a spanner, grip the nut on the unit tubing.
4. While firmly gripping the nut on the unit tubing, use a torque wrench to tighten the flare nut according to the torque values in the **Torque Requirements** table below. Loosen the flaring nut slightly, then tighten again.



### TORQUE REQUIREMENTS

Outer Diameter of Pipe (mm)	Tightening Torque (N•m)	Flare dimension(B) (mm)	Flare shape
Ø 6.35 (Ø 0.25")	18~20(180~200kgf.cm)	8.4~8.7 (0.33~0.34")	
Ø 9.52 (Ø 0.375")	32~39(320~390kgf.cm)	13.2~13.5 (0.52~0.53")	
Ø 12.7 (Ø 0.5")	49~59(490~590kgf.cm)	16.2~16.5 (0.64~0.65")	
Ø 16 (Ø 0.63")	57~71(570~710kgf.cm)	19.2~19.7 (0.76~0.78")	
Ø 19 (Ø 0.75")	67~101(670~1010kgf.cm)	23.2~23.7 (0.91~0.93")	

### ⚠ DO NOT USE EXCESSIVE TORQUE


Excessive force can break the nut or damage the refrigerant piping. You must not exceed torque requirements shown in the table above.

### Instructions for Connecting Piping to Outdoor Unit


1. Unscrew the cover from the packed valve on the side of the outdoor unit.
2. Remove protective caps from ends of valves.
3. Align flared pipe end with each valve, and tighten the flare nut as tightly as possible by hand.
4. Using a spanner, grip the body of the valve. Do not grip the nut that seals the service valve.
5. While firmly gripping the body of the valve, use a torque wrench to tighten the flare nut according to the correct torque values.
6. Loosen the flaring nut slightly, then tighten again.
7. Repeat Steps 3 to 6 for the remaining pipe.

### ⚠ USE SPANNER TO GRIP MAIN BODY OF VALVE

Torque from tightening the flare nut can snap off other parts of valve.



Valve cover



5. While firmly gripping the body of the valve, use a torque wrench to tighten the flare nut according to the correct torque values.

# Air Evacuation

## Preparations and Precautions

Air and foreign matter in the refrigerant circuit can cause abnormal rises in pressure, which can damage the air conditioner, reduce its efficiency, and cause injury. Use a vacuum pump and manifold gauge to evacuate the refrigerant circuit, removing any non-condensable gas and moisture from the system.


Evacuation should be performed upon initial installation and when unit is relocated.

### BEFORE PERFORMING EVACUATION

- ☑ Check to make sure the connective pipes between the indoor and outdoor units are connected properly.
- ☑ Check to make sure all wiring is connected properly.


## Evacuation Instructions

1. Connect the charge hose of the manifold gauge to service port on the outdoor unit's low pressure valve.
2. Connect another charge hose from the manifold gauge to the vacuum pump.
3. Open the Low Pressure side of the manifold gauge. Keep the High Pressure side closed.
4. Turn on the vacuum pump to evacuate the system.
5. Run the vacuum for at least 15 minutes, or until the Compound Meter reads -76cmHg (-10<sup>5</sup>Pa).



6. Close the Low Pressure side of the manifold gauge, and turn off the vacuum pump.
7. Wait for 5 minutes, then check that there has been no change in system pressure.

8. If there is a change in system pressure, refer to Gas Leak Check section for information on how to check for leaks. If there is no change in system pressure, unscrew the cap from the packed valve (high pressure valve).
9. Insert hexagonal wrench into the packed valve (high pressure valve) and open the valve by turning the wrench in a 1/4 counterclockwise turn. Listen for gas to exit the system, then close the valve after 5 seconds.
10. Watch the Pressure Gauge for one minute to make sure that there is no change in pressure. The Pressure Gauge should read slightly higher than atmospheric pressure.
11. Remove the charge hose from the service port.



12. Using hexagonal wrench, fully open both the high pressure and low pressure valves.
13. Tighten valve caps on all three valves (service port, high pressure, low pressure) by hand. You may tighten it further using a torque wrench if needed.

### ! OPEN VALVE STEMS GENTLY

When opening valve stems, turn the hexagonal wrench until it hits against the stopper. Do not try to force the valve to open further.



## Note on Adding Refrigerant

Some systems require additional charging depending on line set lengths. The refrigerant should be charged from the service port on the outdoor unit's low pressure valve. The additional refrigerant required for each size unit depends on the total line length.

- Sizes 09k, 12k, 18k, 24k and 30k ship from the factory with enough charge for the indoor unit, the outdoor unit and 25' of line length.
- Size 36k ships from the factory with enough charge for the indoor unit, the outdoor unit and 15' of line length.

Additional information on total system charge for each size unit can be found in the specification sheets found on Pages 37 through 42 of this manual.



**CAUTION** DO NOT mix refrigerant types.

# Electrical and Gas Leak Checks

## Before Test Run

Only perform test run after you have completed the following steps:

- **Electrical Safety Checks** – Confirm that the unit's electrical system is safe and operating properly
- **Gas Leak Checks** – Check all flare nut connections and confirm that the system is not leaking
- Confirm that gas and liquid (high and low pressure) valves are fully open

## Electrical Safety Checks

After installation, confirm that all electrical wiring is installed in accordance with local and national regulations, and according to the Installation Manual.

### BEFORE TEST RUN

#### Check Grounding Work

Measure grounding resistance by visual detection and with grounding resistance tester. Grounding resistance must be less than  $0.1\Omega$ .

**Note:** This may not be required for some locations in North America.

### DURING TEST RUN

#### Check for Electrical Leakage

During the **Test Run**, use an electroprobe and multimeter to perform a comprehensive electrical leakage test.

If electrical leakage is detected, turn off the unit immediately and call a licensed electrician to find and resolve the cause of the leakage.

**Note:** This may not be required for some locations in North America.



## WARNING – RISK OF ELECTRIC SHOCK

**ALL WIRING MUST COMPLY WITH LOCAL AND NATIONAL ELECTRICAL CODES, AND MUST BE INSTALLED BY A LICENSED ELECTRICIAN.**

## Gas Leak Checks

There are two different methods to check for gas leaks.

### Soap and Water Method


Using a soft brush, apply soapy water or liquid detergent to all pipe connection points on the indoor unit and outdoor unit. The presence of bubbles indicates a leak.

### Leak Detector Method

If using leak detector, refer to the device's operation manual for proper usage instructions.

### AFTER PERFORMING GAS LEAK CHECKS

After confirming that all pipe connection points DO NOT leak, replace the valve cover on the outside unit.



A: Low pressure stop valve  
B: High pressure stop valve  
C & D: Indoor unit flare nuts



# Test Run

## Test Run Instructions

You should perform the **Test Run** for at least 30 minutes.

1. Connect power to the unit.
2. Press the **ON/OFF** button on the remote controller to turn it on.
3. Press the **MODE** button to scroll through the following functions, one at a time:
  - COOL – Select lowest possible temperature
  - HEAT – Select highest possible temperature
4. Let each function run for 5 minutes, and perform the following checks:

List of Checks to Perform	PASS/FAIL	
No electrical leakage		
Unit is properly grounded		
All electrical terminals properly covered		
Indoor and outdoor units are solidly installed		
All pipe connection points do not leak	Outdoor (2):	Indoor (2):
Water drains properly from drain hose		
All piping is properly insulated		
Unit performs COOL function properly		
Unit performs HEAT function properly		
Indoor unit louvers rotate properly		
Indoor unit responds to remote controller		

## DOUBLE-CHECK PIPE CONNECTIONS


During operation, the pressure of the refrigerant circuit will increase. This may reveal leaks that were not present during your initial leak check. Take time during the Test Run to double-check that all refrigerant pipe connection points do not have leaks. Refer to **Gas Leak Check** section for instructions.



5. After the Test Run is successfully completed, and you confirm that all checks points in List of Checks to Perform have PASSED, do the following:
  - a. Using remote control, return unit to normal operating temperature.
  - b. Using insulation tape, wrap the indoor refrigerant pipe connections that you left uncovered during the indoor unit installation process.

## IF AMBIENT TEMPERATURE IS BELOW 17°C (62°F)

You can't use the remote controller to turn on the COOL function when the ambient temperature is below 17°C. In this instance, you can use the **MANUAL CONTROL** button to test the COOL function.

1. Lift the front panel of the indoor unit, and raise it until it clicks in place.
2. The **MANUAL CONTROL** button is located on the right-hand side of the unit. Press it 2 times to select the COOL function.
3. Perform Test Run as normal.





NEXYA Design Specifications and Capacities*		
Model Set		OS-CSENIH09EI
Voltage (min 109, max 127) Minimum Circuit Amps Max Fuse Size	V-PH-Hz-A-A	115-1-60 -19-25
Rated Capacity for Cooling (1)	BTU/H	 9000
Rated Capacity for Heating (1)	BTU/H	 9000
Rated Power Consumption - Cooling Mode	Watts	660
Rated Power Consumption - Heating Mode	Watts	710
Energy Efficiency Ratio / Seasonal Eenergy Efficiency Ratio	EER / SEER	13.8 / 23
Coefficient of Performance	COP	4
HSPF4 / HSPF5 (Heating Seasonal Performance Factors)	BtuH/w	11 / 8.6
<b>Compressor</b> Rated Load Amps	Type	Inverter
	R.L.A.	11.5
<b>Indoor Fan</b> Full Load Amps	Type	inverter
	R.L.A.	.25
Indoor Air Volume (Cooling & Heating)	CFM (H, M, L)	300/241/176
Outdoor Fan Speeds	# of speeds	2
Outdoor Fan Airflow	CFM	794
Outdoor Sound Level	db(A)	54
Indoor Sound Level <sup>2</sup>	db(A) H/M/L	41.5/36/24
Indoor Dimensions (without packaging)	W/H/D	31.57"x7.87"x11.61"
Indoor Dimensions (with packaging)	W/H/D	34.45"x11.22"x14.96"
Outdoor Dimensions (without packaging)	W/H/D	30.12"x11.93"x21.85"
Outdoor Dimensions (with packaging)	W/H/D	34.92"x13.27"x24.02"
Indoor Weight (without packaging)	lbs	18.96
Indoor Weight (with packaging)	lbs	24.47
Outdoor Weight (without packaging)	lbs	66.8
Outdoor Weight (with packaging)	lbs	72.31
Refrigerant Type	ASHRAE #	R-410A
Refrigerant Factory Charge (3)	oz	39.5
Refrigeration Line Connection Sizes	inches	1/4" and 1/2"
Maximum Ref Line Length	Feet	82
Maximum Vertical Distance Between Indoor and Outdoor Units	Feet	33
Additional Refrigerant Charge per Foot	oz	.16
Maximum Remote Control Range	Feet	26

Design Condition Parameters*			Model Set: OS-C/SENIH09EI
<b>Indoor Temperature</b>	Max Operating Temperature in Cooling Mode (db)	°F/°C	DB 90°F/32°C
	Min Operating Temperature in Cooling Mode (db)	°F/°C	DB 61°F/16°C
	Max Operating Temperature in Heating Mode (db)	°F/°C	DB 86°F/30°C
	Min Operating Temperature in Heating Mode (db)	°F/°C	DB 32°F/0°C
<b>Outdoor Temperature</b>	Max Operating Temperature in Cooling Mode (db)	°F/°C	DB 122°F/50°C
	Min Operating Temperature in Cooling Mode (db)	°F/°C	DB -13°F/-25°C
	Max Operating Temperature in Heating Mode (db)	°F/°C	DB 75°F/24°C
	Min Operating Temperature in Heating Mode (db)	°F/°C	DB -13°F/-25°C

\*Values may change if models are revised. Always use the latest publication date for any literature.



- (1) Test condition: Data refers to conditions and parameters as required by DOE requirements governing this product type.  
 HEATING MODE: Outdoor Ambient Temperature DB 45°F/7°C WB 43°F/6°C; Indoor Ambient DB 68°F/20°C - WB 59°F/15°C  
 COOLING MODE: Outdoor Ambient Temperature DB 95°F/35°C WB 75°F/24°C; Indoor Ambient DB 81°F/27°C - WB 66°F/19°C
- (2) Test conditions for sound ratings are conducted as per DOA rating conditions, conducted in a sound chamber performed at a distance of 3.3 feet (1 meter). Minimum sound pressure values are rated in ventilation mode only.
- (3) Total factory charge includes indoor unit, outdoor unit and 25 feet of line length.

NEXYA Design Specifications and Capacities*		
Model Set		OS-CSENIH12EI
Voltage (min 109, max 127) Minimum Circuit Amps Max Fuse Size	V-PH-Hz-A-A	115-1-60 -19-25
Rated Capacity for Cooling (1)	BTU/H	 12,000
Rated Capacity for Heating (1)	BTU/H	 12,000
Rated Power Consumption - Cooling Mode	Watts	960
Rated Power Consumption - Heating Mode	Watts	1000
Energy Efficiency Ratio / Seasonal Eenergy Efficiency Ratio	EER / SEER	12.5 / 22
Coefficient of Performance	COP	3.52
HSPF4 / HSPF5 (Heating Seasonal Performance Factors)	BtuH/w	11.5 / 9.8
<b>Compressor</b>	Type	Inverter
Rated Load Amps	R.L.A.	11.5
<b>Indoor Fan</b>	Type	inverter
Full Load Amps	R.L.A.	.25
Indoor Air Volume (Cooling & Heating)	CFM (H, M, L)	300/241/176
Outdoor Fan Speeds	# of speeds	2
Outdoor Fan Airflow	CFM	794
Outdoor Sound Level	db(A)	54
Indoor Sound Level <sup>2</sup>	db(A) H/M/L	41.5/36/24
Indoor Dimensions (without packaging)	W/H/D	31.57"x7.87"x11.61"
Indoor Dimensions (with packaging)	W/H/D	34.45"x11.22"x14.96"
Outdoor Dimensions (without packaging)	W/H/D	30.12"x11.93"x21.85"
Outdoor Dimensions (with packaging)	W/H/D	34.92"x13.27"x24.02"
Indoor Weight (without packaging)	lbs	18.96
Indoor Weight (with packaging)	lbs	24.47
Outdoor Weight (without packaging)	lbs	66.8
Outdoor Weight (with packaging)	lbs	72.31
Refrigerant Type	ASHRAE #	R-410A
Refrigerant Factory Charge (3)	oz	39.5
Refrigeration Line Connection Sizes	inches	1/4" and 1/2"
Maximum Ref Line Length	Feet	82
Maximum Vertical Distance Between Indoor and Outdoor Units	Feet	33
Additional Refrigerant Charge per Foot	oz	.16
Maximum Remote Control Range	Feet	26

Design Condition Parameters*			Model Set: OS-C/SENIH12EI
Indoor Temperature	Max Operating Temperature in Cooling Mode (db)	°F/°C	DB 90°F/32°C
	Min Operating Temperature in Cooling Mode (db)	°F/°C	DB 61°F/16°C
	Max Operating Temperature in Heating Mode (db)	°F/°C	DB 86°F/30°C
	Min Operating Temperature in Heating Mode (db)	°F/°C	DB 32°F/0°C
Outdoor Temperature	Max Operating Temperature in Cooling Mode (db)	°F/°C	DB 122°F/50°C
	Min Operating Temperature in Cooling Mode (db)	°F/°C	DB -13°F/-25°C
	Max Operating Temperature in Heating Mode (db)	°F/°C	DB 75°F/24°C
	Min Operating Temperature in Heating Mode (db)	°F/°C	DB -13°F/-25°C

\*Values may change if models are revised. Always use the latest publication date for any literature.



- (1) Test condition: Data refers to conditions and parameters as required by DOE requirements governing this product type.  
HEATING MODE: Outdoor Ambient Temperature DB 45°F/7°C WB 43°F/6°C; Indoor Ambient DB 68°F/20°C - WB 59°F/15°C  
COOLING MODE: Outdoor Ambient Temperature DB 95°F/35°C WB 75°F/24°C; Indoor Ambient DB 81°F/27°C - WB 66°F/19
- (2) Test conditions for sound ratings are conducted as per DOA rating conditions, conducted in a sound chamber performed at a distance of 3.3 feet (1 meter). Minimum sound pressure values are rated in ventilation mode only.
- (3) Total factory charge includes indoor unit, outdoor unit and 25 feet of line length.

NEXYA Design Specifications and Capacities*		
Model Set		OS-CSENIH18EI
Voltage (min 188, max 253) Minimum Circuit Amps Max Fuse Size	V-PH-Hz-A-A	208/230-1-60 -17-25
Rated Capacity for Cooling (1)	BTU/H	 18,000
Rated Capacity for Heating (1)	BTU/H	 18,000
Rated Power Consumption - Cooling Mode	Watts	1333
Rated Power Consumption - Heating Mode	Watts	1410
Energy Efficiency Ratio / Seasonal Eenergy Efficiency Ratio	EER / SEER	13.5 / 24
Coefficient of Performance	COP	3.74
HSPF4 / HSPF5 (Heating Seasonal Performance Factors)	BtuH/w	11.6 / 9.4
<b>Compressor</b>	Type	Inverter
Rated Load Amps	R.L.A.	12
<b>Indoor Fan</b>	Type	inverter
Full Load Amps	R.L.A.	.25
Indoor Air Volume (Cooling & Heating)	CFM (H, M, L)	531/459/382
Outdoor Fan Speeds	# of speeds	2
Outdoor Fan Airflow	CFM	1765
Outdoor Sound Level	db(A)	60
Indoor Sound Level <sup>2</sup>	db(A) H/M/L	45.5/41/24.5
Indoor Dimensions (without packaging)	W/H/D	42.64"x9.61"x13.23"
Indoor Dimensions (with packaging)	W/H/D	45.47"x16.34"x12.4"
Outdoor Dimensions (without packaging)	W/H/D	35.04"x13.46"x26.5"
Outdoor Dimensions (with packaging)	W/H/D	39.17"x15.67"x29.13"
Indoor Weight (without packaging)	lbs	29.54
Indoor Weight (with packaging)	lbs	37.48
Outdoor Weight (without packaging)	lbs	95.02
Outdoor Weight (with packaging)	lbs	101.85
Refrigerant Type	ASHRAE #	R-410A
Refrigerant Factory Charge (3)	oz	56.5
Refrigeration Line Connection Sizes	inches	1/4" and 1/2"
Maximum Ref Line Length	Feet	98
Maximum Vertical Distance Between Indoor and Outdoor Units	Feet	66
Additional Refrigerant Charge per Foot	oz	.16
Maximum Remote Control Range	Feet	26

Design Condition Parameters*			Model Set: OS-C/SENIH18EI
<b>Indoor Temperature</b>	Max Operating Temperature in Cooling Mode (db)	°F/°C	DB 90°F/32°C
	Min Operating Temperature in Cooling Mode (db)	°F/°C	DB 61°F/16°C
	Max Operating Temperature in Heating Mode (db)	°F/°C	DB 86°F/30°C
	Min Operating Temperature in Heating Mode (db)	°F/°C	DB 32°F/0°C
<b>Outdoor Temperature</b>	Max Operating Temperature in Cooling Mode (db)	°F/°C	DB 122°F/50°C
	Min Operating Temperature in Cooling Mode (db)	°F/°C	DB -22°F/-30°C
	Max Operating Temperature in Heating Mode (db)	°F/°C	DB 75°F/24°C
	Min Operating Temperature in Heating Mode (db)	°F/°C	DB -22°F/-30°C

\*Values may change if models are revised. Always use the latest publication date for any literature.



- (1) Test condition: Data refers to conditions and parameters as required by DOE requirements governing this product type.  
 HEATING MODE: Outdoor Ambient Temperature DB 45°F/7°C WB 43°F/6°C; Indoor Ambient DB 68°F/20°C - WB 59°F/15°C  
 COOLING MODE: Outdoor Ambient Temperature DB 95°F/35°C WB 75°F/24°C; Indoor Ambient DB 81°F/27°C - WB 66°F/19
- (2) Test conditions for sound ratings are conducted as per DOA rating conditions, conducted in a sound chamber performed at a distance of 3.3 feet (1 meter). Minimum sound pressure values are rated in ventilation mode only.
- (3) Total factory charge includes indoor unit, outdoor unit and 25 feet of line length.

NEXYA Design Specifications and Capacities*		
Model Set		OS-CSENIH24EI
Voltage (min 188, max 253) Minimum Circuit Amps Max Fuse Size	V-PH-Hz-A-A	208/230-1-60 -22-30
Rated Capacity for Cooling (1)	BTU/H	 24,000
Rated Capacity for Heating (1)	BTU/H	 26,000
Rated Power Consumption - Cooling Mode	Watts	1845
Rated Power Consumption - Heating Mode	Watts	2420
Energy Efficiency Ratio / Seasonal Eenergy Efficiency Ratio	EER / SEER	13/ 21
Coefficient of Performance	COP	3.15
HSPF4 / HSPF5 (Heating Seasonal Performance Factors)	BtuH/w	10 /8.5
<b>Compressor</b> Rated Load Amps	Type	Inverter
	R.L.A.	15.4
<b>Indoor Fan</b> Full Load Amps	Type	inverter
	R.L.A.	.38
Indoor Air Volume (Cooling & Heating)	CFM (H, M, L)	601/459/382
Outdoor Fan Speeds	# of speeds	4
Outdoor Fan Airflow	CFM	2235
Outdoor Sound Level	db(A)	62
Indoor Sound Level <sup>2</sup>	db(A) H/M/L	48/40/28
Indoor Dimensions (without packaging)	W/H/D	42.6"x9.21"x13.27"
Indoor Dimensions (with packaging)	W/H/D	45.47"x16.34"x12.4"
Outdoor Dimensions (without packaging)	W/H/D	42.91"x19.69"x34.84"
Outdoor Dimensions (with packaging)	W/H/D	39.17"x15.67"x29.13"
Indoor Weight (without packaging)	lbs	29.98
Indoor Weight (with packaging)	lbs	38.14
Outdoor Weight (without packaging)	lbs	124.78
Outdoor Weight (with packaging)	lbs	134.92
Refrigerant Type	ASHRAE #	R-410A
Refrigerant Factory Charge (3)	oz	83
Refrigeration Line Connection Sizes	inches	3/8" and 3/4"
Maximum Ref Line Length	Feet	164
Maximum Vertical Distance Between Indoor and Outdoor Units	Feet	82
Additional Refrigerant Charge per Foot	oz	.32
Maximum Remote Control Range	Feet	26

Design Condition Parameters*			Model Set: OS-C/SENIH24EI
<b>Indoor Temperature</b>	Max Operating Temperature in Cooling Mode (db)	°F/°C	DB 90°F/32°C
	Min Operating Temperature in Cooling Mode (db)	°F/°C	DB 63°F/17°C
	Max Operating Temperature in Heating Mode (db)	°F/°C	DB 86°F/30°C
	Min Operating Temperature in Heating Mode (db)	°F/°C	DB 32°F/0°C
<b>Outdoor Temperature</b>	Max Operating Temperature in Cooling Mode (db)	°F/°C	DB 122°F/50°C
	Min Operating Temperature in Cooling Mode (db)	°F/°C	DB -22°F/-30°C
	Max Operating Temperature in Heating Mode (db)	°F/°C	DB 75°F/24°C
	Min Operating Temperature in Heating Mode (db)	°F/°C	DB -22°F/-30°C

\*Values may change if models are revised. Always use the latest publication date for any literature.



- (1) Test condition: Data refers to conditions and parameters as required by DOE requirements governing this product type.  
HEATING MODE: Outdoor Ambient Temperature DB 45°F/7°C WB 43°F/6°C; Indoor Ambient DB 68°F/20°C - WB 59°F/15°C  
COOLING MODE: Outdoor Ambient Temperature DB 95°F/35°C WB 75°F/24°C; Indoor Ambient DB 81°F/27°C - WB 66°F/19
- (2) Test conditions for sound ratings are conducted as per DOA rating conditions, conducted in a sound chamber performed at a distance of 3.3 feet (1 meter). Minimum sound pressure values are rated in ventilation mode only.
- (3) Total factory charge includes indoor unit, outdoor unit and 25 feet of line length.

NEXYA Design Specifications and Capacities*		
Model Set		OS-CSENIH30EI
Voltage (min 188, max 253) Minimum Circuit Amps Max Fuse Size	V-PH-Hz-A-A	208/230-1-60 -23-30
Rated Capacity for Cooling (1)	BTU/H	 30,000
Rated Capacity for Heating (1)	BTU/H	 30,000
Rated Power Consumption - Cooling Mode	Watts	2855
Rated Power Consumption - Heating Mode	Watts	3250
Energy Efficiency Ratio / Seasonal Eenergy Efficiency Ratio	EER / SEER	10.5/18.6
Coefficient of Performance	COP	2.71
HSPF4 / HSPF5 (Heating Seasonal Performance Factors)	BtuH/w	9.5/7.7
<b>Compressor</b>	Type	Inverter
Rated Load Amps	R.L.A.	15
<b>Indoor Fan</b>	Type	inverter
Full Load Amps	R.L.A.	.38 0
Indoor Air Volume (Cooling & Heating)	CFM (H, M, L)	794/618/471
Outdoor Fan Speeds	# of speeds	2
Outdoor Fan Airflow (max)	CFM	2235
Outdoor Sound Level	db(A)	60
Indoor Sound Level <sup>2</sup>	db(A) H/M/L	51.5/47.5/44
Indoor Dimensions (without packaging)	W/H/D	49.57"x11.1"x14.25"
Indoor Dimensions (with packaging)	W/H/D	52.76"x17.72"x15.16"
Outdoor Dimensions (without packaging)	W/H/D	37.24"x16.14"x31.89"
Outdoor Dimensions (with packaging)	W/H/D	42.91"x19.69"x34.84"
Indoor Weight (without packaging)	lbs	37.48
Indoor Weight (with packaging)	lbs	50.49
Outdoor Weight (without packaging)	lbs	141.76
Outdoor Weight (with packaging)	lbs	151.90
Refrigerant Type	ASHRAE #	R-410A
Refrigerant Factory Charge (3)	oz	97
Refrigeration Line Connection Sizes	inches	3/8" and 5/8"
Maximum Ref Line Length	Feet	164
Maximum Vertical Distance Between Indoor and Outdoor Units	Feet	82
Additional Refrigerant Charge per Foot	oz	.32
Maximum Remote Control Range	Feet	26

Design Condition Parameters*			Model Set: OS-C/SENIH30EI
Indoor Temperature	Max Operating Temperature in Cooling Mode (db)	°F/°C	DB 90°F/32°C
	Min Operating Temperature in Cooling Mode (db)	°F/°C	DB 63°F/17°C
	Max Operating Temperature in Heating Mode (db)	°F/°C	DB 86°F/30°C
	Min Operating Temperature in Heating Mode (db)	°F/°C	DB 32°F/0°C
Outdoor Temperature	Max Operating Temperature in Cooling Mode (db)	°F/°C	DB 122°F/50°C
	Min Operating Temperature in Cooling Mode (db)	°F/°C	DB 5°F/-15°C
	Max Operating Temperature in Heating Mode (db)	°F/°C	DB 86°F/30°C
	Min Operating Temperature in Heating Mode (db)	°F/°C	DB 5°F/-15°C

\*Values may change if models are revised. Always use the latest publication date for any literature.

- Test condition: Data refers to conditions and parameters as required by DOE requirements governing this product type.  
 HEATING MODE: Outdoor Ambient Temperature DB 45°F/7°C WB 43°F/6°C; Indoor Ambient DB 68°F/20°C - WB 59°F/15°C  
 COOLING MODE: Outdoor Ambient Temperature DB 95°F/35°C WB 75°F/24°C; Indoor Ambient DB 81°F/27°C - WB 66°F/19°C
- Test conditions for sound ratings are conducted as per DOA rating conditions, conducted in a sound chamber performed at a distance of 3.3 feet (1 meter). Minimum sound pressure values are rated in ventilation mode only.
- Total factory charge includes indoor unit, outdoor unit and 25 feet of line length.

NEXYA Design Specifications and Capacities*		
Model Set		OS-CSENIH36EI
Voltage (min 188, max 253) Minimum Circuit Amps Max Fuse Size	V-PH-Hz-A-A	208/230-1-60 -28-35
Rated Capacity for Cooling (1)	BTU/H	 36,000
Rated Capacity for Heating (1)	BTU/H	 36,000
Rated Power Consumption - Cooling Mode	Watts	4256
Rated Power Consumption - Heating Mode	Watts	4270
Energy Efficiency Ratio / Seasonal Eenergy Efficiency Ratio	EER / SEER	8.5/17.5
Coefficient of Performance	COP	2.47
HSPF4 / HSPF5 (Heating Seasonal Performance Factors)	BtuH/w	12/8
<b>Compressor</b>	Type	Inverter
Rated Load Amps	R.L.A.	18
<b>Indoor Fan</b>	Type	inverter
Full Load Amps	R.L.A.	.5
Indoor Air Volume (Cooling & Heating)	CFM (H, M, L)	732/518/400
Outdoor Fan Speeds	# of speeds	4
Outdoor Fan Airflow	CFM	2235
Outdoor Sound Level	db(A)	63.5
Indoor Sound Level <sup>2</sup>	db(A) H/M/L	56.5/54.5/40
Indoor Dimensions (without packaging)	W/H/D	49.57"x11.1"x14.25"
Indoor Dimensions (with packaging)	W/H/D	52.76"x17.72"x15.16"
Outdoor Dimensions (without packaging)	W/H/D	37.24"x16.14"x31.89"
Outdoor Dimensions (with packaging)	W/H/D	42.91"x19.69"x34.84"
Indoor Weight (without packaging)	lbs	40.34
Indoor Weight (with packaging)	lbs	52.69
Outdoor Weight (without packaging)	lbs	150.13
Outdoor Weight (with packaging)	lbs	158.95
Refrigerant Type	ASHRAE #	R-410A
Refrigerant Factory Charge (3)	oz	120
Refrigeration Line Connection Sizes	inches	3/8" and 5/8"
Maximum Ref Line Length	Feet	213
Maximum Vertical Distance Between Indoor and Outdoor Units	Feet	98
Additional Refrigerant Charge per Foot	oz	.32
Maximum Remote Control Range	Feet	26

Design Condition Parameters*			Model Set: OS-C/SENIH36EI
Indoor Temperature	Max Operating Temperature in Cooling Mode (db)	°F/°C	DB 90°F/32°C
	Min Operating Temperature in Cooling Mode (db)	°F/°C	DB 63°F/17°C
	Max Operating Temperature in Heating Mode (db)	°F/°C	DB 86°F/30°C
	Min Operating Temperature in Heating Mode (db)	°F/°C	DB 32°F/0°C
Outdoor Temperature	Max Operating Temperature in Cooling Mode (db)	°F/°C	DB 122°F/50°C
	Min Operating Temperature in Cooling Mode (db)	°F/°C	DB -22°F/-30°C
	Max Operating Temperature in Heating Mode (db)	°F/°C	DB 86°F/30°C
	Min Operating Temperature in Heating Mode (db)	°F/°C	DB -22°F/-30°C

\*Values may change if models are revised. Always use the latest publication date for any literature.

- Test condition: Data refers to conditions and parameters as required by DOE requirements governing this product type.  
 HEATING MODE: Outdoor Ambient Temperature DB 45°F/7°C WB 43°F/6°C; Indoor Ambient DB 68°F/20°C - WB 59°F/15°C  
 COOLING MODE: Outdoor Ambient Temperature DB 95°F/35°C WB 75°F/24°C; Indoor Ambient DB 81°F/27°C - WB 66°F/19°C
- Test conditions for sound ratings are conducted as per DOA rating conditions, conducted in a sound chamber performed at a distance of 3.3 feet (1 meter). Minimum sound pressure values are rated in ventilation mode only.
- Total factory charge includes indoor unit, outdoor unit and 15 feet of line length.



## Startup and Troubleshooting Data Sheet

Outdoor Model # \_\_\_\_\_ Serial # \_\_\_\_\_  
Indoor Model # \_\_\_\_\_ Serial # \_\_\_\_\_  
Unit Owner \_\_\_\_\_ Phone # \_\_\_\_\_ Start Up Date \_\_\_\_\_  
Owner Address 1 \_\_\_\_\_ Address 2 \_\_\_\_\_  
City or Province \_\_\_\_\_ State \_\_\_\_\_ Zip Code \_\_\_\_\_  
Installing Contractor \_\_\_\_\_ Phone # \_\_\_\_\_  
Technician Name \_\_\_\_\_ Phone # \_\_\_\_\_

- ☐ Prior to Install verify model number to insure proper unit selection
- ☐ Prior to Starting the unit verify Supply Voltage to the unit \_\_\_\_\_
- ☐ Install batteries in Remote Control
- ☐ Start Unit to verify operation and record requested values below

The following values are to be recorded after the unit has run a minimum of 10 minutes to insure stabilized operation at high airflow and full compressor operation

- ☐ Cooling Mode return air Db° \_\_\_\_\_ Wb° \_\_\_\_\_ Supply Air Db° \_\_\_\_\_ Wb° \_\_\_\_\_ Outside Air Db° \_\_\_\_\_
- ☐ On Heat Pump Models Only: Heating Mode Return air Db° \_\_\_\_\_ Supply Air Db° \_\_\_\_\_
- ☐ Operating Voltage \_\_\_\_\_ Operating Amps \_\_\_\_\_

After Test Running the unit and recording the data requested above:

- ☐ Provide unit owner with information packet
- ☐ Explain remote control
- ☐ Explain unit operation

## CUSTOMER SERVICE

*It means the world to us because customers are our world*

OLIMPIA SPLENDID USA  
870 International Parkway  
Suite 120  
Flower Mound, TX 75022

Phone: (800) 408-5196

Technical data and aesthetic characteristics of the products may change. Olimpia Splendid reserves the right to change them at any moment without notice

