oraimo

WELCOME GUIDE

* Please read the instructions carefully before using the product and keep the user manual in a safe place for future reference.

SmartAirFryer

| OH-AF210N |

المحتويات

محتويات العبوة 1
نظرة عامة على المنتج 1
مواصفات المنتج الأساسية 1
استخدام مقلاة الهواء خاصتك 2
تنظيف المقلاة الهوائية 3
تعليمات الأمان 4
محتويات العبوة 5
شهادة ضمان 5
بنود وشروط الضمان 5

محتويات العبوة

مقلاة هوائية ×1

الدليل الترحيبي ×1

نظرة عامة على المنتج

مواصفات المنتج الأساسية

الحجم: 28.5*26*34.5 سم

المادة (سلة القلي): لوح مكوف على البارد + طلاء وعاء غير لاصق

المادة (مقلاة الشواية): لوح مطلي بالألمنيوم + طلاء وعاء غير لاصق

الوزن: 3.9 كجم ± 3%

نوع قابس الطاقة المملكة المتحدة

التحكم في درجة الحرارة: 90 - 200 درجة مئوية، مع تفاوت في درجة الحرارة < 15 درجة

الجهد المدخل: 220 - 240 فولت ~ 60/50 هرتز

تقدير الطاقة: 1500 واط

1

استخدام مقلاة الهواء خاصتك

1. ضع المقلاة الهوائية فوق سطح ثابت مستطح ومستوٍ لضمان السلامة والتشغيل الصحيح.
2. قم بتوصيل المقلاة الهوائية بمأخذ الطاقة، مع ضمان وجود مسافة 15 سم على الأقل بين فتحة تهوية المقلاة الهوائية وأي جدران لتسهيل تدفق الهواء.
3. أدخل مقلاة الشواية بشكل صحيح في المقلاة.

4. أضف المكونات المجهزة إلى سلة القلي.

(1) احرص على عدم ملء المقلاة بأكثر من سعتها الموصى بها.

(2) بالنسبة للمكونات التي تنتفخ أو تتمدد عند التسخين، ضع في اعتبارك زيادة حجمها بعد التسخين عند القياس.

5. أدخل سلة القلي في المقلاة الهوائية، مع التأكد من إدخالها بشكل كامل.
6. أدر الموقت ومقبض التحكم بدرجة الحرارة للوقت المطلوب وفقًا للمكونات.

2

تنظيف المقلاة الهوائية

1. قم بفصل قابس هذا الجهاز دائمًا قبل التنظيف.
2. تأكد من تبريد المقلاة الهوائية قبل تنظيفها.
3. ليست هناك حاجة لاستخدام أدوات المطبخ المعدنية أو مواد التنظيف الكاشطة لتنظيف سلة القلي أو مقلاة الشوي، لأن ذلك قد يؤدي إلى تلف الطلاء الذي لا يلتصق به الطعام.
4. امسح جسم المقلاة الهوائية بقطعة قماش مبللة.
5. قم بتنظيف صينية الشواية وسلة القلي بالماء الساخن والقليل من سائل الصحون وإسفنجة غير كاشطة.
6. بعد تجفيف جميع المكونات جيدًا، أعد تجميعها وقم بتخزين الجهاز للاستخدام المستقبلي.

3

تعليمات الأمان

1. تأكد من أن جهد مأخذ الطاقة الخاص بك يطابق الجهد الموضح على ملصق تصنيف الجهاز.
2. لمنع نشوب حريق أو صدمة كهربائية أو إصابة شخصية، لا تغمر السلك أو القابس أو الجهاز في الماء أو أي سائل آخر.
3. تأكد من مراقبة الأطفال لضمهم من اللعب بالجهاز.
4. افصل الجهاز عن مأخذ الطاقة عند عدم استخدامه أو قبل التنظيف. اترك الجهاز يبرد قبل تركيب الأجزاء أو إزالتها وقبل التنظيف.
5. لا تقم بتشغيل الجهاز إذا كان به سلك أو قابس تالف، أو إذا كان لا يعمل بشكل صحيح، أو إذا تعرض للتلف بأي شكل من الأشكال. أرسله إلى مركز خدمة معتمد للفحص أو الإصلاح أو الضبط.
6. قد يؤدي استخدام الملحقات غير الموصى بها من قبل الشركة المصنعة إلى حدوث حريق أو صدمة كهربائية أو إصابة.
7. تم تصميم هذا الجهاز للاستخدام المنزلي فقط. غير مخصص للاستخدام خارج المنزل.
8. أبق السلك بعيدًا عن الحواف الحادة أو الأسطح الساخنة.
9. ضع الجهاز بعيدًا عن المواد القابلة للاشتعال مثل مفارش المائدة أو الستائر لتجنب خطر نشوب حريق.
10. استخدم الجهاز فقط للأغراض المخصصة له كما هو موضح في هذا الدليل.
11. نظرًا لأن هذا جهاز تسخين، استخدمه على سطح مستوٍ ومستقر ومقاوم للحرارة. تجنب وضعه على أسطح مثل الإسفنج أو الفينيل أو البيتا التي يمكن أن تتلف بسهولة بفعل الحرارة.
12. تأكد من جفاف صينية الشواية وسلة القلي قبل إضافة المكونات.
13. بعد الاستخدام، افصل الجهاز عن القابس واضبط التحكم في درجة الحرارة ومقابض الموقت على وضع "إيقاف التشغيل".
14. قد تصبح بعض أجزاء الجهاز، مثل مقلاة الشواية وسلة القلي، ساخنة أثناء الاستخدام. استخدم المقبض دائمًا لتجنب الحروق.
15. كن حذرًا من البخار الساخن المنبعث من فتحات مخرج الهواء أثناء الطهي وبعده. أبق يديك ووجهك على مسافة آمنة، وكن حذرًا عند إزالة المقلاة.
16. لا يُسمح بالتوصيل بأسلاك التيار الكهربائي الخارجية الرئيسية.

4

CONTENTS

Package Contents 1
Product Overview 1
Basic Product Specifications 1
Using Your Air Fryer 2
Clean the Air Fryer 3
Safety Instructions 4
Package Contents 5
Warranty Certificate 5
Warranty Terms & Conditions 5

Package Contents

Air Fryer x1

Welcome Guide x1

Product Overview

Basic Product Specifications

Size: 34.5*26*28.5cm

Material(Frying Basket): cold-rolled sheet+non-stick pot coating

Material(Grill Pan): Aluminum plated plate+non-stick pot coating

Weight: 3.9KGS±3%

Power Plug Type: UK

Temperature Control: 90-200 ℃, with a temperature difference of<15 degrees

Input Voltage: 220-240V~50/60Hz

Power Rating: 1500W

1

Using Your Air Fryer

1. Position the air fryer on a stable, flat, and level surface to ensure safety and proper operation.
2. Connect the air fryer to a power outlet, ensuring at least 15 cm of clearance between the air fryer's ventilation opening and any walls to facilitate airflow.
3. Insert the grill pan correctly into the frying pan.

4. Add the prepared ingredient into the frying basket.

(1) Take care not to overfill the pan beyond its recommended capacity.

(2) For ingredients that swell or expand upon heating, consider their increased volume after heating when measuring.

5. Slide the frying basket into the air fryer, ensuring it is inserted completely.
6. Turn the timer and temperature control knob to the required time according to the ingredients.

2

(1) The timer dial features settings from 0 to 30 minutes for precise cooking control.

(2) The temperature adjustment dial ranges from OFF to settings between 90 and 200 degrees Celsius, with 200 degrees being the maximum achievable temperature.

(3) Both the timer and temperature dials increase their respective settings when turned clockwise, reaching their highest values at the end of the scale.

(4) Ensure the frying basket is fully inserted into the air fryer to guarantee proper function.

(5) For optimal performance, especially when starting with a cold air fryer, it is recommended to preheat the air fryer for 3 minutes.

7. The indicator light is on, and the air fryer starts working.
8. Once the timer bell sounds, indicating that the set cooking time has elapsed, the indicator light will turn off. At this point, carefully pull the ingredient out of the appliance.

The frying basket and the ingredients are hot. Be carefull

Clean the Air Fryer

1. Always unplug this appliance before cleaning.
2. Make sure the air fryer has cooled down before cleaning.
3. There is no need to use the metal kitchen utensils or abrasive cleaning materials to clean the frying basket or grill pan, as this may damage the non-stick coating.
4. Wipe the body of the air fryer with a moist cloth.
5. Clean the grill pan and the frying basket with hot water, some washing-up liquid, and a non-abrasive sponge.
6. After all components have been thoroughly dried, reassemble them and store the appliance for future use.

3

Safety Instructions

1. Verify that the voltage of your power outlet matches the voltage indicated on the appliance's rating label.
2. To prevent fire, electric shock, and personal injury, do not submerge the cord, plug, or appliance in water or any other liquid.
3. Ensure children are supervised to prevent them from playing with the appliance.
4. Disconnect the appliance from the power outlet when not in use or prior to cleaning. Allow it to cool before attaching or removing parts and before cleaning.
5. Do not operate the appliance if it has a damaged cord or plug, if it is not functioning properly, or if it has been damaged in any way. Send it to an authorized service center for inspection, repair, or adjustment.
6. Using accessories not recommended by the manufacturer may cause fire, electric shock, or injury.
7. This appliance is designed for household use only. It is not intended for outdoor use.
8. Keep the cord away from sharp edges or hot surfaces.
9. Place the appliance away from flammable materials such as tablecloths or curtains to prevent the risk of fire.
10. Only use the appliance for its intended purposes as described in this manual.
11. As this is a heating appliance, use it on a flat, stable, and heat-resistant surface. Avoid placing it on surfaces like plastic, vinyl, or enamel that can easily be damaged by heat.
12. Ensure the grill pan and frying basket are dry before adding ingredients.
13. After use, unplug the appliance and set the temperature control and timer knobs to the 'off' position.
14. Some parts of the appliance, such as the grill pan and frying basket, will become hot during use. Always use the handle to avoid burns.
15. Be cautious of hot steam from the air outlet openings during and after cooking. Keep hands and face at a safe distance, and be careful when removing the pan.
16. Connection to external mains cords is not permitted.

4

www.oraimo.com

oraimo accessories

Keep Exploring