

OMEXCO  
Fine Belgian Wallcoverings



HANGING INSTRUCTIONS [B]

---

**IMPORTANT**

The wallcovering can be installed vertically or horizontally. For a horizontal hanging, first draw a vertical line with the help of a plumb line. Then measure from the ceiling a distance which is 5 cm (2 inches) shorter than the width of the wallcovering and mark that place. With a set square, draw a horizontal line, which will serve as a guideline during the hanging.

