

Fitting Instructions - Universal

Plass4 Universal Fittings



Prepare the pipe by removing any unsound material adhering to the pipe then cut and de-burr pipe as necessary.



Slide the universal end of the fitting onto the pipe end until it reaches the internal fins and a resistant point is felt. **NOTE:** DO NOT force pipe end past the internal fins as this may impair joint.



Tighten the black nut using a PLASSON wrench or similar. Assemble the Metric PE joint as per the standard fitting instructions.

Note: If reusing the fitting, ensure the metal teeth are located in the grip ring, and the pipe end does not pass the location of the internal fins.

Slide N' Seal Universal Slip Coupler



Mark pipe insertion depth. (approximately half the fitting length). Undo nuts 1 to 2 turns while ensuring they remain on the fitting.



Insert each pipe to the marking.



Tighten each nut firmly with a Plasson wrench while holding the body with another wrench. The threads should no longer be visible.

Pushfit Universal



Prepare the pipe by removing any unsound material adhering to the pipe then cut and de-burr pipe as necessary.



Push the pipe into the fitting up to the internal stop.



Tighten firmly using a PLASSON wrench or similar.