

NEAT- QUICK MOUNT

FORD RANGER WILDTRACK 2026- TWIN
84122-1

INCLUDED IN THE KIT

- 4x Grille mounting brackets
- 4x Screws
- 4x M8x10mm Stainless bolt
- 1x Fitting instructions.

TOOLS REQUIRED



INSTALLATION PROCESS



SE

- 1 Montera QUICK MOUNT-fästena på rampen med bifogade skruvar (M8x10mm). Använd gänglåsning (Loctite 222). Observera att varje fäste är märkt med L1, L2, R1 eller R2 och placeras enligt markeringar på bilden.
- 2 Montera rampen i grillen och säkerställ att den klickar fast.
- 3 Borra hål för låsskruvarna (3,5mm).
- 4 Skruva i låsskruvarna för hand, Ej med skruvdragare. Använd 25mm skruv i ytterkant och 13mm skruv närmast emblemet.
- 5 QUICK MOUNT är nu monterat.

EN

- 1 Mount the QUICK MOUNT brackets onto the lightbar using the supplied screws (M8x10mm). Use thread locker (Loctite 222). Ensure each bracket is installed according to the markings L1, L2, R1 or R2 and should be placed according to the markings in the picture.
- 2 Install the lightbar into the grille and ensure it clicks into place.
- 3 Drill holes for the locking screws (3,5mm)
- 4 Tighten the locking screws by hand, Not with an electric screwdriver. Use 25mm screws on the outer edge and 13mm screws nearest the emblem.
- 5 QUICK MOUNT is now mounted.