

NEAT- SMART MOUNT

PEUGEOT BOXER, FIAT DUCATO, CITROËN JUMPER,
OPEL MOVANO, TOYOTA PROACE MAX 2025+
83580-1

INCLUDED IN THE KIT

- 2x Grille mounting brackets
- 2x Cutter template
- 4x M6x25mm Stainless bolt
- 4x M6 Stainless nut
- 4x M6 Stainless washer
- 2x M8x10mm Stainless bolt
- 1x Fitting instructions.

TOOLS REQUIRED



INSTALLATION PROCESS



SE

- 1 Använd de bifogade mallarna för att borra hål där skruvarna ska monteras (6,5MM) och märka ut var ribban i grillen ska kapas.
- 2 Skär ut enligt markeringarna.
- 3 Montera framsidorna av SMART MOUNT-fästena på rampen med bifogade skruvar (M8x10). Observera att varje fäste är märkt med L & R räknat i bilens färdriktning. Använd gänglåsning (Loctite 222)
- 4 Placera rampen ihop med fästet mot stötfångaren och placera baksidorna märkta med LB & RB på baksidan av stötfångaren.
- 5 Använd de bifogade skruvarna (M6x20mm) för att klämma åt genom stötfångaren. Skruva åt med handverktyg, Ej med skruvdragare. Montera debifogade täcklocken för skruvarna.
- 6 SMART MOUNT är nu monterat.

EN

- 1 Use the attached templates to drill holes where the screws will be mounted (6,5MM) and mark where the lath in the grill should be cut.
- 2 Cut the grille according to the markings.
- 3 Mount the front side of the SMART MOUNT brackets to the lighthbar with the attached screws (M8x10). Note that each bracket is labeled with L & R counted in the direction of the car's travel. Use thread locker (Loctite 222)
- 4 Assemble the lightbar together with the brackets against the bumper and place the back sides marked with LB & RB on the back of the bumper.
- 5 Use the attached screws (M6x25mm) to clamp through the bumper. Tighten with hand tools, Not with power tools. Mount the attached cover caps for the screws.
- 6 SMART MOUNT is now mounted.