

# SHELLY

---



3-14 years  
HEIGHT 98-158 cm  
(38.5"-62.25")

---

DIFFICULTY



ADVANCED

# I M P O R T A N T !

The contents of this pattern are copyright protected and belong exclusively to VikiSews. You may use VikiSews patterns for personal use. It is prohibited to share VikiSews patterns and instructions with third parties, as well as to publish patterns and instructions online for public access. According to part 1 of clause 1252 and clause 1301 of the Civil Code of the Russian Federation, failure to comply with the mentioned rules constitutes a breach of the legislation in force in the field of copyright and entails liability of the violator. Illegal use or distribution will be prosecuted in accordance with legislation.

You may use VikiSews patterns for commercial use, to sew custom-made garments and/or create fashion collections, on the condition that the patterns are solely used in a manufacturing setting and are not further shared with individuals.

## S H E L L Y

#vikisews

### PATTERN DESCRIPTION

*Shelly is a loose-fitting single-breasted coat with a straight cut. It features a detachable hood and front patch pockets with pointed flaps that fasten with a button and buttonhole. The back features a yoke with a decorative button tab at the center. The coat has a drop shoulder and long, shirt-style, two-piece sleeves embellished with a tab at the hem, which fastens with a button and buttonhole. There are inseam pockets in the side seams and short slits at the hem. The coat has a turn-down collar with a collar stand and a center front button closure. The coat hem is curved and is longer at the back. Decorative topstitching accentuates the pocket flaps, sleeve tabs, back yoke tab, collar, yoke, inseam pocket openings, front edge, as well as garment hem and slits. The coat is fully lined and is below-hip length.*



# TOTAL EASE ALLOWANCE

	Chest ease	Waistline ease	Hipline ease	Upper arm ease
cm	29.7-39	33.1-48.2	20.3-27.5	9.2-14.9
inches	11 3/4-15 3/8	13-19	8-10 7/8	3 5/8-5 7/8

# GARMENT LENGTH, SLEEVE LENGTH

Height, cm	Garment back length, cm	Sleeve length including shoulder width, cm
98	54.5	43-43.5
104	58.5	45.5-46
110	62.5	48.5-49
116	66.5	51-51.5
122	70.5	53.9-54.5
128	73.5	56.5-56.9
134	76.5	59-59.4
140	79.5	61.4-61.9
146	82.5	64-64.5
152	85.5	66.2-66.7
158	88.5	69.8-70

Height, in	Garment back length, in	Sleeve length including shoulder width, in
38.5	21 1/2	16 7/8-17 1/8
41	23	17 7/8-18 1/8
43.25	24 5/8	19 1/8-19 1/4
45.5	26 1/8	20 1/8-20 1/4
48	27 3/4	21 1/4-21 1/2
50.5	28 7/8	22 1/4-22 3/8
52.75	30 1/8	23 1/4-23 3/8
55	31 1/4	24 1/8-24 3/8
57.5	32 1/2	25 1/4-25 3/8
60	33 5/8	26 1/8-26 1/4
62.25	34 7/8	27 1/2-27 1/2

4. Additional material for the detachable hood - 0.55 m (5/8 yd) for all sizes and heights.

5. Straight grain fusible tape, in meters:

Height, cm	Size 26	Size 28	Size 30	Size 32	Size 34	Size 36	Size 38	Size 40
98	7.15	7.3						
104	7.3	7.45						
110		7.65	7.8					
116		7.85	8					
122			8.5	8.5				
128			8.5	8.6	8.75			
134				8.8	8.9	9		
140					9.05	9.2	9.3	
146						9.4	9.5	9.65
152						9.65	9.7	9.8
158							9.9	10

Straight grain fusible tape, in yards:

Height, in	Size 26	Size 28	Size 30	Size 32	Size 34	Size 36	Size 38	Size 40
38.5	7 7/8	8						
41	8	8 1/8						
43.25		8 3/8	8 1/2					
45.5		8 5/8	8 3/4					
48			9 1/4	9 1/4				
50.5			9 1/4	9 3/8	9 5/8			
52.75				9 5/8	9 3/4	9 7/8		
55					9 7/8	10	10 1/8	
57.5						10 1/4	10 3/8	10 1/2
60						10 1/2	10 5/8	10 3/4
62.25							10 7/8	10 7/8



When the main pieces of a garment are fully interfaced, we recommend cutting the main pieces with additional 1 cm (3/8") seam allowances on all sides. This way, if the fabric shrinks after being interfaced, there will still be enough fabric.

Before applying interfacing to the main fabric, we recommend testing interfacing and/or straight fusible tape on a leftover piece of fabric. Also, make sure to check the settings on your iron: the temperature, the steam (if the main fabric can be interfaced using the steam setting), and the time needed for the interfacing to adhere to the main fabric.

To interface, put the wrong side of the fabric piece to the gluey side of the interfacing (the side that feels rough to the touch) and press with the iron.

Do not iron the piece, but instead press it section by section, holding it down with the iron a few seconds until that section is adhered and then pressing down the next section. You may use a cotton pressing cloth to protect your iron sole. Once the interfacing process is complete, leave the piece on a hard, flat surface for 15 minutes for it to cool down.



Place the top and bottom pocket flap pieces right sides together. Align all the edges and corners.

Pin, baste, slightly easing the top flap in and machine-stitch. Backstitch in the beginning and end.

Press the seam flat.

Trim the seam allowance down to 3 mm (1/8") on the bottom flap. Trim the corners down to 2 mm.

