

# FROM THE FOUNDER OF THE #VIKISEWS BRAND

---



Back in 2016, when I was working on my first set of sewing instructions, I was trying to write them in such a way that even a complete beginner could easily understand and use them to create their very first garment. These instructions laid the foundation for the Vikisews brand, its vision and its mission. I wanted to create modern patterns with the most detailed and clear instructions.

Now, with each new collection we are constantly improving our instructions, amending them and adding more relevant details. By the time the final product reaches you, our drafters, correctors, and editors would have spent weeks perfecting every word and every photograph. If you compile a few of our instructions together, you will get a sewing manual that will assist you in sewing all kinds of garments at any difficulty level.

And I would be very happy if these instructions helped you to turn your hobby into a lifelong passion... Enjoy the process! Create your ultimate dream wardrobe! Wear your garments proudly for years to come!

If you have any questions, please contact us at [info@vikisews.com](mailto:info@vikisews.com) - we are always there to help.



## NURIT PATTERN DESCRIPTION

---

Nurit is a straight, loose-fitting coat, slightly tapered at the bottom, featuring wide horizontal quilting. The coat has front and back princess seams and front inseam pockets. The drop-shoulder sleeves are long and wide. The high standing collar is detachable and is attached with snaps. The coat closes with set-in snaps. Nurit is below-knee length.



## IMPORTANT!

---

The contents of this pattern are copyright protected and belong exclusively to Vikisews. You may use Vikisews patterns for personal use. It is prohibited to share Vikisews patterns and instructions with third parties, as well as to publish patterns and instructions online for public access. **Non-compliance with the mentioned rules is a violation of the US copyright law and may result in civil liability and criminal prosecution.**

You may use Vikisews patterns for commercial use, to sew custom-made garments and/or create fashion collections, on the condition that the patterns are solely used in a manufacturing setting and are not further shared with individuals.

## TOTAL EASE ALLOWANCE

	Bust ease	Waistline ease	Hipline ease	Upper arm ease
cm	56	78	50	27
inches	22	30 3/4	19 5/8	10 5/8

## GARMENT LENGTH, SLEEVE LENGTH

Height, cm	Garment length, cm	Sleeve length including shoulder width, cm
1 (154-160)	108.6-109.2	77.8-80.4
2 (162-168)	112.6-113.2	79.8-82.4
3 (170-176)	116.6-117.2	81.8-84.4
4 (178-184)	120.7-121.3	83.8-86.4

Height, ft	Garment length, in	Sleeve length including shoulder width, in
1 (5'1" - 5'3")	42 3/4-43	30 5/8-31 5/8
2 (5'4" - 5'6")	44 3/8-44 5/8	31 3/8-32 1/2
3 (5'7" - 5'9")	45 7/8-46 1/8	32 1/4-33 1/4
4 (5'10" - 6'1")	47 1/2-47 3/4	33-34

## SUGGESTED FABRIC

To sew this coat, choose outerwear fabrics with the following properties:

- medium-weight, soft, without stretch, opaque, wind- and water-resistant
- the fiber content can include natural fibers (cotton), artificial fibers (viscose, acetate), blends (cotton + polyester, etc.), and synthetics (polyester, polyester + elastane)
- the following fabrics are recommended: blended raincoat fabrics, dewspo, twill, taffeta, taslan, etc.

For the lining, choose lining fabrics made from artificial fibers (viscose), blends (viscose + elastane, viscose + polyester), or synthetics (polyester, polyester + elastane).

For the insulation layer, use alpolux, isosoft, thinsulate, polyester batting 100 g/m2 + swan down.

# PATTERN PIECES LIST

---

## 1. From main fabric:

- front - cut 2
- side front - cut 2
- back - cut 1 on fold
- side back - cut 2
- sleeve - cut 2
- stand - cut 2
- back neck facing - cut 1 on fold
- front facing - cut 2
- placket - cut 1 on fold

## 2. From lining:

- front lining - cut 2
- back lining - cut 1 on fold
- sleeve lining - cut 2
- pocket bag - cut 4

## 3. From spunbond:

- front - cut 2
- side front - cut 2
- back - cut 1 on fold
- side back - cut 2
- sleeve - cut 2
- stand - cut 1

## 4. From alpolux 100 insulation:

- back lining - cut 1 on fold
- front lining - cut 2
- sleeve lining - cut 2
- back neck facing - cut 1 on fold
- front facing - cut 2
- placket - cut 1 (1/2 width)
- stand - cut 1

## 5. From interfacing:

- front facing - cut 2
- back neck facing - cut 1 on fold

Partially interface the following:

- back - 1 piece. Interface the neckline edge with stitch-reinforced fusible bias tape. Interface the shoulder edges with straight grain stay tape. Interface the snap placement with 2x2cm (3/4x3/4") squares of interfacing.

- front - 2 pieces. Interface the neckline edge with stitch-reinforced fusible bias tape. Interface the pocket opening with the grown-on pocket facing so that the interfacing covers the front piece by 1cm (3/8"). Interface the snap placement with 2x2cm (3/4x3/4") squares of interfacing.

- stand - 1 piece. Interface the side and lower edges with strips of interfacing.

- placket - 1 piece. Interface one half along the long edge.

**IMPORTANT!** Don't forget to transfer all the notches from the pattern to your fabric.



Using chalk, mark the stitching lines on the right side of the fabric of the following pieces:

- Back
- Side back
- Front
- Side front
- Stand
- Sleeve

Pin the corresponding spunbond pieces to the wrong side of the garment pieces.



Machine stitch over the lines through both layers.

Stitch additional lines on the right side of the fabric as shown in the photos, 5mm (1/4 in) away from the edge. This will form the cavities - "pockets" - to be filled with the swan down.

- On the sleeve pieces – stitch along the sleeve heads, leaving an 8cm (3 in) opening at the center of the curve
- On the upper collar piece – along the side and bottom edges
- On the front and back pieces – along the shoulder and neckline edges
- On the side front and side back pieces – along the shoulder edge, then along the neckline and the sides

