

# I M P O R T A N T !

The contents of this pattern are copyright protected and belong exclusively to Vikisews. You may use Vikisews patterns for personal use. It is prohibited to share Vikisews patterns and instructions with third parties, as well as to publish patterns and instructions online for public access. **Non-compliance with the mentioned rules is a violation of the US copyright law and may result in civil liability and criminal prosecution.**

You may use Vikisews patterns for commercial use, to sew custom-made garments and/or create fashion collections, on the condition that the patterns are solely used in a manufacturing setting and are not further shared with individuals.

## E D W I G E

#vikisews

### PATTERN DESCRIPTION

*Edwige is a loose fitting blouse with a straight silhouette, sewn in a lightweight fabric. The front features yokes and a soft gathering in the top portion, a slightly dropped shoulder which gives a soft line in the shoulder slope, and a deep V-shaped neckline. The blouse is collarless. It fastens with button loops and buttons, with part of the button loops going up to the yoke serving only a decorative function. Edwige features a long set-in bishop sleeve, with a soft gathering ending in a tall cuff. The cuff also fastens with button loops and buttons. Edwige is below-the-hip length.*



## TOTAL WEARING EASE

Bust ease, cm	Waistline ease, cm	Hipline ease, cm	Upper arm ease, cm
20,1-21,2	41-41,8	15,9	18,9-19,8

## GARMENT LENGTH, SLEEVE LENGTH

Height, cm	Garment length at center back, cm	Sleeve length, including cuff, cm
1 (154-160)	64	60,4-61
2 (162-168)	67	62,3-63,1
3 (170-176)	70	64,4-65,2
4 (178-184)	73	66,3-67,1

## SUGGESTED FABRIC

To sew this blouse, choose woven fabrics with the following properties:

- Light to medium weight, non-stretch or with very little stretch, soft, fluid
- The fiber content can include natural fibers (silk), artificial (viscose), blends (silk + polyester, etc), and synthetic (polyester, polyester + elastane, etc)
- The following fabrics are recommended: natural and artificial silk, dress-weight viscose, crepe, thin atlas, chiffon

The blouse on the photo is made with a thin, soft, non-stretch material. The fiber content is 30% silk and 70% viscose.

## FABRIC AND NOTIONS REQUIREMENTS

1. Main fabric, 140cm wide, in meters

Height, cm	Size 34	Size 36	Size 38	Size 40	Size 42-46	Size 48	Size 50-52
1 (154-160)	1,35	1,4	1,4	1,45	1,5	1,65	1,7
2 (162-168)	1,35	1,4	1,45	1,5	1,6	1,75	1,75
3 (170-176)	1,4	1,4	1,5	1,5	1,65	1,75	1,8
4 (178-184)	1,4	1,45	1,5	1,55	1,65	1,8	1,85

2. Woven fusible interfacing, 140cm wide, in meters

Height, cm	Yardage
1 (154-160)	0,75
2 (162-168)	0,8
3 (170-176)	0,8
4 (178-184)	0,85

## IMPORTANT!

*When purchasing fabric, please account for shrinkage and buy 5% more than required.*

3. 16 covered buttons, 8mm in diameter

4. Matching thread - 1 spool

5. One pair of 14cm wide shoulder pads

## TOOLS AND EQUIPMENT

- Sewing machine for construction
- Stitch-in-the-ditch foot for your sewing machine (optional)
- Loop turner
- Tool for making covered buttons

## PATTERN PIECES LIST

### 1. From main fabric:

- Right front – cut 1
- Left front - cut 1
- Back - cut 1
- Front yoke - cut 4
- Right front facing - cut 1
- Left front facing - cut 1
- Back neck facing - cut 1
- Sleeve - cut 2
- Cuff - cut 4
- Rouleau button loops - cut 2

### 2. From interfacing:

- Front yoke - cut 4
- Right front facing - cut 1
- Left front facing - cut 1
- Back neck facing - cut 1
- Cuff - cut 4

## IMPORTANT!

*Don't forget to transfer all pattern markings and notches onto the fabric.*

### Additionally, apply bias cut and stitched tape interfacing to the following:

- Neckline edges on both front yokes
- Neckline edge on the back neck facing
- Neckline and front edges on the right and left front facings
- Cuff edges on both pieces



Press the seam allowances towards the interfacing side.



Turn the front facings' interfacing to the facings' wrong sides and fuse the interfacing by pressing with an iron. As you're pressing, form a 1mm roll towards the interfaced side.



Turn the back neck facing's interfacing to the facing's wrong side and fuse the interfacing by pressing with an iron. As you're pressing, form a 1mm roll towards the interfaced side.