


# WELCOME GUIDE

PowerGaN 33Pro | OCW-7331E+C54 |

## PRECAUTIONS

- 1.This product is only compatible with devices that support the specified charging protocols.
- 2.Do not expose the product to fire or charge it near areas that may become hot.
- 3.Use the specified charging current to power the product.
- 4.Do not expose the product to liquids or use it in humid environments.
- 5.For troubleshooting, please contact after-sales service for assistance.
- 6.Keep out of reach of children.
- 7.Dispose of the product separately from household waste in accordance with local regulations

## PRODUCT OVERVIEW




Fast Charger \*1

## BASIC PRODUCT SPECIFICATIONS

|                                       |  |
|---------------------------------------|--|
| Model                                 | OCW-7331E+C54  |
| Input                                 | 100-240V ~ 50-60Hz 1.0A  |
| Output1 (Type-C)                      | 5.0V $\Rightarrow$ 3.0A, 9.0V $\Rightarrow$ 3.0A, 12.0V $\Rightarrow$ 2.5A, 15.0V $\Rightarrow$ 2.0A<br>20.0V $\Rightarrow$ 1.5A, 11V $\Rightarrow$ 3.0A (33W Max) |
| Output2 (USB-A)                       | 5.0V $\Rightarrow$ 3.0A, 9.0V $\Rightarrow$ 3.0A, 12.0V $\Rightarrow$ 2.5A, 15.0V $\Rightarrow$ 2.0A<br>20.0V $\Rightarrow$ 1.5A (30W Max)                         |
| Output1 (Type-C)<br>+ Output2 (USB-A) | 5.0V $\Rightarrow$ 3.4A (17W Max)  |
| Total Output                          | 33W Max  |
| Product Size                          | 47*51*77.5mm   |
| Product Weight                        | 67.6g $\pm$ 5g   |

\*oraimo Lab test results

## USING YOUR PRODUCT



**oraimo**  
smart accessories

## IMPORTANT SAFETY INSTRUCTIONS

- Do not store the product in excessive heat or a humid environment, such as in direct sunlight or near heating appliances, as it may cause an explosion.
- Using chargers or power supply units that are not recommended by or sold with the product may increase the risk of fire or personal injury.
- The permissible temperature range for using the product should be between 0°C and 45°C.
- Avoid disassembling, modifying, inserting any foreign objects into, or immersing in water or any liquid to prevent liquid leakage, overheating, fire, or explosion.
- If the product is not in use for a long period, ensure it is recharged regularly once every three months.
- When the device is charging, some heat may be generated, which is normal. No need to worry.
- Keep the product out of reach of children to prevent them from swallowing or entangling it.
- Do not expose it to heat or fire.
- Cleaning the product should not be done with any harmful chemicals or detergents.
- Overuse, intense shocks, or drops may cause damage to the product.
- Utilize only original or certified cables for connecting.