



WELCOME GUIDE

PowerNova Q41 | OPB-7401Q |

* For safety issue, the power bank remains low capacity during shipping.
Please fully charge the battery before use!

For more information, please visit:




www.oraimo.com



@oraimo accessories

USAGE INSTRUCTIONS



- Press the main button to check the battery percentage on the digital screen.
- Charge your device through 2 USB-A output ports and 2 Type-C output port.
- Recharge the power bank via either of the two Type-C input ports (Input 1 or Input 2). Both ports support simultaneous charging, with a combined maximum input power of 35W when used together. A Type-C charging cable is included in the package.
- The power bank will automatically shut down if no device is connected within 32 seconds.
- In charging mode, double press the power button to switch the LED display between battery percentage and real-time charging power.
- PowerNova Q41 automatically detects low-current mode, ideal for charging TWS earbuds, smartwatches, toothbrushes, and similar devices. The low-current charging mode will automatically turn off once the device is fully charged.
- Both Type-C ports support fast charging.

IMPORTANT SAFETY INSTRUCTIONS

- Power bank can be recharged for an extended 1-2 hours after the first three full charges, which allowing the power bank to achieve optimal performance.
- Power bank can be fully recharged and discharged for the first three times to achieve optimal performance.
- Do not store the power bank in excessive heat or in a humid environment, such as in direct sunlight or near heating appliances, as it may cause an explosion.
- Using chargers or power supply units that are not recommended by or sold with the power bank may increase the risk of fire or personal injury.
- The permissible temperature range for using the power bank should be between 0°C and 45°C.
- Avoid disassembling, modifying, inserting any foreign objects into, or immersing in water or any liquid to prevent liquid leakage, overheating, fire or explosion.
- If the power bank is not in use for a long period of time, ensure it is recharged regularly once every three months, and it is recommended to store more than 50% of the power.
- When the power bank is recharged, some heat may be generated which is normal. No need to worry.
- Keep the power bank out of reach of children to prevent them from swallowing or entangling it. Furthermore, do not expose it to heat or fire.
- Cleaning the power bank should not be done with any harmful chemicals or detergents.
- Overuse, intense shocks or drops may cause damage to the power bank.
- Utilize only original or certified cables for connecting.

AR

- يمكن إعادة شحن بنك الطاقة لمدة 1-2 ساعات ممتدة بعد أول ثلاث عمليات شحن كاملة، ما يسمح لبنك الطاقة بتحقيق الأداء الأمثل.
- يمكن إعادة شحن وتفرغ بنك الطاقة بالكامل لأول ثلاث مرات لتحقيق الأداء الأمثل.
- لا تترك بنك الطاقة في مكان شديد الحرارة أو في بيئة رطبة، مثل ضوء الشمس المباشر أو قريباً من أجهزة التشفية، حيث قد يتسبب ذلك في حدوث انفجار.
- استخدام أجهزة الشحن أو وحدات إمداد الطاقة غير الموصى بها لبنك الطاقة أو غير المصنعة معه قد يؤدي إلى زيادة خطر نشوب حريق أو إصابة شخصية.
- يجب أن يتراوح نطاق درجة الحرارة المسموح بها لاستخدام بنك الطاقة بين 0 درجة مئوية و 45 درجة مئوية.
- تجنب تفكيك أو تعديل بنك الطاقة أو إدخال أي أغراض غريبة به أو غمره بالماء أو أي سائل لمنع تسرب السائل إليه أو ارتفاع درجة حرارته أو نشوب حريق أو انفجار.
- في حالة عدم استخدام بنك الطاقة لفترة طويلة من الزمن، تأكد من إعادة شحنه بانتظام مرة كل ثلاث شهور ، ويوصى بتخزين أكثر من 50% من الطاقة به.
- عند إعادة شحن بنك الطاقة، قد يتم توليد بعض الحرارة وهو أمر طبيعي. لا داع للقلق.
- احتفظ ببنك الطاقة بعيداً عن متناول الأطفال لمنعهم من ابتلاعه أو تشابكه أسلاكه.
- علاوة على ذلك، لا تعرضه للحرارة أو النار.
- لا ينبغي تنظيف بنك الطاقة باستخدام أي مواد كيميائية أو منظفات منزلية.
- قد يؤدي الاستخدام الخاطئ أو التعرض للضربات أو السقوط الشديد إلى تلف بنك الطاقة.
- استخدم فقط الكابلات الأصلية أو المعتمدة للتوصيل.

AR

- اضغط على الزر الرئيسي للتحقق من النسبة المئوية للشحن البطارية على الشاشة الرقمية.
- الشحن جهازاً عبر 2 منفذ مخرج USB-A و 2 منفذ مخرج Type-C.
- قم بشحن بنك الطاقة عبر أي من منفذَي الإدخال Type-C (إدخال 1 أو إدخال 2). يدعم كلا المنفذين الشحن المتزامن، مع طاقة إدخال قصوى مجمعة تبلغ 35 واط عند استخدامها معاً. يوجد كابل شحن Type-C ضمن المنتج داخل العبوة.
- سيتم إيقاف تشغيل بنك الطاقة تلقائياً إذا لم يتم توصيل أي جهاز خلال 32 ثانية.
- في وضع الشحن المنخفض، يرن على زر الطاقة للتبديل بين نسبة البطارية وكوة الشحن في الوقت الفعلي على شاشة LED.
- PowerNova Q41 يتكيف تلقائياً ويضع التيار المنخفض وهو مثالي للشحن ساعات TWS والساعات الذكية ورفرف الأسنان والأجهزة المماثلة. سيتم إيقاف تشغيل وضع الشحن المنخفض أيار تلقائياً بمجرد شحن الجهاز بالكامل.
- كلا منفذَي Type-C يدعمان الشحن السريع.