

OSP-5381说明书 线下

材质：100g书纸 形式：风琴折 尺寸：145x90mm（成品） 印刷：黑白


Internal Use（内部公开）

oraimo


WELCOME GUIDE
PowerSolar 382 | OPS-5381

Please read this Guide carefully before using the product

PACKAGE CONTENTS




SPECIFICATIONS




INSTALL POWERSOLAR 382

STEP 1: Choose the location of the solar panel and control unit
First, choose the location on the roof for the solar panel: Choose the location with maximum sunlight exposure. Poor solar panel location will reduce charging performance.The control unit has to be connected to the solar panel and the tube light bulb placed inside the house. There is a 5m wire to connect to the panel and tube light bulb.


STEP 2: Install the solar panel on the roof
Install the solar panel with a clear view of the sky, with maximum exposure to direct sunlight.



STEP 3: Mount the metal bracket of the control panel




STEP 4: Mount the control panel on the metal wall bracket
Connect the tube light wire and solar panel wire to the ports at the side of the control panel.




STEP 5: Choose the locations of the tube light and LED bulbs in the house

The tube light and the two LED bulb lights can be installed separately or together, depending on the lighting requirements. For best lighting performance, it is recommended to hang the lights from the ceiling in the center of a room or place them in areas where localized lighting is needed. Nail hooks at the chosen locations and install the lights accordingly.




TURN ON THE BATTERY CONTROL UNIT

Single press the power button to power on the battery control unit. The device will automatically shut down if no load is detected within 32 seconds.



Device Charging

There are 2 USB ports and 1 Type-C port provided in the control panel for charging devices. The mobile phones can be placed on the control panel with the help of a groove.




For more information, please visit:





Recharge

1. Recharge and charge via Type-C port.



2. Recharge via Solar Panel



Fast Charging Indicator
Solar Charging Indicator
Battery Percentage Display

ATTENTION

- Preserve battery lifespan, use and recharge at least once every 3 months
- Use original or certified cables
- Do not expose to liquids
- Do not disassemble
- Avoid dropping
- Avoid extreme temperatures

IMPORTANT SAFETY INSTRUCTIONS

When using this product, basic precautions should always be followed, including the following:

- Store product in a cool and dry place.
- Do not store the product in hot or humid environment.
- Use of a power supply or charger not recommended or sold by the product manufacturer may result in a risk of fire or injury to persons.
- Operating temperature should be between 0°C to 45°C.
- Do not disassemble the product. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury to persons.
- If the product is not used for long periods of time, you should change and discharge once every three months.
- When charging a device, the product may feel warm, this is a normal operating condition and should not be cause for a concern.
- In normal conditions, the battery performance will decline over several years.
- Do not dispose of the product in heat or fire.
- Do not clean the product with harmful chemicals or detergents.
- Misuse, dropping or excessive force may cause product damage.
- When disposing of secondary cells or batteries, keep cells or batteries of different electrochemical systems separate from each other.

CUSTOMER SERVICE

Email: service@carlcare.com India: care@oraimo.com

WARRANTY CERTIFICATE

Name :	
Address :	
Tel. No. :	
Date of purchase : (dd/mm/yy)	
Store name :	
Warranty period :	

WARRANTY TERMS & CONDITIONS

- All quality-related defects on items sold directly by oraimo or oraimo's authorized resellers are covered by an extensive warranty, starting from the date of purchase.
- oraimo's limited warranty is restricted to the country of purchase. The limited warranty is void on items taken outside the country they were originally bought in or shipped to directly from an authorized online purchase.
- This warranty covers only original oraimo products. It is not applicable to normal wear and tear, or any defects arising from damage caused by misuse of this product.
- Warranty is for the primary product only nor transferable. Any free additional product(s) are not covered in this warranty.
- If the product fails regardless of usage in compliance with the instruction manual and other written precaution, replacement will be provided free of charge.
- To claim the warranty, contact the services team from the platform or store where you bought from.