





Product Overview

Type-C1 (C1 IN/OUT)
Type-C2 (C2 OUT)
USB-A (A OUT)

• Single-Port Output
A1: 5W C1: 100W C2: 30W

• Dual-Port Output
C1+C2: 130W
C1+A: 124W
C2+A: 30W

• Triple-Port Output
C1+C2+A: 130W

LED Display



FAST
100%
C1: 100W I
C2: 100W I
A: 100W I

FAST-Charging Mode Activated
(100%) Remaining Battery
(100%) The power bank is charging your device
(100%) The power bank is being recharged
(100%) Watt, Real-time Input/Output Power
(100%) Type-C2 Input & Output Port
(100%) USB-A Output Port

WELCOME GUIDE

PowerJet 130 | ORS-T2952 |


Please read this Guide carefully before using the product

*For safety issues, the product remains at low capacity during shipping.
Please fully charge the product before initial use.

Using Instructions

Charge Your Device

Charge your device through 2 Type-C output ports or the USB-A output port. The power bank supports up to 3 devices fast charge simultaneously.




Type-C to Type-C Cable
OR
Type-C to Lightning Cable

*The power bank intelligently switches to smart fast-charging mode once it matches your device's charging protocol. It is compatible with the majority of devices such as Apple, Samsung, TECNO, Infinix, HP, DELL, and Lenovo, among others.

Passive Charging

Long press the Power Button for 3 seconds to pause charging.



Important Safety Instructions

- Do not store the product in excessive heat or a humid environment, such as in direct sunlight or near heating appliances, as this may cause an explosion.
- Using chargers or power supply units that are not recommended by or sold with the product may cause fire or damage to the product.
- The permissible temperature range for using the product should be between 0°C and 40°C.
- Avoid disassembling, modifying, inserting any foreign objects into, or removing in water or any fluid to prevent liquid leakage, overheating, fire, or explosion.
- Do not place the product in a restricted disposal facility away from these moments.
- When the device is charging, some heat may be generated, which is normal. No need to worry.
- Keep the product out of reach of children to prevent them from swallowing or entangling it.
- Do not expose to fire or to flame.
- Do not attempt to disassemble or tamper with the product.
- Overuse, intense shocks, or drops may cause damage to the product.
- Utilize only original or certified cables for connecting.

Customer Service

365 DAYS WARRANTY | Email: service@oraimo.com | India: india@oraimo.com

Warranty Certificate

Name :	
Address :	
Tel. No. :	
Date of purchase : Month/Year :	
Store name :	
Warranty period :	

Warranty Terms & Conditions


All quality-related defects on items sold directly by oraimo or oraimo's authorized retailers are covered by an extensive warranty, starting from the date of purchase.

oraimo's limited warranty is restricted to the country of purchase. The limited warranty is void on items taken outside the country they were originally bought in or shipped to directly from an authorized online purchase.

- The warranty covers only original oraimo products. It is not applicable to normal wear and tear, or any defects arising from damage caused by misuse of this product.
- Warranty is for the primary product only or non-transferable. Any free additional products are not covered in this warranty.
- If the product fails regardless of usage in compliance with the instruction manual and other written precaution, replacement will be provided free of charge.
- To claim the warranty, contact the services team from the platform or store where you bought from.

Recharge the Power Bank

Recharge your power bank through input 1 (Type-C1) using the Type-C to Type-C charging cable attached to the package.



Connect to an AC adaptor

Connect to a device power source with a Type-C port

*If recharged by a laptop, activate the reverse charging function of the laptop first.



www.araimo.com



araimo accessories

WARRANTY TERMS

- The warranty period starts from the date of delivery of the product and is 2 years. (This period may not be less than 2 years.)
- The product, including all its parts, is covered under warranty.
- If the product is found to be defective, the consumer may exercise one of the rights specified in Article 11 of Law No. 4502 on the Protection of Consumer, namely:
 - Withdrawal from the contract,
 - Requesting a price reduction,
 - Requesting free repair,
 - Requesting replacement with a non-defective equivalent.
- If the consumer chooses the right of free repair, the seller is obliged to repair or have the product repaired free of charge, without demanding any fee under any name such as labor cost, replaced part cost, or otherwise. The consumer may also exercise this right against the manufacturer or importer. The seller, manufacturer, and importer are jointly and severally liable.
- If the consumer uses the right of free repair and:
 - The product breaks down again within the warranty period,
 - The maximum repair period is exceeded,
 - It is determined by an authorized service station, seller, manufacturer, or importer by report that repair is not possible,
 the consumer may request a refund, a price reduction proportional to the defect, or replacement with a non-defective equivalent, if possible. The seller may not refuse this request. If the request is not fulfilled, the seller, manufacturer, and importer are jointly and severally liable.
- The repair period shall not exceed 20 business days. This period starts from the date the fault is reported to the authorized service station or seller within the warranty period, or from the date the product is delivered to the authorized service station if outside the warranty period. If the defect cannot be repaired within 10 business days, the manufacturer or importer must provide the consumer with another product of similar features for use until the repair is completed. If the product breaks down within the warranty period, the time spent in repair shall be added to the warranty period.
- Failures resulting from use contrary to the instructions in the user manual lie outside the scope of the warranty.
- Disputes arising from the exercise of warranty rights, the consumer may apply to the Consumer Arbitration Committee or the Consumer Court in the place of residence or where the consumer transaction was carried out.
- If this Warranty Certificate is not provided by the seller, the consumer may apply to the General Directorate of Consumer Protection and Market Surveillance of the Ministry of Trade.

Technical Service:

Onur Servis Tula Şube
 Address: Tepeören Demireli Caddesi No:137 /34959 Tula
 Sadecan kargı güdümörmöne hizmet vermektedir.
 Onur Servis Genel Merkez
 Address: Atilla İhan Cd. No:20, 34750 Ataşehir/İstanbul
 Sadecan Onur bürosunda hizmet verilmektedir.
 Website: <https://onurservis.com/>
 For authorized service centers, please visit <https://onurservis.com/>, as required by the distributor.

Importer Company:

Company Name: Dorca Communication and Trade Inc.
 Address: Kışıkbaşı Mah., Atilla İhan Cd. No:22, 34750 Ataşehir, İstanbul
 Telephone: (0216) 469 40 40
 Authorized Signature: 
 Company Stamp: 

Manufactured for:

Company Name: GRABMO TECHNOLOGY LIMITED
 Address: FLAT N 16/F BLOCK B UNIVERSAL INDUSTRIAL CENTRE 19,25 SHAN MEI STREET FOTAN NT HONGKONG
 Email: hello@araimo.com

Manufactured by:

Company Name: GRABMO TECHNOLOGY LIMITED
 Address: FLAT N 16/F BLOCK B UNIVERSAL INDUSTRIAL CENTRE 19,25 SHAN MEI STREET FOTAN NT HONGKONG
 Email: hello@araimo.com

Transport and Shipping Instructions

- Before moving the device, ensure all connections are disconnected and cables removed.
- Use the original box and packaging materials for repacking.
- Avoid shock, impact, heat, humidity, and dust during use and transport.

Consumer Maintenance and Repairs

No consumer serviceable or repairable parts. For maintenance or repair, contact an authorized service point listed in the Technical Service List.

Efficient Energy Use

Turn off data connections (Bluetooth, Wi-Fi) when not in use.
 Lower screen brightness and set shorter screen timeout.
 Disable unnecessary sounds.

Recycling


 This product complies with the AEEE Regulation.


 Proper disposal of the product.
 This symbol indicates that the product should not be disposed of together with other household waste across the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal and to promote the sustainable reuse of natural resources, please recycle responsibly. To return a used product, please use return and collection systems or contact the retailer from whom the product was purchased. They can take this product for environmentally safe recycling.




HOŞ GELDİN KILAVUZU

PowerJet 130 | 098-72750 |

Lütfen ürünü kullanmadan önce bu Kılavuzu dikkatlice okuyun
 *Güvenlik nedeniyle, ürün satışı sırasında düşük kapasitede tutulmaktadır.
 Ürünü ilk kullanmadan önce tamamen şarj edin.

Ürüne Genel Bakış




Çihazın Şarj Edin
 Çihazınız 2 Type-C çıkış bağlantı noktası veya USB-A çıkış bağlantı noktası üzerinden şarj edin. Powerbank, aynı anda 3 cihazı kadar hızlı şarj edebilir.

Tek Bağlantı Noktalı Çıkış
 A: 24 W C1: 100 W C2: 30 W

Çift Çıkışlı Bağlantı Noktası
 C1+C2: 130 W
 C1+A: 124 W
 C2+A: 30 W

Üç Bağlantı Noktalı Çıkış
 C1+C2+A: 130 W

LED Ekran




FAST
%
C1: 100 W I
C2: 100 W I
A: 100 W I

(FAST) Hızlı Şarj Modu Etkinleştirildi
 (C1) Hızlı Şarj
 (I) Powerbank cihazınız şarj ediyor
 (I) Powerbank şarj ediyor
 (C2) Yakıt, Gösterge Zamanı Şarj/Giriş Çıkış Gücü
 (C1) Type-C1 Giriş ve Çıkış Bağlantı Noktası
 (C2) Type-C2 Çıkış Bağlantı Noktası
 (A) USB-A Çıkış Bağlantı Noktası

Kullanım Talimatları

Çihazın Şarj Edin

Çihazınız 2 Type-C çıkış bağlantı noktası veya USB-A çıkış bağlantı noktası üzerinden şarj edin. Powerbank, aynı anda 3 cihazı kadar hızlı şarj edebilir.




• Tek Bağlantı Noktalı Çıkış
 A: 24 W C1: 100 W C2: 30 W

• Çift Çıkışlı Bağlantı Noktası
 C1+C2: 130 W
 C1+A: 124 W
 C2+A: 30 W

• Üç Bağlantı Noktalı Çıkış
 C1+C2+A: 130 W

LED Ekran




FAST
%
C1: 100 W I
C2: 100 W I
A: 100 W I

(FAST) Hızlı Şarj Modu Etkinleştirildi
 (C1) Hızlı Şarj
 (I) Powerbank cihazınız şarj ediyor
 (I) Powerbank şarj ediyor
 (C2) Yakıt, Gösterge Zamanı Şarj/Giriş Çıkış Gücü
 (C1) Type-C1 Giriş ve Çıkış Bağlantı Noktası
 (C2) Type-C2 Çıkış Bağlantı Noktası
 (A) USB-A Çıkış Bağlantı Noktası

Kullanım Talimatları

Çihazın Şarj Edin

Çihazınız 2 Type-C çıkış bağlantı noktası veya USB-A çıkış bağlantı noktası üzerinden şarj edin. Powerbank, aynı anda 3 cihazı kadar hızlı şarj edebilir.




• Tek Bağlantı Noktalı Çıkış
 A: 24 W C1: 100 W C2: 30 W

• Çift Çıkışlı Bağlantı Noktası
 C1+C2: 130 W
 C1+A: 124 W
 C2+A: 30 W

• Üç Bağlantı Noktalı Çıkış
 C1+C2+A: 130 W

LED Ekran



FAST
%
C1: 100 W I
C2: 100 W I
A: 100 W I

(FAST) Hızlı Şarj Modu Etkinleştirildi
 (C1) Hızlı Şarj
 (I) Powerbank cihazınız şarj ediyor
 (I) Powerbank şarj ediyor
 (C2) Yakıt, Gösterge Zamanı Şarj/Giriş Çıkış Gücü
 (C1) Type-C1 Giriş ve Çıkış Bağlantı Noktası
 (C2) Type-C2 Çıkış Bağlantı Noktası
 (A) USB-A Çıkış Bağlantı Noktası

Kullanım Talimatları

Çihazın Şarj Edin

Çihazınız 2 Type-C çıkış bağlantı noktası veya USB-A çıkış bağlantı noktası üzerinden şarj edin. Powerbank, aynı anda 3 cihazı kadar hızlı şarj edebilir.



• Tek Bağlantı Noktalı Çıkış
 A: 24 W C1: 100 W C2: 30 W

• Çift Çıkışlı Bağlantı Noktası
 C1+C2: 130 W
 C1+A: 124 W
 C2+A: 30 W

• Üç Bağlantı Noktalı Çıkış
 C1+C2+A: 130 W

LED Ekran




FAST
%
C1: 100 W I
C2: 100 W I
A: 100 W I

(FAST) Hızlı Şarj Modu Etkinleştirildi
 (C1) Hızlı Şarj
 (I) Powerbank cihazınız şarj ediyor
 (I) Powerbank şarj ediyor
 (C2) Yakıt, Gösterge Zamanı Şarj/Giriş Çıkış Gücü
 (C1) Type-C1 Giriş ve Çıkış Bağlantı Noktası
 (C2) Type-C2 Çıkış Bağlantı Noktası
 (A) USB-A Çıkış Bağlantı Noktası

Kullanım Talimatları

Çihazın Şarj Edin

Çihazınız 2 Type-C çıkış bağlantı noktası veya USB-A çıkış bağlantı noktası üzerinden şarj edin. Powerbank, aynı anda 3 cihazı kadar hızlı şarj edebilir.




• Tek Bağlantı Noktalı Çıkış
 A: 24 W C1: 100 W C2: 30 W

• Çift Çıkışlı Bağlantı Noktası
 C1+C2: 130 W
 C1+A: 124 W
 C2+A: 30 W

• Üç Bağlantı Noktalı Çıkış
 C1+C2+A: 130 W

LED Ekran



FAST
%
C1: 100 W I
C2: 100 W I
A: 100 W I

(FAST) Hızlı Şarj Modu Etkinleştirildi
 (C1) Hızlı Şarj
 (I) Powerbank cihazınız şarj ediyor
 (I) Powerbank şarj ediyor
 (C2) Yakıt, Gösterge Zamanı Şarj/Giriş Çıkış Gücü
 (C1) Type-C1 Giriş ve Çıkış Bağlantı Noktası
 (C2) Type-C2 Çıkış Bağlantı Noktası
 (A) USB-A Çıkış Bağlantı Noktası

Garanti Belgesi

Ad:	
Adres:	
Tel. No.:	
Satın alma tarihi:	
(güvenli)	
Makales adı:	
Garanti süresi:	

[illegible][illegible][illegible]