


OBS-982说明书:
100g铜版纸, 无膜, 4C+1专印刷, 骑马钉
成品尺寸: 150*115mm



WELCOME GUIDE
SpaceBox Max (TWS-02)

Please read this guide carefully before using the product.
This safety guide, the product manual, warranty, and warranty policy. Please pay attention to the safety instructions and use.

PACKAGE CONTENTS



Wireless Party Speaker x 1
Micro-USB Cable x 1
Micro-USB Adapter x 1
Micro-USB to USB Adapter x 1
Micro-USB to USB Adapter x 1
Micro-USB to USB Adapter x 1

BASIC PRODUCT SPECIFICATIONS

Product Size	185x120x45mm
Bluetooth Version	4.2
Bluetooth Range	10m
Frequency Response	40Hz-20KHz
Battery Capacity	2000mAh (3.7V)
Playtime	8-10 Hours (Medium Volume, 10% Music Medium Volume)
Charging Time	2-3 Hours
Charging Port	Micro-USB (Bottom)
Charging Cable	Micro-USB to USB Cable
System Output	20W
Play Mode	Bluetooth, AUX In, Memory Card, USB, 3.5mm In, 3.5mm Out

DOWNLOAD THE APP



Download the app from the QR code or search "Oraimo" on the App Store or Google Play.

USING YOUR SPEAKER

Powering on/off



Press the power button to turn the speaker on or off.

Pairing

Pairing



Press the power button to turn the speaker on or off.

Charging the Speaker


Charging the Speaker



Connect the Micro-USB cable to the speaker and the power source.

Bluetooth Connection


Bluetooth Connection



Connect the speaker to a Bluetooth device.

USB Connection


USB Connection



Connect the speaker to a USB device.

Memory Card Connection

Memory Card Connection



Insert the memory card into the speaker.

[illegible][illegible][illegible][illegible][illegible]