

PowerCube 201 | OCW-5203ECC |

1. This product is only compatible with devices that support the specified charging protocols.
2. Do not expose the product to fire or charge it near areas that may become hot.
3. Use the specified charging current to power the product.
4. Do not expose the product to liquids or use it in humid environments.
5. For troubleshooting, please contact after-sales service for assistance.
6. Keep out of reach of children.
7. Dispose of the product separately from household waste in accordance with local regulations

Model	OCW-5203ECC
Plug Type	EU Type
Input	180V-240V~50/60Hz, 0.5A Max
Output 1(Type-C)	5.0V $\pm$ 3.0A; 9V $\pm$ 2.22A; 12V $\pm$ 1.67A 20W Max
Output 2(USB-A1)	5.0V $\pm$ 3.0A; 9V $\pm$ 2.0A; 12V $\pm$ 1.5A 18W Max
Output 1+Output 2	5V $\pm$ 3.0A 15W Max
Cable Type	Type-C to Type-C
Length	1m
Output	3A

A diagram illustrating the connection of a power plug to a wall outlet. On the right, a power plug with two prongs is shown. An arrow points from the plug towards a wall outlet on the left, which contains two circular sockets.

1. Bu ürün yalnızca belirtilen şarj protokolünü destekleyen cihazlarla uyumludur.
2. Ürünü ateşe maruz bırakmayın veya ısınabilecek alanların yakınında şarj etmeyin.
3. Ürünü çalıştırmak için belirtilen şarj akımını kullanın.
4. Ürünü savlara maruz bırakmayın ve nemli ortamlarda kullanmayın.
5. Sorun giderme için kütlen satış sonrası hizmetle iletişime geçin.
6. Çocukların erişemeyeceği yerde saklayın.
7. Ürünü yerel yönetmeliklere uygun olarak evsel atıklardan ayrı olarak atın

Model	OCW-5203ECC
Fiş Tipi	AB Tipi
Giriş	180 V-240 V-50/60 Hz, 0,5 A Maks.
Çıkış 1 (Type-C)	5,0 V⇒3,0 A; 9 V⇒2,22 A; 12 V⇒1,67 A 20 W Maks.
Çıkış 2 (USB-A1)	5,0 V⇒3,0 A; 9 V⇒2,0 A; 12 V⇒1,5 A 18 W Maks.
Çıkış 1 + Çıkış 2	5 V⇒3,0 A 15 W Maks.
Kablo Tipi	Type-C'den Type-C
Uzunluk	1 m
Çıkış	3 A

A diagram showing a power plug being inserted into a wall outlet. The plug is on the right, and the outlet is on the left. An arrow points from the plug towards the outlet, indicating the direction of insertion.

A diagram showing a power plug being inserted into a power outlet. The plug is on the right, and the outlet is on the left. An arrow points from the plug towards the outlet, indicating the direction of insertion.

smart accessorie

- Do not store the product in excessive heat or a humid environment, such as in direct sunlight or near heating appliances, as this may cause an explosion.
- Do not disassemble the product. If the product is damaged or recommended by or sold with the product may increase the risk of fire or personal injury.
- The permissible temperature range for using the product should be between 0°C and 40°C.
- Avoid disassembling, modifying, inserting any foreign objects into, or immersing in water or any liquid to prevent liquid leakage, overheating, fire, or explosion.
- Do not use the product for use for a long period, ensure it is recharged regularly every three months.
- When the device is charging, some heat may be generated, which is normal. No action is required.
- Keep the product out of reach of children to prevent them from swallowing or tampering with it.
- Do not expose it to heat or fire.
- Cleaning the product should not be done with any harmful chemicals or detergents. Use a soft cloth to clean the product. Excessive cleaning may cause damage to the product.
- Use only original or certified cables for connecting.

Name :	
Address :	
Tel. No. :	
Date of purchase : (dd/mm/yy)	
Store name :	
Warranty period :	

- 2) The warranty period starts from the date of delivery of the product and 2 years. (This period may not be less than 2 years.)
- 3) The consumer, including the authorized service station, is entitled to the warranty.
- 3) If the product is found to be defective, the consumer may exercise one of the rights specified in Article 11 of Law No. 6502 on the Protection of Consumers, namely:
 - a- Withdrawal from the contract,
 - b- Requesting a price reduction,
 - c- Requesting free repair,
 - d- Requesting replacement with a non-defective equivalent.
- 4) If the consumer chooses the right of free repair, the seller is obliged to repair or have the product repaired free of charge, without demanding any fee from the consumer, such as the cost of transportation.
- 5) The consumer may also exercise this right against the manufacturer or importer. The seller, manufacturer, and importer are jointly and severally liable.
- 5) If the consumer uses the right of free repair and:
 - The product breaks down again within the warranty period,
 - The maximum repair time exceeds 45 days,
 - It is determined by an authorized service station, seller, manufacturer, or importer (by report) that repair is not possible;the consumer may request a refund, a price reduction proportional to the defect, or replacement with a non-defective equivalent, if possible. The seller may not refuse this request. If the request is not fulfilled, the seller, manufacturer, and importer are jointly and severally liable.
- 6) The warranty period shall not be interrupted by the repair.

This period starts from the date the fault is reported to the authorized service station or seller within the warranty period, or from the date the product is delivered to the authorized service station if outside the warranty period.
- 7) If the defect cannot be repaired within 10 business days, the manufacturer or importer may provide the consumer with another product of similar quality and price until the repair is completed.
- 8) If the product breaks down within the warranty period, the time spent in repair shall be added to the warranty period.
- 9) From the date of the instructions in the user manual are added outside the scope of the warranty.
- 10) In disputes arising from the exercise of warranty rights, the consumer may apply to the consumer protection authority or the Consumer Court.
- 11) The place of residence or where the consumer transaction was carried out.
- 12) If Warranty Certificate is not provided by the seller, the consumer may apply to the Consumer Protection and Market Surveillance of the Ministry of Trade.

Ouno Servis Tuzla Şube
Address: Tepeören Demokrasi Caddesi No:137 ,34959 Tuzla
Sadece kargo gönderimlerine hizmet vermektedir.

Ouno Servis Genel Merkez
Address: Atilla İlhan Cd. No:20,3450 Ataşehir/İstanbul
Sadece ön bürodan hizmet verilmektedir.

Website: <https://ounoservice.com/>
For authorized service centers, please visit <https://ounoservice.com/>, as
authorized by the distributor.

Company Name: Dura Communication and Trade Inc.
Address: Küçükbakkalköy Mah., Atilla İlhan Cd. No:22, 34750 Ataşehir,
İstanbul
Telephone: (0216) 469 40 60
Authorized Signature: **DÜRA NİŞANLI ve Ticaret A.Ş.**
Küçükbakkalköy Mah., Atilla İlhan Cd.
No:22, Ataşehir / İSTANBUL
Company Stamp: **Revizyon No: V.D. 302-045 0488**

Company Name: oraimo TECHNOLOGY LIMITED
Address: FLAT N 16/F BLOCK B UNIVERSAL INDUSTRIAL CENTRE 19-25 SHA
MEI STREET FOTAN NT HONGKONG
Email: hello.ab@oraimo.com

Company Name: oraimo TECHNOLOGY LIMITED
Address: FLAT N 16/F BLOCK B UNIVERSAL INDUSTRIAL CENTRE 19-25 SHA
MEI STREET FOTAN NT HONGKONG
Email: hello.ab@oraimo.com

- Before moving the device, ensure all connections are disconnected and cables removed.
- Use the original box and packaging materials for repacking.
- Avoid shock, impact, heat, humidity, and dust during use and transport.

No consumer serviceable or repairable parts. For maintenance or repair, contact an authorized service point listed in the Technical Service List.

- Turn off data connections (Bluetooth, Wi-Fi) when not in use.
- Lower screen brightness and set shorter screen timeout.
- Disable unnecessary sounds

This product complies with the AEEE Regulation



Proper disposal of the product

الاحتياطات

هذا المنتج متوافق فقط مع الأجهزة التي تدعم بروتوكولات الشحن المحددة. لا تعرض المنتج للبار أو تشحنه بالقرب من المناطق التي قد تصعب ساخنة. استمروا في تيار الشحن المحدد لتشغيل المنتج. لا تعرض المنتج للسوائل أو تستخدمه في البيئات الرطبة. استكشف الأخطاء وإصلاحها، يرجى الاتصال بخدمة ما بعد البيع للحصول على مساعدة. يحفظ بعيدا عن متناول الأطفال. يتخلص من المنتج بشكل منفصل عن النفايات المنزلية وفقا للوائح المحلية.

القطار	OCW-S203ECC
توني القاس	EU
الرجل	240-180 فوات-60/50 0.5 ايمير بحد أقصى
الإبراج 1 - Type-C1	5.0 فوات-3.0 ايمير 9 فوات-2.22 ايمير 12 فوات-1.67 ايمير 20 ايمير 24 ايمير بحد أقصى
الإبراج 2 - (USB-4)	5.0 فوات-3.0 ايمير 9 فوات-2.0 ايمير 12 فوات-1.5 ايمير 18 ايمير 24 ايمير بحد أقصى
الإبراج 1 + الإبراج 2	5.0 فوات-15 ايمير 5 ايمير بحد أقصى
نوع الشاحن	Type-C إلى Type-C
التعليق	نم
الإبراج	3 ايمير
*تحت إشراف oraimo	

smart accessorie

[illegible]

الاسم:	
اللقب:	
رقم الهاتف :	
تاريخ الشراء : (يوم/شهر/سنة)	
اسم المنتج:	
شركة الضمان:	

[illegible]

Tepeören Demokrasi Caddesi No:137, 34959 Tuzla / مزارع
 .Sadece kargo gönderimlerine hizmet vermektedir.
 Ouno Servis Genel Merkezi
 Atilla İhan Cd. No:20, 34750 Ataşehir/İstanbul / مزارع
 .Sadece ön bürodan hizmet verilmektedir.
 موقع الإلكتروني: <https://ounoservice.com/>
 إخطار على بوابتنا الخدمة المستعمدة، يرجى زيارة الموقع الإلكتروني: <https://ounoservice.com/> حسب ما
 نصه الموعود.

اسم الشركة: Dora Communication and Trade Inc.
 العنوان: Küçükbakkalköy Mah., Atilla İhan Cd, No:22, 34750 Ataşehir/İstanbul
 الهاتف: 60 40 469 (0216)
 التوقيع: DORA Yatırım ve Ticaret A.Ş.
 Küçükbakkalköy Mah., Atilla İhan Cd.
 No:22, 34750 Ataşehir / İSTANBUL
 رقم الحساب: V.D. 310 045 0408
 رقم السجل: No: 577285

اسم الشركة: oraimo TECHNOLOGY LIMITED
العنوان: شقة رقم 16/F، مجمع B، المركز الصناعي العالمي، 19-25 شارع شان ماي، حي فو تان إن شي، هونغ كونغ
البريد الإلكتروني: hello.ab@oraimo.com

اسم الشركة: oraimo TECHNOLOGY LIMITED
العنوان: شقة رقم F/16، مجمع B، المركز الصناعي العالمي، 19-25 شارع شان ماي، حي فونان إن تي، هونغ كونغ
البريد الإلكتروني: hello.ab@oraimo.com

- قبل نقل الجهاز، تأكد من فصل جميع اتصالات وإزالة الكابلات.
- استخدم العلبة الأصلية ومواد التغليف لإعادة التعبئة والتغليف.
- تجنب الصدمات والإزطام والحرارة والرطوبة والعيار أثناء الاستخدام والنقل.

لا توجد قطع غيار قابلة للتصيانة أو الإصلاح من قبل المستهلك، للتصيانة أو الإصلاح، اتصل بنقطة خدمة معتمدة مترجمة في قائمة الخدمات الفنية.

قم بإيقاف تشغيل اتصالات البيانات (البلوتوث، Wi Fi) عند عدم استخدامها.
قم بخفض سطوع الشاشة وحدد مهلة زمنية أقصر للشاشة.
قم بتعطيل الأصوات غير الضرورية

بموافقة: هذا المنتج مع لائحة AEEE.



تخلص من هذا المنتج بشكل صحيح.

يُشَرِّحُ هذا الرمز إلى أنه لا ينبغي التخلص من المنتج مع النفايات المنزلية الأخرى في جميع أنحاء الاتحاد الأوروبي.

المنتج أو المكون الضعيف أو الزيت أو مادة التزييت من التخلص من النفايات وتوزيع إعادة الاستعمال.

المستخدم للمواد الخطيرة، يرجى إعادة التدوير مسؤولة. إعادة منتج مستعمل، يرجى استخدام أنظمة الإرجاع.

والتخلص من النفايات، يرجى الرجوع إلى بلد المنشأ.

- قبل نقل الجهاز، تأكد من فصل جميع اتصالات وإزالة الكابلات.
- استخدم العلبة الأصلية ومواد التغليف لإعادة التعبئة والتغليف.
- تجنب الصدمات والإزطام والحرارة والرطوبة والعيار أثناء الاستخدام والنقل.