

oraimo

WELCOME GUIDE

NimbleType | OF-KK500N |

*Please read the instructions carefully before using the product and keep the user manual in a safe place for future reference.


SCAN & DOWNLOAD




oraimo store
Easily Smart, Simply Best

- | | |
|--------------------|----------------|
| Authentic Products | Fast Delivery |
| Best Price | Prompt Service |

PACKAGE CONTENTS




Keyboard x 1



Mouse
x 1





Nano Receiver
x1



Welcome Guide
x1

PRODUCT OVERVIEW

1. Caps Lock
2. Code Matching
3. Charging Indicator
4. Left Key
5. Roller
6. Right Key
7. DPI (Control the mouse sensitivity)



BASIC PRODUCT SPECIFICATIONS

Keyboard

Product Material: ABS+PC

Input: 5V=500mA

Charging Type: Type-C

Battery Capacity: 300mAh

Wireless Type: 2.4G

Size: 283.79 * 123 * 16.11 mm

Mouse

Battery Type: 1*AAA

Power Consumption: ≤12mA, 1.5V


Working Type: Photoelectricity

System: WIN 7 / WIN 8 / WIN 10 / Android / Mac


*oraimo Lab test results

USING INSTRUCTIONS

Step 1: Install the mouse batteries and remove the nano receiver.



- ① Take the battery cover off. ② Remove the nano receiver.




- ③ Insert a AAA battery into the battery compartment. Ensure that the + and - signs match the symbols in the compartment.

- ④ Put back the battery cover.




Tip: Store the nano receiver in the mouse when not used.

Step 2: Connect your keyboard and mouse to your computer




- ① Plug the nano receiver into the USB port on your computer.




- ② Slide the ON/OFF switch on your keyboard and mouse to ON. The computer will automatically detect them, so you can immediately use them.


INDICATOR INSTRUCTIONS



1. In capital input mode, the caps lock indicator turns green.



2. The keyboard powers on, the code matching indicator lights up, and enters the matching status.



3. The keyboard battery voltage is below 3.3V, the charging indicator flashes.
4. The charging indicator lights up during charging and turns off when fully charged.

TROUBLESHOOTING

My Keyboard is not working.

- Make sure that your keyboard is turned on.
- Move your keyboard closer to your computer.
- Make sure that your keyboard and the nano receiver are paired.
- Check if the keyboard is powered, if not, you can fully charge it first.
- Try connecting your nano receiver into a different USB port on your computer.
- Try removing or moving other wireless devices near the computer to prevent interference.

My mouse is not working.

- Make sure that your mouse is turned on.
- Move your mouse closer to your computer.
- Make sure the mouse is on a clean, flat, non-slippery surface to ensure smooth and accurate cursor action.

Could not use the mouse on reflective, transparent, or metallic surfaces.

- Make sure that your mouse and the nano receiver are paired.
- Replacing the mouse battery with a new one.
- Try connecting your nano receiver into a different USB port on your computer.
- Try removing or moving other wireless devices near the computer to prevent interference.

If your mouse pointer is too sensitive, or not sensitive enough, or your roller needs adjustment, do the following:

- Go to Control Panel > Hardware and Sound > Mouse (Windows 7), PC Settings > PC and Devices (Windows 8), or System Preferences > Mouse (Mac) and adjust the cursor or scrolling wheel settings.