

London Craftwork Leather Saddle Bike Bag User Manual

Brand Information

London Craftwork designs premium cycling accessories inspired by classic British craftsmanship. Our products are created to combine timeless style, durability, and everyday practicality for urban and touring cyclists alike.

Product Overview

Thank you for purchasing the London Craftwork Leather Saddle Bike Bag. This compact saddle bag is designed to securely store essential cycling items such as tools, keys, phone, wallet, or a spare inner tube. Crafted from high-quality leather, it offers a refined appearance with reliable performance for daily use.

Key Features

- Premium genuine leather for durability and classic appearance
- Compact size suitable for daily commuting and leisure rides
- Secure leather strap mounting system for saddle rails
- Structured design helps maintain shape over time
- Leather surface offers light resistance to splashes and road spray

Installation Instructions

- Position the bag beneath the bicycle saddle.
- Thread the leather straps around the saddle rails.
- Fasten and tighten the straps securely.
- Ensure the bag is stable and does not contact the rear wheel or seat post before riding.

Usage Guidelines

This product is designed for carrying small personal items only. Do not overload the bag beyond its intended capacity. Always verify that the bag is securely attached before each ride.

Leather Care & Maintenance

- Wipe clean with a soft, dry or slightly damp cloth
- Do not machine wash, soak, or submerge in water
- Apply a suitable leather conditioner periodically
- Store in a cool, dry place away from prolonged direct sunlight

Safety & Compliance Information

For safe use, always ensure the bag is properly secured before cycling. Discontinue use immediately if straps, stitching, or leather show signs of damage. This product is not a safety device and does not provide impact

protection.

Warranty & Customer Support

London Craftwork products are covered by a limited warranty against manufacturing defects. Normal wear and tear, misuse, or improper care are not covered. For warranty claims or product support, please contact the seller through Amazon messaging.