

WARNING:

Improper installation can lead to serious injury or death. This crankset must be installed correctly and securely according to the manufacturer's instructions. Use the correct tools and torque specifications. If you are unsure about any part of the installation process, please consult a qualified bicycle mechanic.

This crankset is not designed for use with all types of bicycles. Check the manufacturer's specifications for compatibility with your bike frame and drivetrain. Using this crankset outside of its intended application can result in failure, damage, and injury.

Crankset bolts must be tightened to the correct torque specifications. Overtightening can damage the crankset or frame, while undertightening can lead to loosening and failure.

Regular inspection and maintenance are crucial for safe use. Inspect the crankset for wear, damage, or loose components before each ride. Replace any worn or damaged parts immediately.

Do not use a crankset that is cracked, bent, or otherwise damaged. A damaged crankset can fail suddenly and cause a serious crash.

This crankset is not a substitute for proper riding technique and safety gear. Always wear a helmet, appropriate clothing, and follow traffic laws while riding.

Potential Risks:

Failure of the crankset can lead to loss of power and control, resulting in a crash. This could result in serious injury or death.

A loose crankset can damage other bike components.

Improper installation or maintenance can reduce the lifespan of the crankset.

Recommendations:

Always follow the manufacturer's instructions for installation and maintenance.

Consult a qualified bicycle mechanic if you have any questions or concerns.

Replace the crankset at the recommended intervals or when signs of wear or damage are present.

Ride within your limits and be aware of your surroundings.

By following these safety guidelines, you can help ensure a safe and enjoyable riding experience.