



Scootboot TheraRide Sizing Guide

Hoof Length (mm)	Hoof Width (mm)	TheraRide Size	Hoof Length (inches)	Hoof Width (inches)
105	95 - 110	0	4 1/8	3 3/4 - 4 1/4
110	100 - 115	1	4 1/4	4 - 4 1/2
115	105 - 120	2	4 1/2	4 1/8 - 4 3/4
120	110 - 125	3	4 3/4	4 1/4 - 5
125	115 - 130	4	4 15/16	4 1/2 - 5 1/8
130	120 - 135	5	5 1/8	4 3/4 - 5 5/16

These measurements are a guide only. They do not represent the inside dimensions of the Scoot Enduro.

Please note: An experienced sizing specialist must be referred to when using this chart to determine your Scoot Boot size. Hoof shape and heel bulb structure is also evaluated and affects finding the correct size. Refer to a Scoot Boot stockist near you or contact our sizing team at sizing@scootboots.com

Chart correct as of November 2024