

DESIGNTAK® - gör entré

Operation and maintenance of entrance canopies

Applies to all DesignTak in Sheet Metal, Glass, Aluminum & Stainless Steel

During installation

- Avoid walking on the roof
- After installation, rinse the roof with water and clean thoroughly. Drill chips and loose fasteners can cause rust formation
- Install snow guards when there is a risk of snow falling on the entrance roof
- Make sure that no loose objects can fall on the roof
- Electrical installations may only be carried out by a qualified professional

Disclaimer

Designtak i Småland AB disclaims all liability regarding installation and incorrect installation of the roof

Ongoing maintenance

- Remove snow if necessary
- Never hang or climb on the roof
- When painting, always follow the paint supplier's recommendations
- On glass roofs, immediately wipe away stains that may become permanent, such as alkaline substances

Maintenance must be performed and documented twice a year, spring and autumn, for the warranty to apply.

- Clean the gutter thoroughly, remove leaves etc.
- Check the tightness between the facade and the roof. If the adhesive has dried out, remove the existing one and replace it with new
- Check that there are no loose objects such as roof tiles etc. that could fall onto the roof
- Stainless steel can be cleaned with window cleaner that does not contain chlorides (table salt)

Maintenance of glass roofs

- Use a soft, damp cloth on the glass surface and edges. In case of heavy soiling, use a mild hand washing-up liquid

Never use!

- Agents containing ammonia or alkaline cleaning agents
- Solvents, alcohol or bleach
- Preparations containing abrasives or having an abrasive effect
- Rough or scratchy cleaning sponges, scouring powder, steel wool, brushes, razor blades or other sharp tools

Maintenance of stainless-steel outdoor brackets

Stainless steel outdoor brackets are exposed to weather, dirt and, in coastal environments, even salt, which can lead to rust and discoloration.

- **Regular cleaning:** Wash with lukewarm water and mild detergent at least 4 times a year. Rinse and dry.
- **Rust and stains:** Remove rust with baking soda and water or a rust remover. Avoid steel wool and chlorine-based cleaners.
- **Protection:** Apply a thin layer of silicone oil or special polish to maintain the shine and reduce dirt accumulation.
- **Extra protection in exposed environments:** Rinse the railing regularly with clean water and clean more often in coastal areas.

By following these simple steps, the brackets will stay beautiful and rust-free for a long time.

Warranty

The warranty period, which according to ABM 07 is 5 years, is calculated from the date of delivery from Designtak i Småland AB

Sheet metal roof 10 years Easy Collection 5 years