Schedule Option 3


AUXILIARY AIR SUSPENSION

- Install the compressor on a dry location (under a seat or in a closet)
- Always operate the compressor when the engine is running

- Il est impèratif de placer le compresseur dans un endroit sec (sous un siège ou dans un coffre)
- Utilisez toujours le compresseur lorsque le moteur du véhicule est en marche

- Installieren Sie dan Kompressor auf einen trockene Stelle (unter einen sitz in ein Staufach oder in einer Schrank)
- Bedienen Sie immer den Kompressor, wenn der Motor läuft


- Plaats de compressor op een droge locatie (onder een stoel of in een bergruimte)
- Bedien de compressor alleen met een draaiende motor





DUNLOP and the Flying D device are trademarks of Sumitomo Rubber Group and are used under lisence by DSC Nederland B.V.

Schedule Option 3

AUXILIARY AIR SUSPENSION







Nr.	Code	Connect to	Anschließen	Relier	Aansluiten aan
1	15	12 V + ignition	12 V + Zündung	12 V + allumage	12 V + contact
2	30	12 V + battery	12 V + Batterie	12 V + batterie	12 V + accu
3	31	Earth	Masse	Messe	Massa

DUNLOP and the Flying D device are trademarks of Sumitomo Rubber Group and are used under lisence by DSC Nederland B.V.