


76581M - LUMIPLUS FLEXI PLUG&PLAY

Revision no.: 0 | Date: 28-11-2024



 Piezas del despiece (kits o unitarios)

POS.	CÓDIGO	DESCRIPCIÓN
1	4403010114	LIGHT SCREWS
2	4403010115	HORIZONTAL CABLE GUIDES
3	4403010117	VERTICAL CABLE GUIDES
4	4403010076	PACKING GLAND ASSEMBLY

POS.	CÓDIGO	DESCRIPCIÓN
5	4403015405	PROJECTOR CABLE, PACKING GLANDS PROJECTOR
6	4403011905	LIGHT CABLE
7	4403010248	REMOTE CONTROL WITH WALL MOUNT