

PRODUCT OVERVIEW

- Full Touchscreen
- Home Button
- Charging Cable x1
- Replaceable Watch Strap x1
- Welcome Guide x1
- Watch Strap
- Heart Rate Sensor
- Charging Port

SETTING UP YOUR SMART WATCH

For your best experience, we recommend using the latest version health app for iOS and Android.

For Your iOS Phone

Get ready with the Oraimo health app, use the QR code on our watch to find the Oraimo health app in one of your favorite app stores, depending on your device.

The App Store for iPhone

When the app is installed, open and follow the instructions that help you create your account, or log in to your existing account.

Your account needs the information such as height, weight, and gender to make various calculations and better health monitoring for you.

Long press the Home Button of the watch to turn on, follow the on-screen instructions to set up the language, and get ready pairing with the phone.

Scan the QR Code to Pair

Use Oraimo health app to scan the QR code on the watch.

If you can't scan successfully, try the following methods:

1. Make sure the QR permission is allowed for the app.

2. Make sure the watch is not connected with another phone.

3. Try turning off the screen lock (passcode) on your phone.

4. Turn off the Bluetooth of the watch, and restart the above steps.

After pairing with your phone, read through this guide to explore the various functions.

BT CALLING

Make sure your phone and the watch for the BT Calling function, make sure the BT for the call on the watch is switched on.

1. Press the Home button, select and tap Call on on the main screen, then switch on the BT for the call on the watch.

2. In the BT list of the mobile phone, connect to "Oraimo Watch Master" and you can use watch to make calls.

GETTING TO KNOW YOUR SMART WATCH

Wrist Placement

For all-day wear, your watch should easily rest a finger's width below your wrist bone and remain snug every second.

Charge Your Watch

Connect the metal contacts on the charging dock to those on the back of the device, then insert the cable.

Connect the charging cable to a power supply, the device's screen will light up and display the charging status.

2. If the smartwatch was in contact with water, wear a clean, dry cloth (soaked in alcohol) for 24 hours, and wipe the metal contacts before charging.

* For white series, the product version at last capacity during shipping.
Please fully charge the product before using.

DS-01

DS-02

DS-03

DS-04




HOŞ GELDİN KILAVUZU

Watch Model : 1009-B116

* Öncelikli müşteriler, özel satışları kapsamında diğer kampanyalar, kısımlardan dolayı bu kılavuzdan önce teslimatları yapılmıştır.

ÜRÜN GENEL BAKIŞI



AKILLI SAAT KURMA

Özellikler: 1. 1.5 inç ekran, 2. 1.5 inç ekran, 3. 1.5 inç ekran, 4. 1.5 inç ekran, 5. 1.5 inç ekran, 6. 1.5 inç ekran, 7. 1.5 inç ekran, 8. 1.5 inç ekran, 9. 1.5 inç ekran, 10. 1.5 inç ekran, 11. 1.5 inç ekran, 12. 1.5 inç ekran, 13. 1.5 inç ekran, 14. 1.5 inç ekran, 15. 1.5 inç ekran, 16. 1.5 inç ekran, 17. 1.5 inç ekran, 18. 1.5 inç ekran, 19. 1.5 inç ekran, 20. 1.5 inç ekran, 21. 1.5 inç ekran, 22. 1.5 inç ekran, 23. 1.5 inç ekran, 24. 1.5 inç ekran, 25. 1.5 inç ekran, 26. 1.5 inç ekran, 27. 1.5 inç ekran, 28. 1.5 inç ekran, 29. 1.5 inç ekran, 30. 1.5 inç ekran, 31. 1.5 inç ekran, 32. 1.5 inç ekran, 33. 1.5 inç ekran, 34. 1.5 inç ekran, 35. 1.5 inç ekran, 36. 1.5 inç ekran, 37. 1.5 inç ekran, 38. 1.5 inç ekran, 39. 1.5 inç ekran, 40. 1.5 inç ekran, 41. 1.5 inç ekran, 42. 1.5 inç ekran, 43. 1.5 inç ekran, 44. 1.5 inç ekran, 45. 1.5 inç ekran, 46. 1.5 inç ekran, 47. 1.5 inç ekran, 48. 1.5 inç ekran, 49. 1.5 inç ekran, 50. 1.5 inç ekran, 51. 1.5 inç ekran, 52. 1.5 inç ekran, 53. 1.5 inç ekran, 54. 1.5 inç ekran, 55. 1.5 inç ekran, 56. 1.5 inç ekran, 57. 1.5 inç ekran, 58. 1.5 inç ekran, 59. 1.5 inç ekran, 60. 1.5 inç ekran, 61. 1.5 inç ekran, 62. 1.5 inç ekran, 63. 1.5 inç ekran, 64. 1.5 inç ekran, 65. 1.5 inç ekran, 66. 1.5 inç ekran, 67. 1.5 inç ekran, 68. 1.5 inç ekran, 69. 1.5 inç ekran, 70. 1.5 inç ekran, 71. 1.5 inç ekran, 72. 1.5 inç ekran, 73. 1.5 inç ekran, 74. 1.5 inç ekran, 75. 1.5 inç ekran, 76. 1.5 inç ekran, 77. 1.5 inç ekran, 78. 1.5 inç ekran, 79. 1.5 inç ekran, 80. 1.5 inç ekran, 81. 1.5 inç ekran, 82. 1.5 inç ekran, 83. 1.5 inç ekran, 84. 1.5 inç ekran, 85. 1.5 inç ekran, 86. 1.5 inç ekran, 87. 1.5 inç ekran, 88. 1.5 inç ekran, 89. 1.5 inç ekran, 90. 1.5 inç ekran, 91. 1.5 inç ekran, 92. 1.5 inç ekran, 93. 1.5 inç ekran, 94. 1.5 inç ekran, 95. 1.5 inç ekran, 96. 1.5 inç ekran, 97. 1.5 inç ekran, 98. 1.5 inç ekran, 99. 1.5 inç ekran, 100. 1.5 inç ekran, 101. 1.5 inç ekran, 102. 1.5 inç ekran, 103. 1.5 inç ekran, 104. 1.5 inç ekran, 105. 1.5 inç ekran, 106. 1.5 inç ekran, 107. 1.5 inç ekran, 108. 1.5 inç ekran, 109. 1.5 inç ekran, 110. 1.5 inç ekran, 111. 1.5 inç ekran, 112. 1.5 inç ekran, 113. 1.5 inç ekran, 114. 1.5 inç ekran, 115. 1.5 inç ekran, 116. 1.5 inç ekran, 117. 1.5 inç ekran, 118. 1.5 inç ekran, 119. 1.5 inç ekran, 120. 1.5 inç ekran, 121. 1.5 inç ekran, 122. 1.5 inç ekran, 123. 1.5 inç ekran, 124. 1.5 inç ekran, 125. 1.5 inç ekran, 126. 1.5 inç ekran, 127. 1.5 inç ekran, 128. 1.5 inç ekran, 129. 1.5 inç ekran, 130. 1.5 inç ekran, 131. 1.5 inç ekran, 132. 1.5 inç ekran, 133. 1.5 inç ekran, 134. 1.5 inç ekran, 135. 1.5 inç ekran, 136. 1.5 inç ekran, 137. 1.5 inç ekran, 138. 1.5 inç ekran, 139. 1.5 inç ekran, 140. 1.5 inç ekran, 141. 1.5 inç ekran, 142. 1.5 inç ekran, 143. 1.5 inç ekran, 144. 1.5 inç ekran, 145. 1.5 inç ekran, 146. 1.5 inç ekran, 147. 1.5 inç ekran, 148. 1.5 inç ekran, 149. 1.5 inç ekran, 150. 1.5 inç ekran, 151. 1.5 inç ekran, 152. 1.5 inç ekran, 153. 1.5 inç ekran, 154. 1.5 inç ekran, 155. 1.5 inç ekran, 156. 1.5 inç ekran, 157. 1.5 inç ekran, 158. 1.5 inç ekran, 159. 1.5 inç ekran, 160. 1.5 inç ekran, 161. 1.5 inç ekran, 162. 1.5 inç ekran, 163. 1.5 inç ekran, 164. 1.5 inç ekran, 165. 1.5 inç ekran, 166. 1.5 inç ekran, 167. 1.5 inç ekran, 168. 1.5 inç ekran, 169. 1.5 inç ekran, 170. 1.5 inç ekran, 171. 1.5 inç ekran, 172. 1.5 inç ekran, 173. 1.5 inç ekran, 174. 1.5 inç ekran, 175. 1.5 inç ekran, 176. 1.5 inç ekran, 177. 1.5 inç ekran, 178. 1.5 inç ekran, 179. 1.5 inç ekran, 180. 1.5 inç ekran, 181. 1.5 inç ekran, 182. 1.5 inç ekran, 183. 1.5 inç ekran, 184. 1.5 inç ekran, 185. 1.5 inç ekran, 186. 1.5 inç ekran, 187. 1.5 inç ekran, 188. 1.5 inç ekran, 189. 1.5 inç ekran, 190. 1.5 inç ekran, 191. 1.5 inç ekran, 192. 1.5 inç ekran, 193. 1.5 inç ekran, 194. 1.5 inç ekran, 195. 1.5 inç ekran, 196. 1.5 inç ekran, 197. 1.5 inç ekran, 198. 1.5 inç ekran, 199. 1.5 inç ekran, 200. 1.5 inç ekran, 201. 1.5 inç ekran, 202. 1.5 inç ekran, 203. 1.5 inç ekran, 204. 1.5 inç ekran, 205. 1.5 inç ekran, 206. 1.5 inç ekran, 207. 1.5 inç ekran, 208. 1.5 inç ekran, 209. 1.5 inç ekran, 210. 1.5 inç ekran, 211. 1.5 inç ekran, 212. 1.5 inç ekran, 213. 1.5 inç ekran, 214. 1.5 inç ekran, 215. 1.5 inç ekran, 216. 1.5 inç ekran, 217. 1.5 inç ekran, 218. 1.5 inç ekran, 219. 1.5 inç ekran, 220. 1.5 inç ekran, 221. 1.5 inç ekran, 222. 1.5 inç ekran, 223. 1.5 inç ekran, 224. 1.5 inç ekran, 225. 1.5 inç ekran, 226. 1.5 inç ekran, 227. 1.5 inç ekran, 228. 1.5 inç ekran, 229. 1.5 inç ekran, 230. 1.5 inç ekran, 231. 1.5 inç ekran, 232. 1.5 inç ekran, 233. 1.5 inç ekran, 234. 1.5 inç ekran, 235. 1.5 inç ekran, 236. 1.5 inç ekran, 237. 1.5 inç ekran, 238. 1.5 inç ekran, 239. 1.5 inç ekran, 240. 1.5 inç ekran, 241. 1.5 inç ekran, 242. 1.5 inç ekran, 243. 1.5 inç ekran, 244. 1.5 inç ekran, 245. 1.5 inç ekran, 246. 1.5 inç ekran, 247. 1.5 inç ekran, 248. 1.5 inç ekran, 249. 1.5 inç ekran, 250. 1.5 inç ekran, 251. 1.5 inç ekran, 252. 1.5 inç ekran, 253. 1.5 inç ekran, 254. 1.5 inç ekran, 255. 1.5 inç ekran, 256. 1.5 inç ekran, 257. 1.5 inç ekran, 258. 1.5 inç ekran, 259. 1.5 inç ekran, 260. 1.5 inç ekran, 261. 1.5 inç ekran, 262. 1.5 inç ekran, 263. 1.5 inç ekran, 264. 1.5 inç ekran, 265. 1.5 inç ekran, 266. 1.5 inç ekran, 267. 1.5 inç ekran, 268. 1.5 inç ekran, 269. 1.5 inç ekran, 270. 1.5 inç ekran, 271. 1.5 inç ekran, 272. 1.5 inç ekran, 273. 1.5 inç ekran, 274. 1.5 inç ekran, 275. 1.5 inç ekran, 276. 1.5 inç ekran, 277. 1.5 inç ekran, 278. 1.5 inç ekran, 279. 1.5 inç ekran, 280. 1.5 inç ekran, 281. 1.5 inç ekran, 282. 1.5 inç ekran, 283. 1.5 inç ekran, 284. 1.5 inç ekran, 285. 1.5 inç ekran, 286. 1.5 inç ekran, 287. 1.5 inç ekran, 288. 1.5 inç ekran, 289. 1.5 inç ekran, 290. 1.5 inç ekran, 291. 1.5 inç ekran, 292. 1.5 inç ekran, 293. 1.5 inç ekran, 294. 1.5 inç ekran, 295. 1.5 inç ekran, 296. 1.5 inç

[illegible]

IMTACITE

[illegible][illegible][illegible]

Waste and Repairs

For maintenance or repair, contact an authorized service point.

When not in use, please turn off.



Product complies with the AEEZ Regulation.

Product must be disposed of together with other household waste across measurement in human health from unpermitted waste disposal and recovery, please recycle responsibly. To return a good product, please return it from where the product was purchased. They refer accordingly.

Auth

Store

EN 12

[illegible][illegible][illegible][illegible][illegible][illegible][illegible][illegible][illegible][illegible]

شهادة التخرج	
الاسم :	
الطرح :	
رقم الشهادة :	
تاريخ التخرج :	
(mm/yy/yy)	
اسم المقرر :	
رقم المقرر :	

[illegible][illegible][illegible][illegible]