

Part Numbers



Item	Description	Part No.
1	Canopy	6951
2	Mantle Assembly	4205
3	Cone Spacer	6794
4	Cone Retainer Washer	6884
5	Ceramic Cone	6171
6	Burner Assembly LPG	4640
	Burner Assembly NATGAS	4639
7	Dust Filter	3343
8	Screw M4 x 10 mm Long	7135
10	Main Injector	6883
11	Spark Tray	4624
12	Nut Flange M12	7021
13	Venturi Brush - (Not Supplied With Heater)	6284
14	Adaptor Stud	6245
15	Main Feed Assembly	3104
16	Pilot Feed Assembly "V" Only	3107
	Pilot Feed Assembly "SX" Only	3012
	Pilot Feed Assembly Old "V" & "S" Only	3106
18	Pilot Injector - Non Windjammer Models	6452
20	Windjammer Pilot Assembly - See Below	— —
21	Cap Screw M6 x 10 mm Long	7042
22	Pipe Support Bracket	6049
23	Suspension Chain Assembly	3073
24	Nut Hex. M12 Stainless Steel	7020
25	Washer M12	7116
26	Chain Suspension Bracket	6045
27	Port Cleaner, Brass Bristle - (Not Supplied With Heater)	5784
28	Probe Bracket Kit	3069
29	Brass Nut 3/8" BSP	6219
30	Brass Olive 3/8" BSP	6255

Thermocouples


17	Thermocouple M10 "V"	6299
	Thermocouple M8 "F", "MX" & "SX"	6095

Jets

9	Main Jet - See Page 2	— —
19	Pilot Jet - See Page 2	— —



Windjammer Pilots



Key	Description	Part No.
A	Windjammer Pilot - E40 F / V / SX - LPG	4628
B	Windjammer Pilot - E40 F / V / SX - NATGAS	4618
C	Windjammer Pilot Tube Assembly - All LPG Models - Spares	4620
D	Windjammer Pilot Tube Assembly - All NATGAS Models - Spares	4621
E	Windjammer Pilot Injector - All Models - Spares	6777