

# Guide book for building earthquake-resistant houses in confined masonry



Schweizerische Eidgenossenschaft  
Confédération suisse  
Confederazione Svizzera  
Confederaziun svizra



Swiss Agency for Development  
and Cooperation SDC



# **Guide book for building earthquake-resistant houses in confined masonry**

---

**Guide book for technical training for earthquake-resistant  
construction of one to two-storey buildings  
in confined masonry**

**GUIDE BOOK FOR BUILDERS**  
masons - steel trades - carpenters

COMPETENCE CENTER FOR RECONSTRUCTION - CCR

SWISS AGENCY FOR DEVELOPMENT AND COOPERATION  
HUMANITARIAN AID - SDC/HA

EARTHQUAKE ENGINEERING RESEARCH INSTITUTE  
EERI



Schweizerische Eidgenossenschaft  
Confédération suisse  
Confederazione Svizzera  
Confederaziun svizra

Swiss Agency for Development  
and Cooperation SDC



**Revised version, August 2015**

**Technical team**

Architects CCR, CSA (Swiss Humanitarian Aid Unit)  
Nadia Carlevaro (EERI), Guillaume Roux-Fouillet

**Illustrations**

Architects CCR (Competence Center for Reconstruction, Haïti)  
Guillaume Roux-Fouillet, Tom Schacher, Nadia Carlevaro  
Martin Siegrist, Dorothee Hasnas

**Review team**

Tom Schacher - architect CSA, EERI  
Svetlana Brzev, Tim Hart - Confined Masonry Network, EERI  
Marjorie Greene, Maggie Ortiz - EERI  
Andrew Charleson, World Housing Encyclopedia

**Published by**

Swiss Agency for Development and Cooperation - SDC  
Humanitarian Aid - HA  
Sägenstrasse 77, Köniz  
3003 Bern - Switzerland

**and**

Earthquake Engineering Research Institute - EERI  
449 14th Street, Suite 220  
Oakland, California, USA, 94612-1934

**Revised version, August 2015**

<h1>Table of contents</h1>	
<b>Introduction</b>	<b>09</b>
<b>1 The mason's world</b>	<b>11</b>
Mason's tools 1	12
Mason's tools 2	13
Formwork tools	14
Steel reinforcement tools	15
Quality of materials	16
Storage of building materials on site	17
Construction site protection	18
<b>2 Confined masonry for two-storey houses</b>	<b>19</b>
Confining elements (ties)	20
A strong house	21
Shape of the house	22
Shear walls	23
Seismic gap	24
Vertical continuity of walls	25
<b>3 Finding an adequate location</b>	<b>27</b>
Site selection: where to build	28
Flood related hazards	29
Building on a slope	30
<b>4 Layout</b>	<b>31</b>
Site preparation	32
Tracing a right angle ( 3 : 4 : 5 )	33
Layout	34

<b>5</b>	<b>5 Stone foundation</b>	<b>35</b>
	Excavation	36
	Foundation dimensions	37
	Special foundations	38
	Stepped foundations	39
	Stone masonry construction	40
	Reinforced concrete strip footing	41
	Curing and ground floor	42
	Placing sewage pipes	43
<b>6</b>	<b>6 Reinforced Concrete Ties</b>	<b>45</b>
	Types of steel rebars	46
	Steel bar diameters	47
	Stirrups	48
	Alternate stirrup positions	49
	Stirrup spacing	50
	Lap length	51
	Tie-beam : T-connection	52
	Tie-beam : L-connection	53
	Tie-beam to Tie-column connection	54
	Protection of rebar ends	55
<b>7</b>	<b>7 Formwork</b>	<b>57</b>
	Formwork for Ties	58
	Vertical formwork	59
	Horizontal formwork	60
	Spacers - 1	61
	Spacers - 2	62

<b>8 Concrete</b>	<b>63</b>
Concrete mix ( 1 : 2 : 3 )	64
Mixing concrete	65
Concrete test	66
Slump test	67
Pouring concrete : Tie-Columns	68
Pouring concrete : Tie-Beams	69
Curing the concrete elements	70
Ensure good quality concrete	71
<b>9 Bricks &amp; Blocks</b>	<b>73</b>
Which clay bricks to use	74
Brick test	75
Which concrete blocks to use	76
Block test	77
Concrete mix for blocks ( 1 : 4 : 3 )	78
Making the blocks	79
<b>10 Masonry walls</b>	<b>81</b>
Cement mortar mix ( 1 : 5 )	82
Cement-lime mortars	83
Masonry wall heights	84
Masonry bonds	85
Toothing	86
Toothing options	87
Dowels	88
Preparing the masonry units	89
Good masonry practice - 1	90
Good masonry practice - 2	91

<b>11 Seismic reinforcement</b>	<b>93</b>
Vertical reinforcement (V)	94
Horizontal reinforcement (H)	95
Adding vertical bands	96
Adding horizontal bands	97
Sill band and lintel band	98
Connect seismic band to tie-column	99
Size of openings	100
Door reinforcement (V)	101
Small window reinforcement (V)	102
Large window reinforcement (V)	103
Small window reinforcement (H)	104
Large window reinforcement (H)	105
<b>12 Slab</b>	<b>107</b>
Placing of slab reinforcement	108
Hollow block slab : formwork	109
Hollow block slab : main reinforcement	110
Hollow block slab : secondary rebars	111
Hollow block slab : positioning pipes - 1	112
Hollow block slab : positioning pipes - 2	113
Hollow block slab : pouring concrete	114
Full concrete slab	115
<b>13 Light roof</b>	<b>117</b>
Roof shape	118
Gable wall	119
Roof structure - Trusses	120
Cyclones	121
Fastening of the veranda framing	122
Fastening of the roof structure	123
Bracing	124

<b>14 Future extensions</b>	<b>125</b>
Preparation	126
Add anchor bars	127
Place reinforcement	128
Extension of the structure	129
<b>15 Retaining walls</b>	<b>131</b>
Where to build with retaining walls	132
Rule 1 - Wall footing	133
Rule 2 - Slope of the wall ( 5 : 1 )	134
Rule 3 - Dimensions of the wall	135
Rule 4 - Placing the stones	136
Rule 5 - Through-stones (or bands)	137
Rule 6 - Drainage	138
Retaining wall - Confining elements	139
<b>16 Construction drawings</b>	<b>141</b>
Reading plans	142
Reading sections	143
Plan dimensions	144
Section dimensions	145



---

# INTRODUCTION

---

This Guide is intended for the training of professional masons in confined masonry. It can be used as a building guide at construction sites or as a training resource. It is presented in a simple manner and explains in a step-by-step sequence how to build a one or two-storey confined masonry house.

The Guide was developed for masons working in developing countries. The recommendations are intended to be conservative (on the safe side) and to ensure life safety of the occupants of the house.

This Guide needs to be adapted in consideration of the type and quality of locally available materials and local capacities. The technical recommendations contained in the Guide should be in compliance with local construction codes and other regulations (when available).

Illustrations included in the Guide may be adapted to suit the local culture and perceptions and to ensure good acceptance. The text may be translated into a local language which the masons are able to read and understand.


While the authors have tried to be as accurate as possible, they cannot be held responsible for construction that might be based on the material presented in this guide. The authors and their organizations disclaim any and all responsibility for the accuracy of any of the material included in the guide.



---

# THE MASON'S WORLD


---



# Mason's tools 1



guide book



tape measure



straight edge



level



pencil



plumb  
line



string

nail



chalk line




aluminium screed



machete



screen (05, 03)



trowel

float



hammer



chisel




club hammer



# Mason's tools 2



bucket



mixing box



cone for slump test



big brush



transparent water hose  
10 -20 m



pickaxe




shovel




rammer




grinder




needle vibrator



concrete mixer



wheelbarrow



vibrating block/brick press

# Formwork tools



guide book



tape measure



straight edge



level



pencil



plumb  
line



string

nail



hammer



chisel



crowbar



axe



saw




plane



# Steel reinforcement tools



guide book



tape measure



straight edge



level



pencil



chalk



plumb line



string nail



wire twister or pincer



pliers



tin snips



hammer



chisel



plastic pipes of different diameters



hacksaw



rebar bender




chain bolt cutter

# Quality of materials

The quality of materials is essential to ensure safe construction !



**Water :**  
clean and non-salty



**Blocks & bricks :** (ch. 9)  
minimal size and strength



**Sand :**  
river sand,  
washed and dry



**Cement :**  
portland cement,  
new and dry bags



**Gravel :**  
crushed or round,  
from hard rock and clean,  
well-graded, max size 18-20 mm




**Steel bars :**  
standard size,  
ribbed steel, grade 60  
new and not corroded

# Storage of building materials on site




Store cement bags away from the sun  
and protected from humidity.  
Do not place on the ground !



Store wood and steel bars in a dry environment.  
Do not place on the ground !

# Construction site protection

Do not forget that health and security concerns everybody, starting with oneself !




If people are injured on a construction site, wash the wound with clean water and soap and go to a doctor !

---

# CONFINED MASONRY FOR TWO-STOREY HOUSES

---




# Confining elements (ties)

Confining the walls is like holding a pile of books together with a string: they can still move but they will not fall apart.




Horizontal ties (tie-beam) and vertical ties (tie-column).




✓ YES


only tie-columns




✗ NO



only tie-beams



✗ NO



# A strong house


All walls and openings should be confined to ensure stability during an earthquake !

**Confining elements :** (chapters 6-8)

tie-column and tie-beams (plinth beam and ring beam)


**Anchoring bands and opening reinforcement :** (chapter 11)

seismic bands (lintel & sill bands) and vertical reinforcement




# Shape of the house

**YES, THIS IS CORRECT !**




Maximum ratio 1 to 3.




Each facade must have at least one tied wall without openings = shear walls.

**NO, THIS IS NOT CORRECT !**




Openings are too big.




Free standing wall without any tie.

# Shear walls


Shear walls are walls without windows or with a small window outside of the diagonals of the wall !



Full shear wall



Opening is too big:  
Not a shear wall !




Opening is small and  
outside the diagonals:  
It is a shear wall !


# Seismic gap

Avoid complex shapes by creating seismic gaps.

Simple shape : BETTER




Complex shape : WORSE



# Vertical continuity of walls

✓ YES




Vertical structure

Walls must be placed continuously one on top of the other. From ground to the roof!

✗ NO

Cantilevered



The opening is too large.


No vertical continuity between the upper and the lower wall.




---

# FINDING AN ADEQUATE LOCATION


---




# Site selection: where to build



Don't build on embankments.



Don't build on fresh embankments.




Don't build on stilts.




Don't build too close to a cliff.




Don't build at the foot of a cliff.




# Flood related hazards



Don't build at the bottom of a canyon.



Don't build near a river.



Don't build near the ocean  
(due to tsunami hazard).

# Building on a slope




✓ YES

Build between retaining walls.



✗ NO

Don't build against a retaining wall.




✗ NO

Don't build on top of a retaining wall.

---

# LAYOUT

---




# Site preparation



Remove the topsoil and the excavated material, and place it in 2 (or more) different heaps, away from the excavated area.




Check whether the ground is level by using a transparent hose filled with water.




# Tracing a right angle ( 3 : 4 : 5 )





3	4	5
30 cm	40 cm	50 cm
60 cm	80 cm	100 cm
90 cm	120 cm	150 cm
1,5 m	2 m	2,5 m
2,1 m	2,8 m	3,5 m
3 m	4 m	5 m
3 ft	4 ft	5 ft
6 ft	8 ft	10 ft
9 ft	12 ft	15 ft



# Layout



Drive in nails in order to pull strings.




---

# STONE FOUNDATION


---

5




# Excavation

Place the soil you have dug up to a minimum of 60 cm away from the trenches, to avoid its falling back into the excavation.



**WARNING : dig until you find firm soil and then build the foundation with the proper width !!!**




## Foundation height :

hard soil :	min 30 cm
rammed soil :	min 50 cm
soft soil :	min 80 cm

## Foundation width :


hard soil :	40 cm
rammed soil :	60 cm
soft soil :	70 cm

# Foundation dimensions




## Hard soil

height : 30-50 cm  
width : 40 cm  
strip footing : 40 cm



## Rammed soil

height : 50-80 cm  
width : 50 cm  
strip footing : 50 cm




## Soft soil

height : min 80 cm  
width : 70 cm  
strip footing : 70 cm

**Warning !**  
height above the ground :  
maximum 20 cm !

# Special foundations

If the part above ground is higher than 20 cm,  
then the foundation acts as a retaining wall.  
**Do not exceed 40 cm above the ground !**





**Foundation height :**  
rammed soil : min 50 cm  
soft soil : min 80 cm

**Foundation width :**  
rammed soil : min 60 cm  
soft soil : min 70 cm

**Avoid building in a flood-prone area !**


# Stepped foundations

If you build on a slope, the foundation must be stepped, keeping the bottom of the trench always horizontal !




**Avoid building parallel to the slope !**

# Stone masonry construction



Place all the stones in a horizontal position !



Do not place the stones in a vertical position !




**Place through-stones :**


Horizontally : at least every 1 m

Vertically : at least every 50 cm

Place through-stones in section :





Place through-stones in plan :




# Reinforced concrete strip footing

**A strip footing is a must for soft soil conditions !**  
It is also recommended for other soil conditions.




**Strip footing :**  
Width 40 cm = 4 rebars  
Width 50 cm = 4 rebars  
Width 70 cm = 5 rebars

**Before pouring the concrete, make sure the reinforcement is perfectly vertical !**



Leave a space around the reinforcement for the concrete.




# Curing and ground floor

**Cure the foundation walls !**  
Wet every day,  
for the three first days !


Always interrupt  
foundation work  
on a sloped line.




**Build a "drainage bed" to avoid moisture coming in !**



# Placing sewage pipes



**The pipe must go through the foundation, under the plinth beam !**




**Do not go through the plinth beam !**



---


# Reinforced Concrete Ties

---




# Types of steel rebars

Use ribbed steel for all rebars.  
Only stirrups can be made of smooth steel.



For confined masonry **Grade 60** should be used!  
Always use **standard rebars** (not sub-standard)!

Strength indication are written on the rebar :




**Do not use second hand rebars !**




# Steel bar diameters

For rebars :




For stirrups:



Rebars diameters (imperial and metric) :


imperial	inch	metric	rebars	stirrups
#6	3/4 in.	19 mm	✗	✗
#5	5/8 in.	16 mm	✗	✗
#4	1/2 in.	12 mm	✓	✗
#3	3/8 in.	10 mm	✓	✗
-	1/3 in.	8 mm	✗	✓
#2	1/4 in.	6 mm	✗	✓

Rebar dimensions for vertical and horizontal ties :




# Stirrups


Bend stirrup ends at 45° !




If stirrups are not bent at 45°, they will open during an earthquake !



Possible stirrup types :



# Alternate stirrup positions




It is necessary to alternate position of stirrup hooks !!

# Stirrup spacing

## Rules for stirrup spacing:


1. At the top and bottom of each tie-column and ends of tie-beams place the **first stirrup at 5 cm spacing**, then place stirrups at **10 cm spacing** over a length of  **$H/6$**  (better 60cm).

2. Place stirrups at **20 cm spacing** elsewhere.




# Lap length

The concrete keeps the rebars together like tight fists :  
the more fists we have (longer overlap)  
the stronger the connection !




Tie wires only hold the rebars in place. They don't add strength to the connections !




Lap length :  
(overlapping)  
 $50 \times \varnothing$   
(50 times the diameter)

for 10 mm rebar = 50 cm  
for 12 mm rebar = 60 cm

# Tie-beam : T-connection




**Always :**  
extend hooked bars from the inside to the outside !




**Lap length :**  
(overlapping)  
 **$50 \times \varnothing$**   
(50 times the diameter)  
for 10 mm rebar = 50 cm  
for 12 mm rebar = 60 cm

Connection with  
straight bars.





Connection around  
the inner corner.



# Tie-beam : L-connection


Rebars must cross like the fingers of a hand !




Extend hooked bars from the inside to the outside !

Put an additional rebar around the outer corner.


Connection with straight bars.



Hooked bars from inside to inside.





# Tie-beam to Tie-column connection



If the wall ends here, bend the vertical rebars into the tie-beam.

**One-storey building**


If the wall continues, add vertical rebars with an 50 Ø overlapp.





**Two-storey building**

# Protection of rebar ends

Protect rebar ends with lean concrete.



Exposed rebar ends will rust and cannot be reused.






---

# FORMWORK



---



# Formwork for Ties

## Block walls :



20cm wall thickness :  
place formwork boards  
on both sides.



15cm wall thickness:  
Place a 1 inch board  
under the formwork  
board.

## Brick walls :

15-24cm wall thickness :  
place formwork boards  
on both sides.




15cm wall thickness:  
Place a 1 inch board  
under the formwork  
board.


**Sizes of tie-columns and tie-beams :**  
20 x 20 cm recommended / 15 x 20 cm minimum !

# Vertical formwork

Vertical formwork at upper floor level :



Vertical formwork at ground floor level :



# Horizontal formwork


YES  
✓

NO




Don't use tie wire.

Use wood planks to connect formwork.



Formwork must be well fastened !

To be able to reuse the formwork, use small nailed planks. Do not use tie wire. !







Formwork must be well braced !

# Spacers - 1


Spacers are very important : they ensure that the rebars remain in the right place and are well covered by concrete.

Don't use stones to fix the rebars, use spacers instead !




# Spacers - 2

Add spacers on all sides  
to avoid rebars touching the formwork.




tie-column


Alternate the position of the spacers around the stirrups !




plinth beam



tie-beam



reinforced concrete slab




joist and pan slab

---

# CONCRETE

---



# Concrete mix ( 1 : 2 : 3 )

1 part  
cement



3 parts  
gravel  
(max. 18mm)



2 parts  
clean sand  
(washed  
and dry)



3/4 part  
clean  
water



**Table of various concrete mixes (by volume) :**

	Cement	Sand	Gravel	Strength	
minimum	→ 1	2	4	200 kg/m <sup>3</sup>	
preferred	→ 1	2	3	250 kg/m <sup>3</sup>	✓
	1.5	2	3	350 kg/m <sup>3</sup>	

**Preferred mix = ( 1 : 2 : 3 ) = 250 kg/m<sup>3</sup> !**

**Note :**

Concrete should have a minimum amount of 300 kg of cement per cubic metre. The values taken into account in this manual are lower (min. 200 kg/m<sup>3</sup>), to allow for a concrete not made properly by untrained workforce.

# Mixing concrete

## Mixing the concrete by hand :



1. Make a pile with the gravel, the sand and the cement but without water!



2. Mix the pile without water and move it twice with a shovel.



3. Add the water and mix again.  
**Add the water only at the end !**

## Mixing with a concrete mixer :



1. Add 1/2 water and cement, mix 1 minute.
2. Add aggregate, mix 1 minute.
3. Add rest of water slowly, mix 3-4 min.

**Always use the concrete within 90 min after mixing !!!**

# Concrete test

## QUICK TEST :


Take a handful of concrete.  
If the concrete leaks through  
your fingers, it is too wet !



Concrete must be **used in less than 90 min.**  
Never "refresh" dried concrete by adding water !  
Don't mix too much concrete at a time !

# Slump test


Use a standard steel cone :



## SLUMP TEST PROCEDURE :





1. Fill cone in 3 equal layers.



2. Tamp down each layer 25 times with a rod (rebar).



3. Lift the cone vertically and place next to the slump.




**Result** : the difference between slump and cone should be less then 12.5cm !

# Pouring concrete : Tie-Columns




Never add water to make the concrete more liquid and "flow down better" !




Use a stick (or rebar) and a hammer to help the concrete flow down, to compact it and avoid air pockets.  
**Use a mechanical vibrator if one is available !**

# Pouring concrete : Tie-Beams



Use a stick (or rebar) and a hammer to help the concrete flow down, to compact it and avoid air pockets.  
Use a mechanical vibrator if one is available !



Roughen up the top surface of the plinth beam  
to increase bonding of the mortar for the wall

# Curing the concrete elements


**Concrete needs water to harden !**

After placing concrete, cure the concrete by wetting the formwork 3 times a day for 3 days. Remove formwork only after three days !



After formwork is removed, cure the concrete for 7 days, and cover it with plastic sheets.

# Ensure good quality concrete




Poor compaction :  
the concrete is weakened !




---

# BRICKS & BLOCKS


---




# Which clay bricks to use




Best brick :  
solid burnt clay brick  
with frogs.



Good brick :  
vertical holes less then  
50% of surface area.




Bad brick :  
vertical holes more then  
50% of surface area.



Bad brick :  
with horizontal holes  
(cannot carry weight).

**Solid bricks are better then multiperforated ones !**




**Note** : we recommend to use 10MPa bricks.

# Brick test

## Visual test :

1. regular in form
2. uniform colour
3. not warped
4. no visible flaws or lumps



NO 



NO 



NO 



NO 

## Physical test :

1. Bricks cannot be easily scratched by a knife.




2. Resists the "3 point test" :  
Person standing on a brick spanning between two other bricks.




3. Bricks must give a ringing sound when struck against each other.

# Which concrete blocks to use




YES

Best block :  
15-20 cm thick,  
solid block.




YES

Best block :  
15-20 cm thick,  
with 4 holes.




YES

Satisfactory block :  
15-20 cm thick,  
with 3 holes.



YES


**Only if excellent quality !**  
20 cm thick,  
with 2 holes.



**Note** : we recommend to use 10MPa blocks.


# Block test

Test blocks before buying them !



Acceptable quality :  
(less than 1 broken)

Drop 5 blocks  
from 1.5 m height  
on hard surface !  
(concrete surface)




Bad quality : don't buy !  
(more than 1 broken)

Check if blocks were  
cured in the shade !



Stored in the shade : good.




Blocks that dry in  
the sun : very bad !



Stored under plastic sheets : good !

# Concrete mix for blocks ( 1 : 4 : 3 )



Sand should be crushed, washed and dried.  
Do not use sea beach sand !



1. Make a pile with the gravel, the sand and the cement but without water!



2. Mix the pile without water and move it twice with a shovel.



3. Add water and mix again !


**Add water only at the end !**

# Making the blocks

**Wait 8 days before using the blocks !**

Fill the molds with the mixture.


If possible use a vibrating machine !




To compact the concrete, hit the mold with a shovel and a hammer.



Cover the blocks with plastic sheets immediately!



Store the blocks in the shade.




Cure the blocks 3 times a day for **minimum 7 days** and cover with plastic sheets.



---

# MASONRY WALLS

---



# Cement mortar mix ( 1 : 5 )

Mix the mortar:



1 part  
cement

5 parts  
clean sand  
(washed and dry)

3/4 part  
clean water



1. Make a pile with  
the sand and the  
cement but without  
water!

**Use 1:3 mix ratio  
for 15cm or less  
wall thickness !**



2. Mix the pile without  
water and move it twice  
with a shovel.



3. Add the water  
and mix again.

**Add the water  
only at the end !**

# Cement-lime mortars


## Cement-Lime mortar

has lower compressive strength than simple cement mortar but offers a better workability, higher elasticity, and it is more economical !

Recommended mortar mix proportions :

	Cement	Lime	Sand	
	x	y	z	
preferred →	1	0.5	4.5	✓
	1	1	6	
minimum →	1	2	9	


Mix the mortar:



# Masonry walls height


The Width of masonry unit defines the wall height.

For bricks: Height smaller then 25 x wall Width  
 For blocks : Height max 22 x wall Width  
**Height = maximum 3m !**




# Masonry bonds

✓ YES



Solid wall = Running bond  
vertical joints are not continuous.


✗ NO



Weak wall = Stack bond  
vertical joints are continuous.

# Toothing



Toothing :  
min 5cm / max 13cm




Distance from  
blocks or bricks :  
**minimum 3 cm !**  
(same length as last  
bone of thumb).

Toothing 1/3-1/4 of a block :  
(max 1/2 of brick length)  
**GOOD !**

Toothing 1/2 of a block :  
( $>$  1/2 of brick length)  
**TOO BIG !**




# Toothing options



50% running bond  
toothing

**Clay bricks (23-24 cm):**


50% running bond  
(half of a brick)  
Toothing = max 12 cm



50% running bond  
toothing

**Concrete blocks (40 cm):**

50% running bond  
(half of a block)  
**Break 1/3 of last block!**  
Toothing = min 5 cm



33% running bond  
toothing

**Concrete blocks (40 cm):**

33% running bond  
(1/3 - 2/3 of a block)  
Toothing = max 13 cm



# Dowels

Although tothing is the optimal method, the use of dowels can be an alternative.

**Dowels are 6mm rebars**

**Place dowels :**


- > **50 cm** within the bed joints of the wall
- > **place in pairs**  
every 2 layers of blocks  
every 4 layers of bricks




**Note :**

Dowels should be covered with enough mortar to protect them properly. **Test if dowels can be placed properly !**

# Preparing the masonry units



... or ...



Soak the blocks  
in water for a  
while...

... water them  
with a brush  
before use.

... or ...




... water all blocks together.

# Good masonry practice - 1


Use a plank as guide to ensure the wall is in plumb and straight.

**Stack blocks one course at a time !**



Cure the concrete with water before laying the blocks.


**Important : fill vertical joints with mortar !**




Joints : 10 - 15 mm  
= the width of the pinky finger !

# Good masonry practice - 2

Don't build more than 6 courses of masonry per day!  
And then add a seismic band if needed.



Protect the wall in warm weather:  
mortar must not dry out in the sun!




Keep wall moist by pouring water on them 3 times a day for 7 days and/or by covering them with a plastic sheet for 7 days.



---



# SEISMIC REINFORCEMENT

---





# Vertical reinforcement (V)

Place a vertical band on each side of every opening !  
Add a horizontal reinforcement band above all openings !



# Horizontal reinforcement (H)


Place a seismic band below and above every opening!  
Don't go higher than 6 courses of blocks, don't exceed 1.20m !



# Adding vertical bands

Place vertical reinforcement on each side of every opening.

Vertical bands are "half tie-columns" : **add two rebars.**




**Vertical bands :**  
(for openings)

Width : 10 cm

2 Rebars : 10 mm

Stirrups : 6 mm (@ 15cm)

If a wall between openings functions as shear wall, the vertical reinforcement is identical to a tie-column : **add four rebars !**




# Adding horizontal bands


Add horizontal bands to the walls if :

- > the quality of materials and construction is not ensured
- > if the Height is smaller than 1.5 of the Length


Rule :  
 $H < 1.5 \times L$




~~NO~~



YES ✓



# Sill band and lintel band



## Seismic bands :

Height (bricks) 7.5 cm


Heights (blocks) 10 cm

2 Rebars : 10 mm

Stirrups : 6 mm @15 cm


Roughen up the top surface of the bands to increase bonding of the masonry mortar.

spacer



Place a stirrup every 15 cm !

# Connect seismic band to tie-column




# Size of openings

In walls that are not shear walls, the width of the openings should not exceed half of the length of the wall.


**Rule :**  
**b smaller than  $a/2$**

✓ YES



Correct: b smaller than  $a/2$


✗ NO



Incorrect : b bigger than  $a/2$


# Door reinforcement (V)

Hook the door vertical reinforcement rebars and lap 30cm with the tie-beam rebars, under the stirrups.  
Do the same with lintel band and the vertical bands.




# Small window reinforcement (V)

For windows smaller than 90 cm.





Hook the window vertical reinforcement and lap 30 cm with the tie-beams reinforcement, inside the stirrups.

Do the same with the horizontal reinforcement and the vertical bands.




# Large window reinforcement (V)

For windows larger than 90 cm.




# Small window reinforcement (H)

For windows smaller than 90 cm.





Hook the window reinforcement and lap  $30 \text{ cm}$  with the seismic band reinforcement, inside the stirrups.



# Large window reinforcement (H)

For windows larger than 90 cm.






---

# SLAB


---



# Placing of slab reinforcement

Placement of primary rebars.


Step 1



Primary rebars are placed in the shorter direction (span).

Placement of secondary rebars.


Step 2




Secondary rebars are placed on top of and perpendicular to the primary rebars

# Hollow block slab: formwork


✓ **GOOD FORMWORK**




✗ **BAD FORMWORK**







# Hollow block slab: main reinforcement








To ensure a good connection, it is important to insert the hooked slab rebars deep into the bond beam.



# Hollow block slab: secondary rebars




# Hollow block slab: positioning pipes 1



# Hollow block slab: positioning pipes 2


✓ YES

Place pipes in block holes.




✓ YES

Place pipes in service duct.



✗ NO

Don't place pipes in walls or in ties !




Test watertightness of the pipes before pouring concrete by filling them with water.

# Hollow block slab: pouring concrete




Water the formwork before pouring concrete.




Use a stick (or rebar) and a hammer to compact the concrete and avoid air pockets.

# Full concrete slab



Curing the concrete :  
create ponds with  
sand or mud and fill  
them with water for  
a week.






---

# LIGHT ROOF

---



# Roof shape




✓ Good  
YES



✓ Better  
YES




✓ Better  
YES




✗ Not so good  
AVOID

# Gable wall



YES ✓


Concrete tie  
on top of the  
gable wall.



YES ✓

# Roof structure - Trusses

**X AVOID**




Building with planks :  
**AVOID**

(not enough room for nails)

**✓ YES**



Building with solid timber :  
**GOOD**




Building with plywood gusset :  
**BETTER !**


**Timber connections :**

Put at least  
**3 nails in each direction !**

**Nails length** should be  
**twice the thickness** of the  
timber !




# Cyclones




YES



Keep verandas independent from main roof : cyclones may tear off the verandas.



YES



YES




Opened gable wall.




Main roof becoming veranda.

If a veranda is part of the main roof, then a cyclone could tear off the whole roof.

# Fastening of the veranda framing




# Fastening of the roof structure




Solidly fasten the anchors or straps to the wood framing.

Close the spaces between trusses with a plank or a screen to avoid insects.

# Bracing




Bracing :  
wood planks nailed  
to the trusses.



---



# FUTURE EXTENSIONS

---




# Preparation

Open all corners, all rebar connections.




Build a new solid foundation for the new room.

# Add anchor bars




Add hooks : 10 mm rebars.




Place the hooks around the vertical rebars :  
one on top and one under each stirrup.

# Place reinforcement




Connect the new plinth beam to the existing one with the hooks.

Place the 10 mm hooks and then place both the ring beams (tie-beams) and the tie-columns.




Connect each corner the same way !

# Extension of the structure



Pour concrete for the plinth beam and fill completely the opened corners.

Build the masonry walls first and only after pour the concrete for the tie columns.




The walls and tie-elements for future extensions should align with the existing structure (existing tie-elements).



---


# RETAINING WALLS

---



# Where to build with retaining walls


A retaining wall doesn't support a house.  
A retaining wall only holds back the ground!



Don't built your house too close to a retaining wall.




Don't build your house on top of a retaining wall.




Don't build your house against a retaining wall.

# Rule 1 - Wall footing




**Height : bottom of wall to firm soil !**

- hard soil : 30 cm
- rammed soil : 30 cm - 60 cm
- soft soil : 60 cm - 90 cm




# Rule 2 - Slope of the wall ( 5 : 1 )



Chart

$$H : L = 5 : 1$$




H	L
100	20
125	25
150	30
175	35
200	40
250	50


## Slope 1:5

Every time you go up 5 cm, move back 1 cm !

Every time you go up 1 meter, move back 20 cm !



# Rule 3 - Dimensions of the wall



**Height above ground (H) :**  
 H max = 2.50 m !

**Top (C) :** min 50cm !  
 50 cm :  $H \leq 150$  cm  
 55 cm :  $H > 150 < 250$  cm  
 60 cm :  $H \geq 250$  cm

**Total height (A) :**  
 $A = H + B$   
 (-> B = 30-80 cm)


**Wall base width (D) calculation :**  
 The base of the wall (D) equals the total height (A) divided by 5, plus the top's width (C) :

$$D = A/5 + C$$

Table


H	C	B	A	D
100	50	30-80	130-180	75-85
125	50	30-80	155-205	80-90
150	50	30-80	180-230	85-95
175	55	30-80	205-255	95-100
200	55	30-80	230-280	100-110
250	60	30-80	280-330	115-125

## Rule 4 - Placing the stones




Place the stones on their flat faces and tilt them towards the back.

Place the stones at right angles to the wall's external face.





Don't place the stones in vertical position !




Don't place the stones at grade !

# Rule 5 - Through-stones (or bands)




# Rule 6 - Drainage

✓ YES




Place a drainage pipe every 1.50 m !  
(vertically and horizontally)

✗ NO



# Retaining wall - Confining elements

These recommendations are for building a house on retaining walls: **only if there is no other solution !**



## Tie-columns



Every 3 - 4.50 m

## Tie-beams

Must go all around the foundation !

Every 1 m height  
Add one at the top !

**If possible :  
avoid building  
the house on  
retaining walls !!!**







---

# CONSTRUCTION DRAWINGS

---




# Reading plans



To draw a plan, cut the house at the window height.


Door symbol :  
indicates the direction  
of opening of the door.



House plan (seen from the top).


# Reading sections

If you vertically cut the house on this line ...



same window

... this is what you will see !




# Plan dimensions


The sum of all partial dimensions must result in the total dimension.

Partial dimensions

Total dimension




# Section dimensions





## COPYRIGHT

This guidebook as well as its use (unless otherwise indicated) are protected by a license. The author is the Swiss Agency for Development and Cooperation (SDC).



 **Attribution** - You must give appropriate credit, provide a link to the license, and indicate if changes were made. You may do so in any reasonable manner, but not in any way that suggests the licensor endorses you or your use.

 **NonCommercial** - You may not use the material for commercial purposes.

 **ShareAlike** - If you remix, transform, or build upon the material, you must distribute your contributions under the same license as the original.





This Guide was originally developed by the Competence Center for Reconstruction of the Swiss Agency for Development and Cooperation (SDC) after the devastating January 2010 Haiti earthquake.

It was developed as a resource for the mason training programme related to confined masonry construction practice, which was launched as a response to the urgent need to establish an earthquake-resistant construction practice in Haiti. Its main purpose was to improve construction practices in areas where housing construction occurs without technical input.

This guide was used at construction sites and as a resource material for mason training programmes. It offered simple but essential advice on building safer houses using the confined masonry construction technology.

This version of the Guide was adapted by SDC together with members of the Confined Masonry Network of the Earthquake Engineering Research Institute (EERI) for use in various countries and regions of the world.

It is hoped that this resource that was first developed in Haiti will be useful in other countries facing the same challenges. The users may include local governmental and non-governmental organizations, international humanitarian and development agencies, and most importantly skilled and unskilled masons around the world.

**Revised version, August 2015**